




# LASERJET ENTERPRISE M855 LASERJET ENTERPRISE FLOW MFP M880


## Repair Manual




M855dn




M855xh



M855x+



M880z



M880z+





# HP Color LaserJet Enterprise M855 and flow MFP M880

Repair Manual

**Copyright and License**

© 2013 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number: A2W77-90997


Edition 1, 11/2013


**Trademark Credits**


Microsoft®, Windows®, Windows® XP, and Windows Vista® are U.S. registered trademarks of Microsoft Corporation.

## Conventions used in this guide


---

 **TIP:** Helpful hints or shortcuts.

 **NOTE:** Information that explains a concept or how to complete a task.

 **IMPORTANT:** Information to help you avoid potential product error conditions.

 **CAUTION:** Procedures that you should follow to avoid losing data or damaging the product.

 **WARNING!** Alerts you to specific procedures that you must follow to avoid personal injury, catastrophic loss of data, or extensive damage to the product.

---



---

# Table of contents

<b>1 Removal and replacement .....</b>	<b>1</b>
Removal and replacement strategy .....	2
Considerations during removal and replacement .....	2
Required tools .....	3
Types of screws .....	3
Service approach .....	3
Before performing service .....	4
After performing service .....	4
Parts removal order .....	4
Supported paper sizes and types .....	4
Supported paper sizes for the input trays and duplexer .....	5
Supported paper types for the input trays and duplexer .....	7
Supported paper sizes for the finishing accessories .....	9
Supported paper types for the finishing accessories .....	12
Customer-self repair assemblies .....	14
Toner cartridge .....	14
Imaging drum .....	15
Secondary transfer roller .....	16
Reinstall the secondary transfer roller .....	17
Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 .....	18
Intermediate transfer belt (ITB) .....	19
Fuser .....	21
Switch back tray .....	22
Formatter .....	23
Reinstall the formatter or install a replacement formatter .....	24
Hard-disk drive (HDD) or solid-state memory (SSM) .....	25
Identify the storage device .....	25
Remove the HDD .....	26
Reinstall the HDD .....	27
Remove the SSM .....	28
Reinstall the SSM .....	29
Reinstall the product firmware .....	30

Memory DIMM .....	32
Remove the memory DIMM .....	32
Reinstall the memory DIMM .....	33
Fax PCA (M880) .....	35
Remove the fax PCA (M880) .....	35
Document feeder mylar strip (M880) .....	36
Install a replacement document feeder mylar strip (M880) .....	37
Document feeder white backing (M880) .....	39
Install a replacement document feeder white backing (M880) .....	40
Background selector (M880) .....	44
Reinstall the background selector (M880) .....	46
Control panel assembly (M855) .....	47
Reinstall the control panel assembly (M855) .....	52
Control panel assembly (M880) .....	53
Reinstall the control panel assembly (M880) .....	57
Keyboard assembly (M880) .....	59
Remove the keyboard assembly (M880) .....	59
Reinstall the keyboard assembly (M880) .....	63
Pickup, feed, and separation rollers and pads .....	67
Document-feeder roller (M880 only) .....	68
Reinstall the document-feeder roller (M880 only) .....	69
Document-feeder separation pad (M880 only) .....	70
Reinstall the document-feeder separation pad (M880 only) .....	72
Tray 1 rollers .....	75
Reinstall the Tray 1 rollers .....	77
Tray 2, 1x500-sheet feeder, and 3x500-sheet feeder rollers .....	78
Remove the Tray 2, 1x500-sheet feeder, and 3x500-sheet feeder rollers .....	78
Reinstall the Tray 2, 1x500-sheet feeder, and 3x500-sheet feeder rollers .....	79
High-capacity input (HCI) rollers .....	80
Remove the HCI rollers .....	80
Reinstall the HCI rollers .....	81
Covers and doors .....	82
Location of major components .....	84
Scanner back cover (M880) .....	88
Scanner left cover (M880) .....	89
Remove the scanner left cover (M880) .....	89
Scanner right cover (M880) .....	90
Remove the scanner right cover (M880) .....	90
Scanner front cover (M880) .....	91
Remove the scanner front cover (M880) .....	91
Right upper rear cover (M855) .....	96

Hardware integration pocket (HIP) cover (M855) .....	97
Hardware integration pocket (HIP) cover (M880) .....	98
Reinstall the HIP cover (M880) .....	100
Face-down bin .....	101
Reinstall the face-down bin .....	102
Left rear cover .....	104
Remove the left rear cover .....	104
Switch back cover .....	105
Lower right cover .....	106
Rear upper rear cover (M880) .....	107
Right upper rear cover (M880) .....	108
Rear upper MFP cover (M880) .....	109
Reinstall the rear upper MFP cover (M880) .....	110
Left upper rear cover and rear upper B cover (M880) .....	111
Remove the left upper rear cover and rear upper B cover (M880) .....	111
Rear upper front cover (M880) .....	113
Remove the rear upper front cover (M880) .....	113
Front top cover .....	115
Remove the front top cover .....	115
Rear top cover (M855) .....	116
Remove the rear top cover (M855) .....	116
Left cover .....	118
Remove the left cover .....	118
Right upper front cover (M855) .....	120
Remove the right upper front cover (M855) .....	120
Right upper front cover (M880) .....	122
Remove the right upper front cover (M880) .....	122
Right upper cover (M855) .....	124
Remove the right upper cover (M855) .....	124
Right door assembly .....	129
Remove the right door assembly .....	129
Reinstall the right door assembly .....	132
Left front cover .....	133
Remove the left front cover .....	133
Install a replacement left front cover .....	136
Front door .....	137
Reinstall the front door .....	141
Rear cover .....	143
Remove the rear cover .....	143
Install a replacement rear cover .....	144
Right rear cover .....	146

Remove the right rear cover .....	146
Front inner cover .....	147
Remove the front inner cover .....	147
Reinstall the front inner cover .....	148
Main assemblies .....	149
Location of major components .....	152
Document feeder assembly (M880) .....	154
Remove the document feeder assembly (M880) .....	154
Reinstall the document feeder assembly (M880) .....	159
Scanner control board (SCB) (M880) .....	160
Remove the SCB (M880) .....	160
Scanner assembly (M880) .....	162
Remove the scanner assembly (M880) .....	162
Reinstall the scanner assembly (M880) .....	166
Interlock switch assembly .....	167
Remove the interlock switch assembly .....	167
Front-door open detection switch .....	169
Remove the front-door open detection switch .....	169
Reinstall the front-door-open detection switch .....	171
Main switch assembly .....	173
Remove the main switch assembly .....	173
Secondary transfer assembly .....	175
Remove the secondary transfer assembly .....	175
Reinstall the secondary transfer assembly .....	181
Multipurpose tray (Tray 1) drive assembly .....	183
Remove the multipurpose tray (Tray 1) drive assembly .....	183
Multipurpose tray (Tray 1) guide assembly .....	190
Remove the multipurpose tray guide assembly .....	190
Tray 2 pickup unit .....	191
Remove the Tray 2 pickup assembly .....	191
Fuser home position sensor .....	192
Remove the fuser home position sensor .....	192
Reinstall the fuser home position sensor .....	193
Shutter gear holder assembly .....	194
Remove the shutter gear holder assembly .....	194
Reinstall the shutter gear holder assembly .....	196
Fuser-edge area cooling fan FM10 (front) .....	200
Remove the fuser-edge area cooling fan FM10 (front) .....	200
Reinstall the fuser-edge area cooling fan FM10 (front) .....	202
Fuser-edge area cooling fan FM9 (rear) .....	204
Remove the fuser-edge area cooling fan FM9 (rear) .....	204

Reinstall the fuser-edge area cooling fan FM9 (rear) .....	205
Fuser fan FM2 .....	207
Remove the fuser fan FM2 .....	207
Reinstall the fuser fan FM2 .....	209
Fuser fan duct .....	211
Remove the fuser fan duct .....	211
Reinstall the fuser fan duct .....	213
Cartridge fan FM3 (yellow and magenta) .....	214
Remove the cartridge fan FM3 (yellow and magenta) .....	214
Reinstall the cartridge fan FM3 (yellow and magenta) .....	216
Cartridge fan FM4 (cyan and black) .....	218
Remove the cartridge fan FM4 (cyan and black) .....	218
Reinstall the cartridge fan FM4 (cyan and black) .....	220
Laser/scanner fan FM1 .....	222
Remove the laser/scanner fan FM1 .....	222
Reinstall the laser/scanner fan FM1 .....	224
Delivery fan FM8 .....	226
Cartridge front area cooling fan FM7 .....	228
Remove the cartridge front area cooling fan FM7 .....	228
Reinstall the cartridge front area cooling fan FM7 .....	229
Memory tag PCA .....	230
Remove the memory tag PCA .....	230
Reinstall the memory tag PCA and sheet-metal bracket .....	232
Image-drum motor .....	233
Remove the image-drum motor .....	233
Fuser power supply .....	235
Remove the fuser power supply .....	235
Reinstall the fuser power supply .....	236
Primary transfer-roller disengagement motor .....	238
Remove the primary transfer-roller disengagement motor .....	238
Intermediate transfer belt (ITB) alienation-drive assembly .....	240
Remove the ITB alienation-drive assembly .....	240
Fuser motor .....	242
Remove the fuser motor .....	242
Intermediate transfer belt (ITB) motor .....	243
Remove the ITB motor .....	243
Toner-cartridge feed motor (black) .....	244
Remove the toner-cartridge feed motor (black) .....	244
Toner-cartridge feed motor (yellow, magenta, and cyan) .....	245
Remove the toner-cartridge feed motor (yellow, magenta, and cyan) .....	245
Environmental sensor .....	247

Remove the environmental sensor .....	247
Interconnect PCA (M855) .....	248
Remove the interconnect PCA (M855) .....	248
Reinstall the interconnect PCA (M855) .....	251
Interconnect PCA (M880) .....	252
Remove the interconnect PCA (M880) .....	252
Reinstall the interconnect PCA (M880) .....	254
Formatter case .....	255
Remove the formatter case .....	255
Reinstall the formatter case .....	256
Formatter, formatter case, and interconnect board (ICB) .....	257
Remove the formatter, formatter case, and ICB .....	257
Reinstall the formatter, formatter case, and ICB .....	259
High-voltage power supply (HVPS) B .....	260
Remove the HVPS B .....	260
Reinstall the HVPS B .....	261
DC controller PCA .....	263
Remove the DC controller PCA .....	263
Color-plane registration (CPR) sensor assembly .....	264
Remove the CPR sensor assembly .....	264
Reinstall the CPR sensor assembly .....	267
Low-voltage power supply (LVPS) .....	269
Remove the LVPS .....	269
High-voltage power supply (HVPS) A (first transfer) .....	272
Remove the HVPS A (first transfer) .....	272
Reinstall the HVPS A (first transfer) .....	274
Lifter-drive assembly .....	276
Remove the lifter-drive assembly .....	276
Reinstall the lifter-drive assembly .....	278
Toner-cartridge drive assembly (yellow and magenta) .....	280
Remove the toner-cartridge drive assembly (yellow and magenta) .....	280
Reinstall the toner-cartridge drive assembly (yellow and magenta) .....	281
Toner-cartridge drive assembly (cyan and black) .....	282
Remove the toner-cartridge drive assembly (cyan and black) .....	282
Reinstall the toner-cartridge drive assembly (cyan and black) .....	283
Cartridge interface PCA (cyan and black) .....	284
Remove the cartridge interface PCA (cyan and black) .....	285
Cartridge interface PCA (yellow and magenta) .....	286
Remove the cartridge interface PCA (yellow and magenta) .....	287
Main drive assembly .....	288
Remove the main drive assembly .....	289

Reinstall the main drive assembly .....	290
Replace or reinstall the toner-cartridge drive assemblies or the main drive assembly ....	291
Replace the toner-cartridge drive assembly or the main drive assembly .....	291
Reinstall the toner-cartridge drive assembly or the main drive assembly .....	296
Fuser drive assembly .....	298
Remove the fuser drive assembly .....	298
Reinstall the fuser drive assembly .....	303
Scanner cover .....	306
Remove the scanner cover .....	306
Laser/scanner assembly (yellow and magenta) .....	307
Remove the laser/scanner assembly (yellow and magenta) .....	307
Reinstall the laser/scanner assembly (yellow and magenta) .....	311
Laser/scanner assembly (cyan and black) .....	312
Remove the laser/scanner assembly (cyan and black) .....	312
Reinstall the laser/scanner assembly (cyan and black) .....	317
Duplex reverse assembly (M855) .....	319
Remove the duplex reverse assembly (M855) .....	319
Duplex reverse assembly (M880) .....	320
Remove the duplex reverse assembly (M880) .....	320
VOC fan (M855) .....	321
Remove the VOC fan (M855) .....	321
VOC fan (M880) .....	323
Remove the VOC fan (M880) .....	324
Face-down delivery assembly(M855) .....	327
Remove the face-down delivery assembly (M855) .....	327
Face-down delivery assembly (M880) .....	332
Remove the face-down delivery assembly (M880) .....	333
Face-down cover .....	343
Remove the face-down cover .....	344
Duplexing feed assembly .....	345
Reinstall the duplexing feed assembly .....	349
Multipurpose tray (Tray 1) pickup assembly .....	350
Remove the multipurpose tray (Tray 1) pickup assembly .....	350
Reinstall the multipurpose tray (Tray 1) pickup assembly .....	355
Input accessories .....	356
High-capacity input (HCI) feeder .....	357
Location of major components .....	357
HCI right tray .....	360
HCI left tray .....	361
HCI rear cover .....	362
HCI right lower cover .....	363

Remove the HCI right lower cover .....	363
HCI right tray pickup motor .....	365
Remove the HCI right tray pickup motor .....	365
HCI right tray pickup drive .....	366
Remove the HCI right tray pickup drive .....	366
HCI left tray pickup motor .....	367
Remove the HCI left tray pickup motor .....	367
HCI left tray pickup drive .....	368
Remove the HCI left tray pickup drive .....	368
HCI right tray lifter drive assembly .....	369
Remove the HCI right tray lifter drive assembly .....	369
HCI left tray lifter drive assembly .....	370
Remove the HCI left tray lifter drive assembly .....	370
HCI right tray media-level sensor assembly .....	371
Remove the HCI right tray media-level sensor assembly .....	371
HCI left tray media-level sensor assembly .....	372
Remove the HCI left tray media-level sensor assembly .....	372
HCI right tray automatic close assembly .....	373
Remove the HCI right tray automatic close assembly .....	373
HCI left tray automatic close assembly .....	374
Remove the HCI left tray automatic close assembly .....	374
HCI right tray pickup assembly .....	375
Remove the HCI right tray pickup assembly .....	375
Reinstall the HCI right tray pickup assembly .....	376
HCI left tray pickup assembly .....	377
Remove the HCI left tray pickup assembly .....	377
Reinstall the HCI left tray pickup assembly .....	379
HCI merge assembly .....	380
Remove the HCI merge assembly .....	380
Reinstall the HCI merge assembly .....	381
HCI controller PCA .....	382
Remove the HCI controller PCA .....	382
1x500- and 3x500-sheet feeders .....	383
Location of major components .....	383
1x500 and 3x500 rear cover .....	387
1x500 and 3x500 right front cover .....	388
Remove the 1x500 and 3x500 right front cover .....	388
Reinstall the 1x500 and 3x500 right front cover .....	389
1x500 and 3x500 upper front face cover .....	390
Remove the 1x500 and 3x500 upper front face cover .....	390
Reinstall the 1x500 and 3x500 upper front face cover .....	391

1x500 and 3x500 upper front cover .....	392
Remove the 1x500 and 3x500 right front cover .....	392
1x500 and 3x500 upper front left face cover .....	395
Remove the 1x500 and 3x500 upper front left face cover .....	395
1x500 storage box door .....	396
Remove the 1x500 storage box door .....	396
1x500 storage box .....	398
Remove the 1x500 storage box .....	398
1x500 and 3x500 right lower cover .....	400
Remove the 1x500 and 3x500 right lower cover .....	400
1x500 Tray 3 pickup assembly .....	402
Remove the 1x500 Tray 3 pickup assembly .....	402
Reinstall the 1x500 Tray 3 pickup assembly .....	405
3x500 Tray 3 pickup assembly .....	407
Remove the 3x500 Tray 3 pickup assembly .....	407
Reinstall the 3x500 Tray 3 pickup assembly .....	410
3x500 Tray 4 pickup assembly .....	412
Remove the 3x500 Tray 4 pickup assembly .....	412
Reinstall the 3x500 Tray 4 pickup assembly .....	415
3x500 Tray 5 pickup assembly .....	416
Remove the 3x500 Tray 5 pickup assembly .....	416
Reinstall the 3x500 Tray 5 pickup assembly .....	418
1x500 Tray 3 automatic close assembly .....	419
Remove the 1x500 Tray 3 automatic close assembly .....	419
3x500 Tray 3, Tray 4, and Tray 5 automatic close assemblies .....	420
Remove the 3x500 Tray 3, Tray 4, and Tray 5 automatic close assemblies .....	420
1x500 Tray 3, 3x500 Tray 3, Tray 4, and Tray 5 pickup motors .....	422
Remove the 1x500 Tray 3, 3x500 Tray 3, Tray 4, and Tray 5 pickup motors .....	422
1x500 and 3x500 controller PCA .....	424
Remove the HCI controller PCA .....	424
Shared input accessory covers and doors .....	425
HCI, 1x500, and 3x500 left cover .....	425
Remove the HCI, 1x500, and 3x500 left cover .....	426
Reinstall the HCI, 1x500, and 3x500 left cover .....	427
HCI, 1x500, and 3x500 right door assembly .....	428
Remove the HCI, 1x500, and 3x500 right door assembly .....	428
HCI, 1x500, and 3x500 right rear cover .....	430
Remove the HCI, 1x500, and 3x500 right rear cover .....	430
Reinstall the HCI right rear cover .....	432

Intermediate paper transport unit (IPTU) .....	433
Location of major components .....	434
IPTU assembly .....	437
IPTU rear cover .....	439
Reinstall the IPTU rear cover .....	440
IPTU driver PCA .....	442
Remove the IPTU driver PCA .....	442
IPTU finisher lock assembly .....	443
Remove the IPTU finisher lock assembly .....	443
IPTU fan assembly .....	446
Remove the IPTU fan assembly .....	446
IPTU side panel assembly .....	447
Remove the IPTU side panel assembly .....	447
Reinstall the IPTU side panel assembly .....	450
IPTU upper and lower guide assemblies .....	451
Remove the IPTU upper and lower guide assemblies .....	451
Install a replacement IPTU upper guide assembly .....	456
Finishing accessories .....	457
Identify the finishing accessories .....	458
Identifying finishing accessory covers and doors .....	460
Shared finishing accessory assemblies .....	464
Top cover lock assembly .....	466
Latch lower covers (front and rear) .....	468
Latch assembly .....	470
Remove the latch assembly .....	470
Open/closed stepped cover assembly .....	471
Upper stepped cover assembly .....	472
Lower stepped cover assembly .....	474
Remove the lower stepped cover assembly .....	474
Reinstall the lower stepped cover .....	477
Top door assembly .....	478
Front door .....	479
Remove the front door .....	479
Inner upper cover assembly .....	480
Inner upper cover assembly (remove) .....	481
Clutch assembly (front side) .....	482
Remove the clutch assembly (front side) .....	482
Sensor switch assembly .....	483
Remove the sensor switch assembly .....	483
Inner lower cover assembly .....	486
Inner lower cover assembly (remove) .....	488

Front foot cover assembly .....	490
Remove the front foot cover assembly .....	490
Bin cable guide cover .....	492
Reinstall the bin cable guide cover .....	495
Rear cover assembly .....	496
Remove the rear cover assembly .....	496
Main controller PCA assembly .....	498
Remove the main controller PCA assembly .....	498
Entrance upper guide assembly .....	513
Remove the entrance upper guide assembly .....	513
Rear foot cover assembly .....	516
Remove the rear foot cover assembly .....	516
Stack wall upper assembly and upper wall guide assembly .....	518
Remove the stack wall upper assembly and upper wall guide assembly .....	518
Upper cross member assembly .....	521
Remove the upper cross member assembly .....	521
Reinstall the upper cross member assembly .....	529
Paper feed drive assembly .....	533
Remove the paper feed drive assembly .....	533
Pressure roller assembly .....	535
Remove the pressure roller assembly .....	536
Stack upper bin and lower bin assemblies .....	540
Remove stack upper bin and lower bin assemblies .....	541
Reinstall the stack upper bin and lower bin assemblies .....	544
Height wall assembly .....	546
Remove the height wall center assembly .....	546
Reinstall the height wall assembly .....	547
Paper face sensor and flag assembly .....	548
Remove the paper face sensor and flag assembly .....	548
Staple subassembly .....	553
Remove the staple subassembly .....	553
Staple connecting cable assembly .....	556
Remove the staple connecting cable assembly .....	556
Staple assembly .....	558
Remove the staple assembly .....	558
Paper detect holder assembly .....	562
Remove the paper detect holder assembly .....	562
Reinstall the paper detect holder assembly .....	563
Operation tray assembly .....	564
Remove the operation tray assembly .....	565

Reinstall the operation tray assembly .....	571
Swing guide assembly .....	575
Remove the swing guide assembly .....	576
Reinstall the swing guide assembly .....	582
Return roller assembly .....	586
Remove the return roller assembly .....	587
Clutch assembly (rear side) .....	588
Remove the clutch assembly (rear side) .....	588
Stack ejection motor assembly .....	591
Remove the stack ejection motor assembly .....	591
Press motor assembly .....	595
Remove the press motor assembly .....	595
Common driver PCA assembly .....	599
Remove the common controller PCA assembly .....	599
Interface cable assembly .....	601
Remove the interface cable assembly .....	601
Paper pass assembly .....	603
Remove the paper pass assembly .....	603
Booklet maker accessory .....	607
Knob .....	608
Saddle output bin assembly .....	609
Reinstall the saddle output bin .....	610
Right cover assembly (BM PCA) .....	611
Remove the right cover assembly (BM PCA) .....	611
Booklet maker controller PCA .....	615
Remove the booklet maker controller PCA .....	615
Inner side plate assembly .....	616
Remove the inner side plate assembly .....	616
Before reinstalling the inner side plate assembly .....	620
Guide sensor assembly .....	623
Remove the guide sensor assembly .....	623
Guide motor assembly .....	625
Remove the guide motor assembly .....	625
Saddle motor assembly (SS and BM) .....	627
Remove the saddle motor assembly (SS and BM) .....	627
Saddle feed motor assembly .....	629
Remove the saddle feed assembly .....	629
Folding-motor mount assembly .....	633
Remove the folding-motor mount assembly .....	633
Reinstall the folding-motor mount assembly .....	637
Delivery switch mount assembly .....	638

Remove the delivery switch mount assembly .....	638
Saddle stapler assembly .....	641
Remove the saddle stapler assembly .....	641
Lower left guide assembly .....	643
Remove the lower left guide assembly .....	643
Saddle delivery inner cover, front assembly .....	645
Remove the saddle delivery inner cover, front assembly .....	645
Saddle delivery inner cover, rear assembly .....	647
Remove the saddle delivery inner cover, rear assembly .....	647
Saddle guide assembly .....	649
Remove the saddle guide assembly .....	650
Reinstall the saddle guide assembly .....	653
Saddle feed assembly .....	655
Remove the saddle feed assembly .....	656
Reinstall the saddle feed assembly .....	659
Saddle assembly .....	660
Remove the saddle assembly .....	661
Reinstall the saddle assembly .....	668
Upper delivery guide assembly .....	669
Remove the upper delivery guide assembly .....	669
Saddle paper delivery assembly .....	671
Remove the saddle paper delivery assembly .....	671
Reinstall the saddle paper delivery assembly .....	673
Saddle rear end sensor assembly .....	674
Remove the saddle rear end sensor assembly .....	675
Reinstall the saddle rear end sensor .....	681
Booklet maker and stapler/stacker with hole punch accessories .....	682
Remove the punch front cover .....	682
Punch lower front cover assembly .....	684
Remove the punch lower front cover assembly .....	684
Punch rear cover assembly .....	686
Remove the punch rear cover assembly .....	686
Punch controller PCA assembly .....	687
Remove the punch controller PCA assembly .....	687
Reinstall the punch controller PCA assembly .....	687
Punch waste tray .....	688
Punch inner cover assembly .....	689
Remove the punch inner cover assembly .....	689
Punch top cover .....	691
Remove the punch top .....	691
Punch hole assembly .....	694

Remove the punch hole assembly .....	694
Reinstall the punch hole assembly .....	699
Replace the punch hole assembly or the punch controller PCA assembly .....	702
Set the punch hole assembly type .....	702
Set the sensor adjustment values .....	704
<b>2 Parts and diagrams .....</b>	<b>707</b>
Order parts by authorized service providers .....	708
Order parts, accessories, and supplies .....	708
Related documentation and software .....	708
Supplies part numbers .....	708
Customer self-repair parts .....	709
Service replacement parts .....	711
Accessories .....	712
How to use the parts lists and diagrams .....	714
Assembly locations .....	715
Base product (no optional trays or accessories) .....	715
Stapler/stacker and booklet maker .....	720
Stapler/stacker external assembly locator .....	722
Booklet maker .....	728
Intermediate paper transportation unit (IPTU) .....	734
1x500-sheet feeder .....	738
3x500-sheet feeder .....	740
High-capacity input (HCI) feeder .....	742
Document feeder and scanner assemblies (M880) .....	748
Document feeder assemblies (M880) .....	750
Scanner assemblies (M880) .....	754
Covers .....	756
Right door assembly .....	760
Internal components .....	762
Internal components (1 of 6) .....	762
Internal components (2 of 6) .....	764
Internal components (3 of 6) .....	766
Internal components (4 of 6) .....	768
Internal components (5 of 6) .....	770
Internal components (6 of 6) .....	772
Intermediate paper transfer unit (IPTU) assemblies .....	774
1x500-sheet feeder with stand (M855 only) covers .....	776
1x500-sheet feeder with stand (M855 only) covers .....	776
1x500-sheet feeder with stand components .....	778
3x500-sheet feeder .....	780

3x500-sheet feeder covers .....	780
3x500-sheet feeder components .....	782
High-capacity input (HCI) feeder .....	784
Stapler stacker/booklet maker .....	790
Stapler/stacker covers .....	790
Booklet maker covers .....	792
Finisher main body (1 of 3) .....	794
Finisher main body (2 of 3) .....	796
Finisher main body (3 of 3) .....	798
Stapler/stacker main body .....	800
Booklet maker main body .....	802
Booklet maker saddle assembly .....	804
Alphabetical parts list .....	808
Numerical parts list .....	825
<b>Index .....</b>	<b>843</b>



---

# List of tables

Table 1-1	Supported paper sizes for the input trays and duplexer .....	5
Table 1-2	Supported paper types .....	8
Table 1-3	Supported paper sizes for the finishing accessories .....	9
Table 1-4	Supported paper types for the finishing accessories .....	12
Table 1-5	M855 base product covers and doors (1 of 2) .....	84
Table 1-6	M855 base product covers and doors (2 of 2) .....	85
Table 1-7	M880 base product covers and doors (1 of 2) .....	86
Table 1-8	M880 base product covers and doors (2 of 2) .....	87
Table 1-9	Base product main assemblies (1 of 2) .....	152
Table 1-10	Base product main assemblies (2 of 2) .....	153
Table 1-11	External covers and doors .....	357
Table 1-12	Main assemblies (1 of 2) .....	358
Table 1-13	Main assemblies (2 of 2) .....	359
Table 1-14	Printed circuit assembly (PCA) .....	359
Table 1-15	External covers and doors (1x500-sheet feeder) .....	383
Table 1-16	External covers and doors (3x500-sheet feeder) .....	384
Table 1-17	Main assemblies (1x500-sheet feeder) .....	385
Table 1-18	Main assemblies (3x500-sheet feeder) .....	385
Table 1-19	Printed circuit assembly (PCA) .....	386
Table 1-20	IPTU covers (1 of 2) .....	434
Table 1-21	IPTU covers (2 of 2) .....	435
Table 1-22	IPTU main assemblies .....	435
Table 1-23	IPTU PCA .....	436
Table 1-24	Stapler stacker covers and doors .....	460
Table 1-25	Stapler stacker with hole punch covers and doors .....	461
Table 1-26	Booklet maker covers and doors .....	462
Table 1-27	Booklet maker with hole punch covers and doors .....	463
Table 1-28	DIPSW settings .....	509
Table 1-29	Do not change these DIPSW settings .....	510
Table 1-30	LED601 and LED602 blinking patterns .....	703
Table 1-31	LED601 and LED602 blinking patterns .....	705
Table 2-1	Order parts, accessories, and supplies .....	708

Table 2-2	Related documentation and software .....	708
Table 2-3	Supplies part numbers .....	708
Table 2-4	Customer self-repair parts .....	709
Table 2-5	Service replacement parts .....	711
Table 2-6	M855 base product assembly locations (1 of 2) .....	715
Table 2-7	M855 base product assembly locations (2 of 2) .....	716
Table 2-8	M880 base product assembly locations (1 of 2) .....	718
Table 2-9	M880 base product assembly locations (2 of 2) .....	719
Table 2-10	Stapler/stacker and booklet maker main assemblies .....	720
Table 2-11	Stapler/stacker and booklet maker PCA .....	721
Table 2-12	Stapler/stacker external assembly locator .....	722
Table 2-13	Stapler/stacker with hole puncher external assembly locator .....	723
Table 2-14	Staple stacker internal assembly locator .....	724
Table 2-15	Staple stacker with hole puncher internal assembly locator .....	725
Table 2-16	Staple stacker external assembly locator (door open) .....	726
Table 2-17	Staple stacker with hole puncher external assembly locator (door open) .....	727
Table 2-18	Booklet maker external assembly locator .....	728
Table 2-19	Booklet maker with hole puncher external assembly locator .....	729
Table 2-20	Booklet maker internal assembly locator .....	730
Table 2-21	Booklet maker with hole puncher internal assembly locator .....	731
Table 2-22	Booklet maker external assembly locator (door open) .....	732
Table 2-23	Booklet maker with hole puncher external assembly locator (door open) .....	733
Table 2-24	IPTU external assembly locator (1 of 3) .....	734
Table 2-25	IPTU external assembly locator (2 of 3) .....	734
Table 2-26	IPTU external assembly locator (3 of 3) .....	735
Table 2-27	IPTU internal assembly locator (1 of 2) .....	736
Table 2-28	IPTU internal assembly locator (2 of 2) .....	736
Table 2-29	IPTU PCA .....	737
Table 2-30	1x500-sheet feeder (1 of 2) .....	738
Table 2-31	1x500-sheet feeder (2 of 2) .....	739
Table 2-32	3x500-sheet feeder (1 of 2) .....	740
Table 2-33	3x500-sheet feeder (2 of 2) .....	741
Table 2-34	HCI feeder (1 of 6) .....	742
Table 2-35	HCI feeder (2 of 6) .....	743
Table 2-36	HCI feeder (3 of 6) .....	744
Table 2-37	HCI feeder (4 of 6) .....	745
Table 2-38	HCI feeder (5 of 6) .....	746
Table 2-39	HCI feeder (6 of 6) .....	746
Table 2-40	Document feeder and scanner assemblies (M880) .....	749
Table 2-41	Document feeder assemblies (M880, 1 of 2) .....	751
Table 2-42	Document feeder assemblies (M880, 2 of 2) .....	753

Table 2-43	Scanner assemblies (M880) .....	755
Table 2-44	Covers (M855) .....	757
Table 2-45	Covers (M880) .....	759
Table 2-46	Right door assembly .....	761
Table 2-47	Internal components (1 of 6) .....	763
Table 2-48	Internal components (2 of 6) .....	765
Table 2-49	Internal components (3 of 6) .....	767
Table 2-50	Internal components (4 of 6) .....	769
Table 2-51	Internal components (5 of 6) .....	771
Table 2-52	Internal components (6 of 6) .....	773
Table 2-53	Intermediate paper transfer unit (IPTU) assemblies .....	775
Table 2-54	1x500-sheet feeder with stand (M855 only) covers .....	777
Table 2-55	1x500-sheet feeder with stand components .....	779
Table 2-56	3x500-sheet feeder covers .....	781
Table 2-57	3x500-sheet feeder components .....	783
Table 2-58	HCI feeder covers .....	785
Table 2-59	HCI feeder internal components (1 of 2) .....	787
Table 2-60	HCI feeder internal components (2 of 2) .....	789
Table 2-61	Stapler/stacker covers .....	791
Table 2-62	Booklet maker covers .....	793
Table 2-63	Finisher main body (1 of 3) .....	795
Table 2-64	Finisher main body (2 of 3) .....	797
Table 2-65	Finisher main body (3 of 3) .....	799
Table 2-66	Stapler/stacker main body .....	801
Table 2-67	Booklet maker main body .....	803
Table 2-68	Booklet maker saddle assembly .....	807
Table 2-69	Alphabetical parts list .....	808
Table 2-70	Numerical parts list .....	825



---

# List of figures

Figure 1-1	Screwdrivers .....	3
Figure 1-2	Remove the toner cartridge .....	14
Figure 1-3	Remove the image drum .....	15
Figure 1-4	Remove the secondary transfer roller (1 of 2) .....	16
Figure 1-5	Remove the secondary transfer roller (2 of 2) .....	16
Figure 1-6	Reinstall the secondary transfer roller .....	17
Figure 1-7	Remove Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 .....	18
Figure 1-8	Remove the ITB (1 of 4) .....	19
Figure 1-9	Remove the ITB (2 of 4) .....	19
Figure 1-10	Remove the ITB (3 of 4) .....	20
Figure 1-11	Remove the ITB (4 of 4) .....	20
Figure 1-12	Remove the fuser (1 of 3) .....	21
Figure 1-13	Remove the fuser (2 of 3) .....	21
Figure 1-14	Remove the fuser (3 of 3) .....	21
Figure 1-15	Remove the switch back tray .....	22
Figure 1-16	Remove the formatter (1 of 2) .....	23
Figure 1-17	Remove the formatter (2 of 2) .....	23
Figure 1-18	Remove the HDD (1 of 2) .....	26
Figure 1-19	Remove the HDD (2 of 2) .....	26
Figure 1-20	Remove the SSM (1 of 2) .....	28
Figure 1-21	Remove the SSM (2 of 2) .....	28
Figure 1-22	Remove the memory DIMM (1 of 2) .....	32
Figure 1-23	Remove the memory DIMM (2 of 2) .....	32
Figure 1-24	Reinstall the memory DIMM .....	33
Figure 1-25	Reinstall the memory DIMM .....	33
Figure 1-26	Reinstall the memory DIMM .....	34
Figure 1-27	Remove the fax PCA (M880; 1 of 2) .....	35
Figure 1-28	Remove the fax PCA (M880; 2 of 2) .....	35
Figure 1-29	Remove the document feeder mylar strip (M880; 1 of 4) .....	36
Figure 1-30	Remove the document feeder mylar strip (M880; 2 of 4) .....	36
Figure 1-31	Remove the document feeder mylar strip (M880; 3 of 4) .....	37
Figure 1-32	Remove the document feeder mylar strip (M880; 4 of 4) .....	37

Figure 1-33	Install a replacement document feeder mylar strip (M880; 1 of 2)	38
Figure 1-34	Install a replacement document feeder mylar strip (M880; 2 of 2)	38
Figure 1-35	Remove the document feeder white backing (M880; 1 of 3)	39
Figure 1-36	Remove the document feeder white backing (M880; 2 of 3)	39
Figure 1-37	Remove the document feeder white backing (M880; 3 of 3)	40
Figure 1-38	Install a replacement document feeder white backing (M880; 1 of 6)	40
Figure 1-39	Install a replacement document feeder white backing (M880; 2 of 6)	41
Figure 1-40	Install a replacement document feeder white backing (M880; 3 of 6)	41
Figure 1-41	Install a replacement document feeder white backing (M880; 4 of 6)	42
Figure 1-42	Install a replacement document feeder white backing (M880; 5 of 6)	42
Figure 1-43	Install a replacement document feeder white backing (M880; 6 of 6)	43
Figure 1-44	Remove the background selector (M880; 1 of 4)	44
Figure 1-45	Remove the background selector (M880; 2 of 4)	44
Figure 1-46	Remove the background selector (M880; 3 of 4)	45
Figure 1-47	Remove the background selector (M880; 4 of 4)	45
Figure 1-48	Reinstall the background selector (M880)	46
Figure 1-49	Remove the control panel assembly (M855; 1 of 10)	47
Figure 1-50	Remove the control panel assembly (M855; 2 of 10)	47
Figure 1-51	Remove the control panel assembly (M855; 3 of 10)	48
Figure 1-52	Remove the control panel assembly (M855; 4 of 10)	48
Figure 1-53	Remove the control panel assembly (M855; 5 of 10)	49
Figure 1-54	Remove the control panel assembly (M855; 6 of 10)	49
Figure 1-55	Remove the control panel assembly (M855; 7 of 10)	50
Figure 1-56	Remove the control panel assembly (M855; 8 of 10)	50
Figure 1-57	Remove the control panel assembly (M855; 9 of 10)	51
Figure 1-58	Remove the control panel assembly (M855; 10 of 10)	51
Figure 1-59	Reinstall the control panel (M855)	52
Figure 1-60	Remove the control panel assembly (M880; 1 of 8)	53
Figure 1-61	Remove the control panel assembly (M880; 2 of 8)	53
Figure 1-62	Remove the control panel assembly (M880; 3 of 8)	54
Figure 1-63	Remove the control panel assembly (M880; 4 of 8)	54
Figure 1-64	Remove the control panel assembly (M880; 5 of 8)	55
Figure 1-65	Remove the control panel assembly (M880; 6 of 8)	55
Figure 1-66	Remove the control panel assembly (M880; 7 of 8)	56
Figure 1-67	Remove the control panel assembly (M880; 8 of 8)	56
Figure 1-68	Reinstall the control panel assembly (M880; 1 of 3)	57
Figure 1-69	Reinstall the control panel assembly (M880; 2 of 3)	57
Figure 1-70	Reinstall the control panel assembly (M880; 3 of 3)	58
Figure 1-71	Remove the keyboard assembly (M880; 1 of 7)	59
Figure 1-72	Remove the keyboard assembly (M880; 2 of 7)	60
Figure 1-73	Remove the keyboard assembly (M880; 3 of 7)	60

Figure 1-74	Remove the keyboard assembly (M880; 4 of 7)	61
Figure 1-75	Remove the keyboard assembly (M880; 5 of 7)	61
Figure 1-76	Remove the keyboard assembly (M880; 6 of 7)	62
Figure 1-77	Remove the keyboard assembly (M880; 7 of 7)	62
Figure 1-78	Reinstall the keyboard assembly (M880; 1 of 7)	63
Figure 1-79	Reinstall the keyboard assembly (M880; 2 of 7)	63
Figure 1-80	Reinstall the keyboard assembly (M880; 3 of 7)	64
Figure 1-81	Reinstall the keyboard assembly (M880; 4 of 7)	64
Figure 1-82	Reinstall the keyboard assembly (M880; 5 of 7)	65
Figure 1-83	Reinstall the keyboard assembly (M880; 6 of 7)	65
Figure 1-84	Reinstall the keyboard assembly (M880; 7 of 7)	66
Figure 1-85	Remove the document-feeder roller (M880; 1 of 3)	68
Figure 1-86	Remove the document-feeder roller (M880; 2 of 3)	68
Figure 1-87	Remove the document-feeder roller (M880; 3 of 3)	69
Figure 1-88	Reinstall the document-feeder roller (M880)	69
Figure 1-89	Remove the document-feeder separation pad (M880; 1 of 4)	70
Figure 1-90	Remove the document-feeder separation pad (M880; 2 of 4)	70
Figure 1-91	Remove the document-feeder separation pad (M880; 3 of 4)	71
Figure 1-92	Remove the document-feeder separation pad (M880; 4 of 4)	71
Figure 1-93	Reinstall the document-feeder separation pad (M880; 1 of 5)	72
Figure 1-94	Reinstall the document-feeder separation pad (M880; 2 of 5)	72
Figure 1-95	Reinstall the document-feeder separation pad (M880; 3 of 5)	73
Figure 1-96	Reinstall the document-feeder separation pad (M880; 4 of 5)	73
Figure 1-97	Reinstall the document-feeder separation pad (M880; 5 of 5)	74
Figure 1-98	Remove the Tray 1 rollers (1 of 5)	75
Figure 1-99	Remove the Tray 1 rollers (2 of 5)	75
Figure 1-100	Remove the Tray 1 rollers (3 of 5)	76
Figure 1-101	Remove the Tray 1 rollers (4 of 5)	76
Figure 1-102	Remove the Tray 1 rollers (5 of 5)	76
Figure 1-103	Reinstall the Tray 1 rollers	77
Figure 1-104	Remove the Tray 2, 1x500, and 3x500 rollers (1 of 2)	78
Figure 1-105	Remove the Tray 2, 1x500, and 3x500 rollers (2 of 2)	79
Figure 1-106	Reinstall the Tray 2, 1x500, and 3x500 rollers	79
Figure 1-107	Remove the HCI rollers (1 of 2)	80
Figure 1-108	Remove the HCI rollers (2 of 2)	81
Figure 1-109	Reinstall the HCI rollers	81
Figure 1-110	M855 base product covers and doors (1 of 2)	84
Figure 1-111	M855 base product covers and doors (2 of 2)	85
Figure 1-112	M880 base product covers and doors (1 of 2)	86
Figure 1-113	M880 base product covers and doors (2 of 2)	87
Figure 1-114	Remove the scanner back cover (M880; 1 of 2)	88

Figure 1-115	Remove the scanner back cover (M880; 2 of 2)	88
Figure 1-116	Remove the scanner left cover (M880; 1 of 2)	89
Figure 1-117	Remove the scanner left cover (M880; 2 of 2)	89
Figure 1-118	Remove the scanner right cover (M880; 1 of 2)	90
Figure 1-119	Remove the scanner right cover (M880; 2 of 2)	90
Figure 1-120	Remove the scanner front cover (M880; 1 of 8)	91
Figure 1-121	Remove the scanner front cover (M880; 2 of 8)	92
Figure 1-122	Remove the scanner front cover (M880; 3 of 8)	92
Figure 1-123	Remove the scanner front cover (M880; 4 of 8)	93
Figure 1-124	Remove the scanner front cover (M880; 5 of 8)	93
Figure 1-125	Remove the scanner front cover (M880; 6 of 8)	94
Figure 1-126	Remove the scanner front cover (M880; 7 of 8)	94
Figure 1-127	Remove the scanner front cover (M880; 8 of 8)	95
Figure 1-128	Remove the right upper rear cover (M855)	96
Figure 1-129	Remove the hardware integration pocket (HIP) cover (M855)	97
Figure 1-130	Remove the HIP cover (M880; 1 of 3)	98
Figure 1-131	Remove the HIP cover (M880; 2 of 3)	98
Figure 1-132	Remove the HIP cover (M880; 3 of 3)	99
Figure 1-133	Reinstall the HIP cover (M880; 1 of 2)	100
Figure 1-134	Reinstall the HIP cover (M880; 2 of 2)	100
Figure 1-135	Remove the face-down bin (1 of 2)	101
Figure 1-136	Remove the face-down bin (2 of 2)	101
Figure 1-137	Reinstall the face-down bin (1 of 2)	102
Figure 1-138	Remove the face-down bin (2 of 2)	102
Figure 1-139	Correct installation of face-down bin.	103
Figure 1-140	Incorrect installation of face-down bin.	103
Figure 1-141	Remove the left rear cover (1 of 2)	104
Figure 1-142	Remove the left rear cover (2 of 2)	104
Figure 1-143	Remove the switch back cover (1 of 2)	105
Figure 1-144	Remove the switch back cover (2 of 2)	105
Figure 1-145	Remove the lower right cover (1 of 2)	106
Figure 1-146	Remove the lower right cover (2 of 2)	106
Figure 1-147	Remove the rear upper rear cover (M880; 1 of 2)	107
Figure 1-148	Remove the rear upper rear cover (M880; 2 of 2)	107
Figure 1-149	Remove the right upper rear cover (M880; 1 of 2)	108
Figure 1-150	Remove the right upper rear cover (M880; 2 of 2)	108
Figure 1-151	Remove the rear upper MFP cover (M880; 1 of 2)	109
Figure 1-152	Remove the rear upper MFP cover (M880; 2 of 2)	109
Figure 1-153	Reinstall the rear upper MFP cover (M880)	110
Figure 1-154	Remove the left upper rear cover and rear upper B cover (M880; 1 of 3)	111
Figure 1-155	Remove the left upper rear cover and rear upper B cover (M880; 2 of 3)	112

Figure 1-156	Remove the left upper rear cover and rear upper B cover (M880; 3 of 3)	112
Figure 1-157	Remove the rear upper front cover (M880; 1 of 2)	113
Figure 1-158	Remove the rear upper front cover (M880; 2 of 2)	114
Figure 1-159	Remove the front top cover (1 of 2)	115
Figure 1-160	Remove the front top cover (2 of 2)	115
Figure 1-161	Remove the rear top cover (M855; 1 of 3)	116
Figure 1-162	Remove the rear top cover (M855; 2 of 3)	117
Figure 1-163	Remove the rear top cover (M855; 3 of 3)	117
Figure 1-164	Remove the left cover (1 of 2)	118
Figure 1-165	Remove the left cover (2 of 2)	119
Figure 1-166	Remove the right upper front cover (M855; 1 of 2)	120
Figure 1-167	Remove the right upper front cover (M855; 2 of 2)	121
Figure 1-168	Remove the right upper front cover (M880; 1 of 2)	122
Figure 1-169	Remove the right upper front cover (M880; 2 of 2)	123
Figure 1-170	Remove the right upper cover (M855; 1 of 9)	124
Figure 1-171	Remove the right upper cover (M855; 2 of 9)	125
Figure 1-172	Remove the right upper cover (M855; 3 of 9)	125
Figure 1-173	Remove the right upper cover (M855; 4 of 9)	126
Figure 1-174	Remove the right upper cover (M855; 5 of 9)	126
Figure 1-175	Remove the right upper cover (M855; 6 of 9)	127
Figure 1-176	Remove the right upper cover (M855; 7 of 9)	127
Figure 1-177	Remove the right upper cover (M855; 8 of 9)	128
Figure 1-178	Remove the right upper cover (M855; 9 of 9)	128
Figure 1-179	Remove the right door assembly (1 of 7)	129
Figure 1-180	Remove the right door assembly (2 of 7)	129
Figure 1-181	Remove the right door assembly (3 of 7)	130
Figure 1-182	Remove the right door assembly (4 of 7)	130
Figure 1-183	Remove the right door assembly (5 of 7)	131
Figure 1-184	Remove the right door assembly (6 of 7)	131
Figure 1-185	Remove the right door assembly (7 of 7)	132
Figure 1-186	Reinstall the right door assembly	132
Figure 1-187	Remove the left front cover (1 of 5)	133
Figure 1-188	Remove the left front cover (2 of 5)	134
Figure 1-189	Remove the left front cover (3 of 5)	134
Figure 1-190	Remove the left front cover (4 of 5)	135
Figure 1-191	Remove the left front cover (5 of 5)	135
Figure 1-192	Install a replacement left front cover	136
Figure 1-193	Remove the front door (1 of 9)	137
Figure 1-194	Remove the front door (2 of 9)	137
Figure 1-195	Remove the front door (3 of 9)	138
Figure 1-196	Remove the front door (4 of 9)	138

Figure 1-197	Remove the front door (5 of 9)	139
Figure 1-198	Remove the front door (6 of 9)	139
Figure 1-199	Remove the front door (7 of 9)	140
Figure 1-200	Remove the front door (8 of 9)	140
Figure 1-201	Remove the front door (9 of 9)	141
Figure 1-202	Reinstall the front door (1 of 2)	141
Figure 1-203	Reinstall the front door (2 of 2)	142
Figure 1-204	Remove the rear cover (1 of 3)	143
Figure 1-205	Remove the rear cover (2 of 3)	143
Figure 1-206	Remove the rear cover (3 of 3)	144
Figure 1-207	Install a replacement rear cover (1 of 2)	144
Figure 1-208	Install a replacement rear cover (2 of 2)	145
Figure 1-209	Remove the right rear cover (1 of 2)	146
Figure 1-210	Remove the right rear cover (2 of 2)	146
Figure 1-211	Remove the front inner cover (1 of 2)	147
Figure 1-212	Remove the front inner cover (2 of 2)	148
Figure 1-213	Reinstall the front inner cover	148
Figure 1-214	Base product main assemblies (1 of 2)	152
Figure 1-215	Base product main assemblies (2 of 2)	153
Figure 1-216	Remove the document feeder assembly (M880; 1 of 9)	154
Figure 1-217	Remove the document feeder assembly (M880; 2 of 9)	155
Figure 1-218	Remove the document feeder assembly (M880; 3 of 9)	155
Figure 1-219	Remove the document feeder assembly (M880; 4 of 9)	156
Figure 1-220	Remove the document feeder assembly (M880; 5 of 9)	156
Figure 1-221	Remove the document feeder assembly (M880; 6 of 9)	157
Figure 1-222	Remove the document feeder assembly (M880; 7 of 9)	157
Figure 1-223	Remove the document feeder assembly (M880; 8 of 9)	158
Figure 1-224	Remove the document feeder assembly (M880; 9 of 9)	158
Figure 1-225	Remove the SCB (M880; 1 of 4)	160
Figure 1-226	Remove the SCB (M880; 2 of 4)	160
Figure 1-227	Remove the SCB (M880; 3 of 4)	161
Figure 1-228	Remove the SCB (M880; 4 of 4)	161
Figure 1-229	Remove the scanner assembly (M880; 1 of 7)	162
Figure 1-230	Remove the scanner assembly (M880; 2 of 7)	163
Figure 1-231	Remove the scanner assembly (M880; 3 of 7)	163
Figure 1-232	Remove the scanner assembly (M880; 4 of 7)	164
Figure 1-233	Remove the scanner assembly (M880; 5 of 7)	164
Figure 1-234	Remove the scanner assembly (M880; 6 of 7)	165
Figure 1-235	Remove the scanner assembly (M880; 7 of 7)	165
Figure 1-236	Remove the interlock switch assembly (1 of 2)	167
Figure 1-237	Remove the interlock switch assembly (2 of 2)	168

Figure 1-238	Remove the front-door open detection switch (1 of 4)	169
Figure 1-239	Remove the front-door open detection switch (2 of 4)	170
Figure 1-240	Remove the front-door open detection switch (3 of 4)	170
Figure 1-241	Remove the front-door open detection switch (4 of 4)	171
Figure 1-242	Reinstall the front-door-open detection switch (1 of 3)	171
Figure 1-243	Reinstall the front-door-open detection switch (2 of 3)	172
Figure 1-244	Reinstall the front-door-open detection switch (3 of 3)	172
Figure 1-245	Remove the main switch assembly (1 of 3)	173
Figure 1-246	Remove the main switch assembly (2 of 3)	174
Figure 1-247	Remove the main switch assembly (3 of 3)	174
Figure 1-248	Remove the secondary transfer assembly (1 of 10)	175
Figure 1-249	Remove the secondary transfer assembly (2 of 10)	176
Figure 1-250	Remove the secondary transfer assembly (3 of 10)	176
Figure 1-251	Remove the secondary transfer assembly (4 of 10)	177
Figure 1-252	Remove the secondary transfer assembly (5 of 10)	177
Figure 1-253	Remove the secondary transfer assembly (6 of 10)	178
Figure 1-254	Remove the secondary transfer assembly (7 of 10)	178
Figure 1-255	Remove the secondary transfer assembly (8 of 10)	179
Figure 1-256	Remove the secondary transfer assembly (9 of 10)	180
Figure 1-257	Remove the secondary transfer assembly (10 of 10)	180
Figure 1-258	Reinstall the secondary transfer assembly (1 of 3)	181
Figure 1-259	Reinstall the secondary transfer assembly (2 of 3)	181
Figure 1-260	Reinstall the secondary transfer assembly (3 of 3)	182
Figure 1-261	Remove the multipurpose tray (Tray 1) drive assembly (1 of 13)	183
Figure 1-262	Remove the multipurpose tray (Tray 1) drive assembly (2 of 13)	184
Figure 1-263	Remove the multipurpose tray (Tray 1) drive assembly (3 of 13)	184
Figure 1-264	Remove the multipurpose tray (Tray 1) drive assembly (4 of 13)	185
Figure 1-265	Remove the multipurpose tray (Tray 1) drive assembly (5 of 13)	185
Figure 1-266	Remove the multipurpose tray (Tray 1) drive assembly (6 of 13)	186
Figure 1-267	Remove the multipurpose tray (Tray 1) drive assembly (7 of 13)	186
Figure 1-268	Remove the multipurpose tray (Tray 1) drive assembly (8 of 13)	187
Figure 1-269	Remove the multipurpose tray (Tray 1) drive assembly (9 of 13)	187
Figure 1-270	Remove the multipurpose tray (Tray 1) drive assembly (10 of 13)	188
Figure 1-271	Remove the multipurpose tray (Tray 1) drive assembly (11 of 13)	188
Figure 1-272	Remove the multipurpose tray (Tray 1) drive assembly (12 of 13)	189
Figure 1-273	Remove the multipurpose tray (Tray 1) drive assembly (13 of 13)	189
Figure 1-274	Remove the multipurpose tray guide assembly	190
Figure 1-275	Remove the Tray 2 pickup assembly	191
Figure 1-276	Remove the fuser home position sensor (1 of 3)	192
Figure 1-277	Remove the fuser home position sensor (2 of 3)	192
Figure 1-278	Remove the fuser home position sensor (3 of 3)	193

Figure 1-279	Reinstall the fuser home position sensor .....	193
Figure 1-280	Remove the shutter gear holder assembly (1 of 5) .....	194
Figure 1-281	Remove the shutter gear holder assembly (2 of 5) .....	194
Figure 1-282	Remove the shutter gear holder assembly (3 of 5) .....	195
Figure 1-283	Remove the shutter gear holder assembly (4 of 5) .....	195
Figure 1-284	Remove the shutter gear holder assembly (5 of 5) .....	196
Figure 1-285	Reinstall the shutter gear holder assembly (1 of 6) .....	196
Figure 1-286	Reinstall the shutter gear holder assembly (2 of 6) .....	197
Figure 1-287	Reinstall the shutter gear holder assembly (3 of 6) .....	197
Figure 1-288	Reinstall the shutter gear holder assembly (4 of 6) .....	198
Figure 1-289	Reinstall the shutter gear holder assembly (5 of 6) .....	198
Figure 1-290	Reinstall the shutter gear holder assembly (6 of 6) .....	199
Figure 1-291	Remove the fuser-edge area cooling fan FM10 (front; 1 of 3) .....	200
Figure 1-292	Remove the fuser-edge area cooling fan FM10 (front; 2 of 3) .....	200
Figure 1-293	Remove the fuser-edge area cooling fan FM10 (front; 3 of 3) .....	201
Figure 1-294	Reinstall the fuser-edge area cooling fan FM10 (front; 1 of 3) .....	202
Figure 1-295	Reinstall the fuser-edge area cooling fan FM10 (front; 2 of 3) .....	202
Figure 1-296	Reinstall the fuser-edge area cooling fan FM10 (front; 3 of 3) .....	203
Figure 1-297	Remove the fuser-edge area cooling fan FM9 (rear; 1 of 3) .....	204
Figure 1-298	Remove the Remove the fuser-edge area cooling fan FM9 (rear; 2 of 3) .....	204
Figure 1-299	Remove the fuser-edge area cooling fan FM9 (rear; 3 of 3) .....	205
Figure 1-300	Reinstall the fuser-edge area cooling fan FM9 (rear; 1 of 3) .....	205
Figure 1-301	Reinstall the fuser-edge area cooling fan FM9 (rear; 2 of 3) .....	206
Figure 1-302	Reinstall the fuser-edge area cooling fan FM9 (rear; 3 of 3) .....	206
Figure 1-303	Remove the fuser fan FM2 (1 of 5) .....	207
Figure 1-304	Remove the fuser fan FM2 (2 of 5) .....	207
Figure 1-305	Remove the fuser fan FM2 (3 of 5) .....	208
Figure 1-306	Remove the fuser fan FM2 (4 of 5) .....	208
Figure 1-307	Remove the fuser fan FM2 (5 of 5) .....	209
Figure 1-308	Reinstall the fuser fan FM2 (1 of 3) .....	209
Figure 1-309	Reinstall the fuser fan FM2 (2 of 3) .....	210
Figure 1-310	Reinstall the fuser fan FM2 (3 of 3) .....	210
Figure 1-311	Remove the fuser fan duct (1 of 3) .....	211
Figure 1-312	Remove the fuser fan duct (2 of 3) .....	212
Figure 1-313	Remove the fuser fan duct (3 of 3) .....	212
Figure 1-314	Reinstall the fuser fan duct .....	213
Figure 1-315	Remove the cartridge fan FM3 (yellow and magenta; 1 of 5) .....	214
Figure 1-316	Remove the cartridge fan FM3 (yellow and magenta; 2 of 5) .....	214
Figure 1-317	Remove the cartridge fan FM3 (yellow and magenta; 3 of 5) .....	215
Figure 1-318	Remove the cartridge fan FM3 (yellow and magenta; 4 of 5) .....	215
Figure 1-319	Remove the cartridge fan FM3 (yellow and magenta; 5 of 5) .....	216

Figure 1-320	Reinstall the cartridge fan FM3 (yellow and magenta; 1 of 3)	216
Figure 1-321	Reinstall the cartridge fan FM3 (yellow and magenta; 2 of 3)	217
Figure 1-322	Reinstall the cartridge fan FM3 (yellow and magenta; 3 of 3)	217
Figure 1-323	Remove the cartridge fan FM4 (cyan and black; 1 of 5)	218
Figure 1-324	Remove the cartridge fan FM4 (cyan and black; 2 of 5)	218
Figure 1-325	Remove the cartridge fan FM4 (cyan and black; 3 of 5)	219
Figure 1-326	Remove the cartridge fan FM4 (cyan and black; 4 of 5)	219
Figure 1-327	Remove the cartridge fan FM4 (cyan and black; 5 of 5)	220
Figure 1-328	Reinstall the cartridge fan FM4 (cyan and black; 1 of 2)	220
Figure 1-329	Reinstall the cartridge fan FM4 (cyan and black; 2 of 3)	221
Figure 1-330	Reinstall the cartridge fan FM4 (cyan and black; 3 of 3)	221
Figure 1-331	Remove the laser/scanner fan FM1 (1 of 4)	222
Figure 1-332	Remove the laser/scanner fan FM1 (2 of 4)	222
Figure 1-333	Remove the laser/scanner fan FM1 (3 of 4)	223
Figure 1-334	Remove the laser/scanner fan FM1 (4 of 4)	223
Figure 1-335	Reinstall the laser/scanner fan FM1 (1 of 3)	224
Figure 1-336	Reinstall the laser/scanner fan FM1 (2 of 3)	224
Figure 1-337	Reinstall the laser/scanner fan FM1 (3 of 3)	225
Figure 1-338	Remove the delivery fan FM8 (1 of 3)	226
Figure 1-339	Remove the delivery fan FM8 (2 of 3)	226
Figure 1-340	Remove the delivery fan FM8 (3 of 3)	227
Figure 1-341	Remove the cartridge front area cooling fan FM7 (1 of 2)	228
Figure 1-342	Remove the cartridge front area cooling fan FM7 (2 of 2)	229
Figure 1-343	Reinstall the cartridge front area cooling fan FM7	229
Figure 1-344	Remove the memory tag PCA (1 of 3)	230
Figure 1-345	Remove the memory tag PCA (2 of 3)	231
Figure 1-346	Remove the memory tag PCA (3 of 3)	231
Figure 1-347	Reinstall the memory tag PCA	232
Figure 1-348	Remove the image-drum motor (1 of 2)	233
Figure 1-349	Remove the image-drum motor (2 of 2)	234
Figure 1-350	Remove the fuser power supply (1 of 2)	235
Figure 1-351	Remove the fuser power supply (2 of 2)	236
Figure 1-352	Reinstall the fuser power supply (1 of 2)	236
Figure 1-353	Reinstall the fuser power supply (2 of 2)	237
Figure 1-354	Remove the primary transfer-roller disengagement motor (1 of 2)	238
Figure 1-355	Remove the primary transfer-roller disengagement motor (2 of 2)	239
Figure 1-356	Remove the ITB alienation drive assembly (1 of 2)	240
Figure 1-357	Remove the ITB alienation drive assembly (2 of 2)	241
Figure 1-358	Remove the fuser motor (1 of 2)	242
Figure 1-359	Remove the fuser motor (2 of 2)	242
Figure 1-360	Remove the ITB motor (1 of 2)	243

Figure 1-361	Remove the ITB motor (2 of 2)	243
Figure 1-362	Remove the toner-cartridge feed motor (black; 1 of 2)	244
Figure 1-363	Remove the toner-cartridge feed motor (black; 2 of 2)	244
Figure 1-364	Remove the toner-cartridge feed motor (yellow, magenta, and cyan; 1 of 2)	245
Figure 1-365	Remove the toner-cartridge feed motor (yellow, magenta, and cyan; 2 of 2)	246
Figure 1-366	Remove the environmental sensor	247
Figure 1-367	Remove the interconnect PCA (M855; 1 of 4)	248
Figure 1-368	Remove the interconnect PCA (M855; 2 of 4)	249
Figure 1-369	Remove the interconnect PCA (M855; 3 of 4)	249
Figure 1-370	Remove the interconnect PCA (M855; 4 of 4)	250
Figure 1-371	Reinstall the interconnect PCA (M855)	251
Figure 1-372	Remove the interconnect PCA (M880; 1 of 4)	252
Figure 1-373	Remove the interconnect PCA (M880; 2 of 4)	253
Figure 1-374	Remove the interconnect PCA (M880; 3 of 4)	253
Figure 1-375	Remove the interconnect PCA (M880; 4 of 4)	254
Figure 1-376	Reinstall the interconnect PCA (M880)	254
Figure 1-377	Remove the formatter case (1 of 2)	255
Figure 1-378	Remove the formatter case (2 of 2)	256
Figure 1-379	Reinstall the formatter case	256
Figure 1-380	Remove the formatter, formatter case, and ICB (1 of 4)	257
Figure 1-381	Remove the formatter, formatter case, and ICB (2 of 4)	258
Figure 1-382	Remove the formatter, formatter case, and ICB (3 of 4)	258
Figure 1-383	Remove the formatter, formatter case, and ICB (4 of 4)	259
Figure 1-384	Reinstall the formatter, formatter case, and ICB	259
Figure 1-385	Remove the HVPS B (1 of 2)	260
Figure 1-386	Remove the HVPS B (2 of 2)	261
Figure 1-387	Reinstall the HVPS B (1 of 2)	261
Figure 1-388	Reinstall the HVPS B (2 of 2)	262
Figure 1-389	Remove the DC controller PCA	263
Figure 1-390	Remove the CPR sensor assembly (1 of 5)	264
Figure 1-391	Remove the CPR sensor assembly (2 of 5)	265
Figure 1-392	Remove the CPR sensor assembly (3 of 5)	265
Figure 1-393	Remove the CPR sensor assembly (4 of 5)	266
Figure 1-394	Remove the CPR sensor assembly (5 of 5)	266
Figure 1-395	Reinstall the CPR sensor assembly (1 of 4)	267
Figure 1-396	Reinstall the CPR sensor assembly (2 of 4)	267
Figure 1-397	Reinstall the CPR sensor assembly (3 of 4)	268
Figure 1-398	Reinstall the CPR sensor assembly (4 of 4)	268
Figure 1-399	Remove the LVPS (1 of 5)	269
Figure 1-400	Remove the LVPS (2 of 5)	269
Figure 1-401	Remove the LVPS (3 of 5)	270

Figure 1-402	Remove the LVPS (4 of 5) .....	270
Figure 1-403	Remove the LVPS (5 of 5) .....	271
Figure 1-404	Remove the HVPS A (first transfer) (1 of 3) .....	272
Figure 1-405	Remove the HVPS A (first transfer) (2 of 3) .....	273
Figure 1-406	Remove the HVPS A (first transfer) (3 of 3) .....	273
Figure 1-407	Reinstall the HVPS A (first transfer) (1 of 3) .....	274
Figure 1-408	Reinstall the HVPS A (first transfer) (2 of 3) .....	274
Figure 1-409	Reinstall the HVPS A (first transfer) (3 of 3) .....	275
Figure 1-410	Remove the lifter-drive assembly (1 of 3) .....	276
Figure 1-411	Remove the lifter-drive assembly (2 of 3) .....	277
Figure 1-412	Remove the lifter-drive assembly (3 of 3) .....	277
Figure 1-413	Unlocked position of the lifter-driver assembly (correct) .....	278
Figure 1-414	Locked position of the lifter-driver assembly (incorrect) .....	278
Figure 1-415	Unlocking the lifter-drive assembly .....	279
Figure 1-416	Remove the toner-cartridge drive assembly (yellow and magenta) .....	280
Figure 1-417	Reinstall the toner-cartridge drive assembly (yellow and magenta) .....	281
Figure 1-418	Remove the toner-cartridge drive assembly (cyan and black) .....	283
Figure 1-419	Reinstall the toner-cartridge drive assembly (cyan and black) .....	283
Figure 1-420	Remove the cartridge interface PCA (cyan and black) .....	285
Figure 1-421	Remove the cartridge interface PCA (yellow and magenta) .....	287
Figure 1-422	Remove the main drive assembly (1 of 2) .....	289
Figure 1-423	Remove the main drive assembly (2 of 2) .....	289
Figure 1-424	Reinstall the main drive assembly .....	290
Figure 1-425	Replace the toner-cartridge drive assembly or the main drive assembly (1 of 8) .....	291
Figure 1-426	Replace the toner-cartridge drive assembly or the main drive assembly (2 of 8) .....	292
Figure 1-427	Replace the toner-cartridge drive assembly or the main drive assembly (3 of 8) .....	292
Figure 1-428	Replace the toner-cartridge drive assembly or the main drive assembly (4 of 8) .....	293
Figure 1-429	Replace the toner-cartridge drive assembly or the main drive assembly (5 of 8) .....	293
Figure 1-430	Correct position of toner-cartridge drive assembly (6 of 8) .....	294
Figure 1-431	Incorrect position of toner-cartridge drive assembly (7 of 8) .....	294
Figure 1-432	Replace the toner-cartridge drive assembly or the main drive assembly (8 of 8) .....	295
Figure 1-433	Reinstall the toner-cartridge drive assembly or the main drive assembly (1 of 4) .....	296
Figure 1-434	Reinstall the toner-cartridge drive assembly or the main drive assembly (2 of 4) .....	296
Figure 1-435	Correct position of toner-cartridge drive assembly (3 of 4) .....	297
Figure 1-436	Incorrect position of toner-cartridge drive assembly (4 of 4) .....	297
Figure 1-437	Remove the fuser drive assembly (1 of 10) .....	298
Figure 1-438	Remove the fuser drive assembly (2 of 10) .....	299
Figure 1-439	Remove the fuser drive assembly (3 of 10) .....	299
Figure 1-440	Remove the fuser drive assembly (4 of 10) .....	300
Figure 1-441	Remove the fuser drive assembly (5 of 10) .....	300
Figure 1-442	Remove the fuser drive assembly (6 of 10) .....	301

Figure 1-443	Remove the fuser drive assembly (7 of 10)	301
Figure 1-444	Remove the fuser drive assembly (8 of 10)	302
Figure 1-445	Remove the fuser drive assembly (9 of 10)	302
Figure 1-446	Remove the fuser drive assembly (10 of 10)	303
Figure 1-447	Reinstall the fuser drive assembly (1 of 4)	303
Figure 1-448	Reinstall the fuser drive assembly (2 of 4)	304
Figure 1-449	Reinstall the fuser drive assembly (3 of 4)	304
Figure 1-450	Reinstall the fuser drive assembly (4 of 4)	305
Figure 1-451	Remove the scanner cover	306
Figure 1-452	Remove the laser/scanner assembly (yellow and magenta; 1 of 6)	307
Figure 1-453	Remove the laser/scanner assembly (yellow and magenta; 2 of 6)	308
Figure 1-454	Remove the laser/scanner assembly (yellow and magenta; 3 of 6)	309
Figure 1-455	Remove the laser/scanner assembly (yellow and magenta; 4 of 6)	309
Figure 1-456	Remove the laser/scanner assembly (yellow and magenta; 5 of 6)	310
Figure 1-457	Remove the laser/scanner assembly (yellow and magenta; 6 of 6)	310
Figure 1-458	Reinstall the laser/scanner assembly (yellow and magenta; 1 of 2)	311
Figure 1-459	Reinstall the laser/scanner assembly (yellow and magenta; 2 of 2)	311
Figure 1-460	Remove the laser/scanner assembly (cyan and black; 1 of 8)	312
Figure 1-461	Remove the laser/scanner assembly (cyan and black; 2 of 8)	313
Figure 1-462	Remove the laser/scanner assembly (cyan and black; 3 of 8)	313
Figure 1-463	Remove the laser/scanner assembly (cyan and black; 4 of 8)	314
Figure 1-464	Remove the laser/scanner assembly (cyan and black; 5 of 8)	315
Figure 1-465	Remove the laser/scanner assembly (cyan and black; 6 of 8)	315
Figure 1-466	Remove the laser/scanner assembly (cyan and black; 7 of 8)	316
Figure 1-467	Remove the laser/scanner assembly (cyan and black; 8 of 8)	316
Figure 1-468	Reinstall the laser/scanner assembly (cyan and black; 1 of 3)	317
Figure 1-469	Reinstall the laser/scanner assembly (cyan and black; 2 of 3)	317
Figure 1-470	Reinstall the laser/scanner assembly (cyan and black; 3 of 3)	318
Figure 1-471	Remove the duplex reverse assembly (M855)	319
Figure 1-472	Remove the duplex reverse assembly (M880)	320
Figure 1-473	Remove the VOC fan (M855; 1 of 2)	321
Figure 1-474	Remove the VOC fan (M855; 2 of 2)	322
Figure 1-475	Remove the VOC fan (M880; 1 of 6)	324
Figure 1-476	Remove the VOC fan (M880; 2 of 6)	324
Figure 1-477	Remove the VOC fan (M880; 3 of 6)	325
Figure 1-478	Remove the VOC fan (M880; 4 of 6)	325
Figure 1-479	Remove the VOC fan (M880; 5 of 6)	326
Figure 1-480	Remove the VOC fan (M880; 6 of 6)	326
Figure 1-481	Remove the face-down delivery assembly (M855; 1 of 8)	327
Figure 1-482	Remove the face-down delivery assembly (M855; 2 of 8)	328
Figure 1-483	Remove the face-down delivery assembly (M855; 3 of 8)	328

Figure 1-484	Remove the face-down delivery assembly (M855; 4 of 8)	329
Figure 1-485	Remove the face-down delivery assembly (M855; 5 of 8)	329
Figure 1-486	Remove the face-down delivery assembly (M855; 6 of 8)	330
Figure 1-487	Remove the face-down delivery assembly (M855; 7 of 8)	330
Figure 1-488	Remove the face-down delivery assembly (M855; 8 of 8)	331
Figure 1-489	Remove the face-down delivery assembly (M880; 1 of 19)	333
Figure 1-490	Remove the face-down delivery assembly (M880; 2 of 19)	333
Figure 1-491	Remove the face-down delivery assembly (M880; 3 of 19)	334
Figure 1-492	Remove the face-down delivery assembly (M880; 4 of 19)	334
Figure 1-493	Remove the face-down delivery assembly (M880; 5 of 19)	335
Figure 1-494	Remove the face-down delivery assembly (M880; 6 of 19)	335
Figure 1-495	Remove the face-down delivery assembly (M880; 7 of 19)	336
Figure 1-496	Remove the face-down delivery assembly (M880; 8 of 19)	336
Figure 1-497	Remove the face-down delivery assembly (M880; 9 of 19)	337
Figure 1-498	Remove the face-down delivery assembly (M880; 10 of 19)	337
Figure 1-499	Remove the face-down delivery assembly (M880; 11 of 19)	338
Figure 1-500	Remove the face-down delivery assembly (M880; 12 of 19)	339
Figure 1-501	Remove the face-down delivery assembly (M880; 13 of 19)	339
Figure 1-502	Remove the face-down delivery assembly (M880; 14 of 19)	340
Figure 1-503	Remove the face-down delivery assembly (M880; 15 of 19)	340
Figure 1-504	Remove the face-down delivery assembly (M880; 16 of 19)	341
Figure 1-505	Remove the face-down delivery assembly (M880; 17 of 19)	341
Figure 1-506	Remove the face-down delivery assembly (M880; 18 of 19)	342
Figure 1-507	Remove the face-down delivery assembly (M880; 19 of 19)	342
Figure 1-508	Remove face-down cover	344
Figure 1-509	Remove the duplexing feed assembly (1 of 7)	345
Figure 1-510	Remove the duplexing feed assembly (2 of 7)	345
Figure 1-511	Remove the duplexing feed assembly (3 of 7)	346
Figure 1-512	Remove the duplexing feed assembly (4 of 7)	346
Figure 1-513	Remove the duplexing feed assembly (5 of 7)	347
Figure 1-514	Remove the duplexing feed assembly (6 of 7)	347
Figure 1-515	Remove the duplexing feed assembly (7 of 7)	348
Figure 1-516	Remove the multipurpose tray (Tray 1) pickup assembly (1 of 10)	350
Figure 1-517	Remove the multipurpose tray (Tray 1) pickup assembly (2 of 10)	350
Figure 1-518	Remove the multipurpose tray (Tray 1) pickup assembly (3 of 10)	351
Figure 1-519	Remove the multipurpose tray (Tray 1) pickup assembly (4 of 10)	351
Figure 1-520	Remove the multipurpose tray (Tray 1) pickup assembly (5 of 10)	352
Figure 1-521	Remove the multipurpose tray (Tray 1) pickup assembly (6 of 10)	352
Figure 1-522	Remove the multipurpose tray (Tray 1) pickup assembly (7 of 10)	353
Figure 1-523	Remove the multipurpose tray (Tray 1) pickup assembly (8 of 10)	353
Figure 1-524	Remove the multipurpose tray (Tray 1) pickup assembly (9 of 10)	354

Figure 1-525	Remove the multipurpose tray (Tray 1) pickup assembly (10 of 10)	354
Figure 1-526	Reinstall the multipurpose tray (Tray 1) pickup assembly	355
Figure 1-527	External covers and doors	357
Figure 1-528	Main assemblies (1 of 2)	358
Figure 1-529	Main assemblies (2 of 2)	359
Figure 1-530	Printed circuit assembly (PCA)	359
Figure 1-531	Remove the HCI right tray	360
Figure 1-532	Remove the HCI left tray	361
Figure 1-533	Remove the HCI rear cover	362
Figure 1-534	Remove the HCI right lower cover (1 of 2)	363
Figure 1-535	Remove the HCI right lower cover (2 of 2)	364
Figure 1-536	Remove the HCI right tray pickup motor	365
Figure 1-537	Remove the HCI right tray pickup drive (1 of 2)	366
Figure 1-538	Remove the HCI left tray pickup motor	367
Figure 1-539	Remove the HCI left tray pickup drive	368
Figure 1-540	Remove the HCI right tray lifter drive assembly	369
Figure 1-541	Remove the HCI left tray lifter drive assembly	370
Figure 1-542	Remove the HCI right tray media-level sensor assembly (1 of 2)	371
Figure 1-543	Remove the HCI right tray media-level sensor assembly (2 of 2)	371
Figure 1-544	Remove the HCI left tray media-level sensor assembly (1 of 2)	372
Figure 1-545	Remove the HCI left tray media-level sensor assembly (2 of 2)	372
Figure 1-546	Remove the HCI right tray automatic close assembly (1 of 2)	373
Figure 1-547	Remove the HCI right tray automatic close assembly (2 of 2)	373
Figure 1-548	Remove the HCI left tray automatic close assembly (1 of 2)	374
Figure 1-549	Remove the HCI left tray automatic close assembly (2 of 2)	374
Figure 1-550	Remove the HCI right tray pickup assembly (1 of 3)	375
Figure 1-551	Remove the HCI right tray pickup assembly (2 of 3)	375
Figure 1-552	Remove the HCI right tray pickup assembly (3 of 3)	376
Figure 1-553	Reinstall the HCI right tray pickup assembly	376
Figure 1-554	Remove the HCI left tray pickup assembly (1 of 2)	377
Figure 1-555	Remove the HCI left tray pickup assembly (2 of 2)	378
Figure 1-556	Reinstall the HCI left tray pickup assembly (1 of 2)	379
Figure 1-557	Reinstall the HCI left tray pickup assembly (2 of 2)	379
Figure 1-558	Remove the HCI merge assembly (1 of 2)	380
Figure 1-559	Remove the HCI merge assembly (2 of 2)	381
Figure 1-560	Reinstall the HCI merge assembly	381
Figure 1-561	Remove the HCI controller PCA	382
Figure 1-562	External covers and doors (1x500-sheet feeder)	383
Figure 1-563	External covers and doors (3x500-sheet feeder)	384
Figure 1-564	Main assemblies (1x500-sheet feeder)	385
Figure 1-565	Main assemblies (3x500-sheet feeder)	385

Figure 1-566	Printed circuit assembly (PCA) .....	386
Figure 1-567	Remove the 1x500 and 3x500 rear cover (1 of 2) .....	387
Figure 1-568	Remove the 1x500 and 3x500 rear cover (2 of 2) .....	387
Figure 1-569	Remove the 1x500 and 3x500 right front cover (1 of 2) .....	388
Figure 1-570	Remove the 1x500 and 3x500 right front cover (2 of 2) .....	389
Figure 1-571	Reinstall the 1x500 and 3x500 right front cover .....	389
Figure 1-572	Remove the 1x500 and 3x500 upper front face cover .....	390
Figure 1-573	Reinstall the 1x500 and 3x500 upper front face cover .....	391
Figure 1-574	Remove the 1x500 and 3x500 upper front cover (1 of 4) .....	392
Figure 1-575	Remove the 1x500 and 3x500 upper front cover (2 of 4) .....	393
Figure 1-576	Remove the 1x500 and 3x500 upper front cover (3 of 4) .....	393
Figure 1-577	Remove the 1x500 and 3x500 upper front cover (4 of 4) .....	394
Figure 1-578	Remove the 1x500 and 3x500 upper front left face cover .....	395
Figure 1-579	Remove the 1x500 storage box door (1 of 3) .....	396
Figure 1-580	Remove the 1x500 storage box door (2 of 3) .....	396
Figure 1-581	Remove the 1x500 storage box door (3 of 3) .....	397
Figure 1-582	Remove the 1x500 storage box (1 of 2) .....	398
Figure 1-583	Remove the 1x500 storage box (2 of 2) .....	399
Figure 1-584	Remove the 1x500 and 3x500 right lower cover (1 of 2) .....	400
Figure 1-585	Remove the 1x500 and 3x500 right lower cover (2 of 2) .....	401
Figure 1-586	Remove the 1x500 Tray 3 pickup assembly (1 of 5) .....	402
Figure 1-587	Remove the 1x500 Tray 3 pickup assembly (2 of 5) .....	402
Figure 1-588	Remove the 1x500 Tray 3 pickup assembly (3 of 5) .....	403
Figure 1-589	Remove the 1x500 Tray 3 pickup assembly (4 of 5) .....	403
Figure 1-590	Remove the 1x500 Tray 3 pickup assembly (5 of 5) .....	404
Figure 1-591	Reinstall the 1x500 Tray 3 pickup assembly (1 of 4) .....	405
Figure 1-592	Reinstall the 1x500 Tray 3 pickup assembly (2 of 4) .....	405
Figure 1-593	Reinstall the 1x500 Tray 3 pickup assembly (3 of 4) .....	406
Figure 1-594	Reinstall the 1x500 Tray 3 pickup assembly (4 of 4) .....	406
Figure 1-595	Remove the 3x500 Tray 3 pickup assembly (1 of 4) .....	407
Figure 1-596	Remove the 3x500 Tray 3 pickup assembly (2 of 4) .....	408
Figure 1-597	Remove the 3x500 Tray 3 pickup assembly (3 of 4) .....	408
Figure 1-598	Remove the 3x500 Tray 3 pickup assembly (4 of 4) .....	409
Figure 1-599	Reinstall the 3x500 Tray 3 pickup assembly (1 of 4) .....	410
Figure 1-600	Reinstall the 3x500 Tray 3 pickup assembly (2 of 4) .....	410
Figure 1-601	Reinstall the 3x500 Tray 3 pickup assembly (3 of 4) .....	411
Figure 1-602	Reinstall the 3x500 Tray 3 pickup assembly (4 of 4) .....	411
Figure 1-603	Remove the 3x500 Tray 4 pickup assembly (1 of 4) .....	412
Figure 1-604	Remove the 3x500 Tray 4 pickup assembly (2 of 4) .....	413
Figure 1-605	Remove the 3x500 Tray 4 pickup assembly (3 of 4) .....	413
Figure 1-606	Remove the 3x500 Tray 4 pickup assembly (4 of 4) .....	414

Figure 1-607	Reinstall the 3x500 Tray 4 pickup assembly (1 of 2)	415
Figure 1-608	Reinstall the 3x500 Tray 4 pickup assembly (2 of 2)	415
Figure 1-609	Remove the 3x500 Tray 5 pickup assembly (1 of 3)	416
Figure 1-610	Remove the 3x500 Tray 5 pickup assembly (2 of 3)	417
Figure 1-611	Remove the 3x500 Tray 5 pickup assembly (3 of 3)	417
Figure 1-612	Reinstall the 3x500 Tray 5 pickup assembly (1 of 2)	418
Figure 1-613	Reinstall the 3x500 Tray 5 pickup assembly (2 of 2)	418
Figure 1-614	Remove the 1x500 Tray 3 automatic close assembly (1 of 2)	419
Figure 1-615	Remove the 1x500 Tray 3 automatic close assembly (2 of 2)	419
Figure 1-616	Remove the 3x500 Tray 3, Tray 4, and Tray 5 automatic close assemblies (1 of 2)	420
Figure 1-617	Remove the 3x500 Tray 3, Tray 4, and Tray 5 automatic close assemblies (2 of 2)	421
Figure 1-618	1x500 pickup motor location	422
Figure 1-619	3x500 pickup motor locations	423
Figure 1-620	Remove the 1x500 Tray 3, 3x500 Tray 3, Tray 4, and Tray 5 pickup motors	423
Figure 1-621	Remove the HCI controller PCA	424
Figure 1-622	Remove the HCI, 1x500, and 3x500 left cover (1 of 2)	426
Figure 1-623	Remove the HCI, 1x500, and 3x500 left cover (2 of 2)	426
Figure 1-624	Reinstall the HCI, 1x500, and 3x500 left cover	427
Figure 1-625	Remove the HCI, 1x500, and 3x500 right door assembly (1 of 3)	428
Figure 1-626	Remove the HCI, 1x500, and 3x500 right door assembly (2 of 3)	428
Figure 1-627	Remove the HCI, 1x500, and 3x500 right door assembly (3 of 3)	429
Figure 1-628	Remove the HCI, 1x500, and 3x500 right rear cover (1 of 4)	430
Figure 1-629	Remove the HCI, 1x500, and 3x500 right rear cover (2 of 4)	430
Figure 1-630	Remove the HCI, 1x500, and 3x500 right rear cover (3 of 4)	431
Figure 1-631	Remove the HCI, 1x500, and 3x500 right rear cover (4 of 4)	431
Figure 1-632	Reinstall the HCI, 1x500, and 3x500 right rear cover	432
Figure 1-633	Correct placement of the IPTU for servicing	433
Figure 1-634	Incorrect placement of the IPTU for servicing	433
Figure 1-635	IPTU covers (1 of 2)	434
Figure 1-636	IPTU covers (2 of 2)	435
Figure 1-637	IPTU main assemblies	435
Figure 1-638	IPTU PCA	436
Figure 1-639	Remove the IPTU (1 of 4)	437
Figure 1-640	Remove the IPTU (2 of 4)	437
Figure 1-641	Remove the IPTU (3 of 4)	438
Figure 1-642	Remove the IPTU (4 of 4)	438
Figure 1-643	Remove the IPTU rear cover (1 of 3)	439
Figure 1-644	Remove the IPTU rear cover (2 of 3)	439
Figure 1-645	Remove the IPTU rear cover (3 of 3)	440
Figure 1-646	Reinstall the IPTU rear cover (1 of 2)	440
Figure 1-647	Reinstall the IPTU rear cover (2 of 2)	441

Figure 1-648	Remove the IPTU driver PCA (1 of 2)	442
Figure 1-649	Remove the IPTU driver PCA (2 of 2)	442
Figure 1-650	Remove the IPTU finisher lock assembly (1 of 5)	443
Figure 1-651	Remove the IPTU finisher lock assembly (2 of 5)	443
Figure 1-652	Remove the IPTU finisher lock assembly (3 of 5)	444
Figure 1-653	Remove the IPTU finisher lock assembly (4 of 5)	444
Figure 1-654	Remove the IPTU finisher lock assembly (5 of 5)	445
Figure 1-655	Remove the IPTU fan assembly (1 of 2)	446
Figure 1-656	Remove the IPTU fan assembly (2 of 2)	446
Figure 1-657	Remove the IPTU side panel assembly (1 of 6)	447
Figure 1-658	Remove the IPTU side panel assembly (2 of 6)	448
Figure 1-659	Remove the IPTU side panel assembly (3 of 6)	448
Figure 1-660	Remove the IPTU side panel assembly (4 of 6)	449
Figure 1-661	Remove the IPTU side panel assembly (5 of 6)	449
Figure 1-662	Remove the IPTU side panel assembly (6 of 6)	450
Figure 1-663	Reinstall the IPTU side panel assembly	450
Figure 1-664	Remove the IPTU upper and lower guide assemblies (1 of 9)	451
Figure 1-665	Remove the IPTU upper and lower guide assemblies (2 of 9)	451
Figure 1-666	Remove the IPTU upper and lower guide assemblies (3 of 9)	452
Figure 1-667	Remove the IPTU upper and lower guide assemblies (4 of 9)	452
Figure 1-668	Remove the IPTU upper and lower guide assemblies (5 of 9)	453
Figure 1-669	Remove the IPTU upper and lower guide assemblies (6 of 9)	453
Figure 1-670	Remove the IPTU upper and lower guide assemblies (7 of 9)	454
Figure 1-671	Remove the IPTU upper and lower guide assemblies (8 of 9)	455
Figure 1-672	Remove the IPTU upper and lower guide assemblies (9 of 9)	455
Figure 1-673	Install a replacement IPTU upper guide assembly (1 of 2)	456
Figure 1-674	Install a replacement IPTU upper guide assembly (2 of 2)	456
Figure 1-675	Identify the BM finishing accessory	458
Figure 1-676	Identify the BMHP finishing accessory	458
Figure 1-677	Identify the SS finishing accessory	459
Figure 1-678	Identify the SSHP finishing accessory	459
Figure 1-679	Stapler stacker covers and doors	460
Figure 1-680	Stapler stacker with hole punch covers and doors	461
Figure 1-681	Booklet maker covers and doors	462
Figure 1-682	Booklet maker with hole punch covers and doors	463
Figure 1-683	Remove the top cover lock assembly (1 of 3)	466
Figure 1-684	Remove the top cover lock assembly (2 of 3)	466
Figure 1-685	Remove the top cover lock assembly (3 of 3)	467
Figure 1-686	Remove the latch lower covers (front and rear; 1 of 3)	468
Figure 1-687	Remove the latch lower covers (front and rear; 2 of 3)	468
Figure 1-688	Remove the latch lower covers (front and rear; 3 of 3)	469

Figure 1-689	Remove the latch assembly (1 of 2) .....	470
Figure 1-690	Remove the latch assembly (2 of 2) .....	470
Figure 1-691	Remove the open/close stepped cover assembly (1 of 2) .....	471
Figure 1-692	Remove the open/close stepped cover assembly (2 of 2) .....	471
Figure 1-693	Remove the upper stepped cover assembly (1 of 4) .....	472
Figure 1-694	Remove the upper stepped cover assembly (2 of 4) .....	472
Figure 1-695	Remove the upper stepped cover assembly (3 of 4) .....	473
Figure 1-696	Remove the upper stepped cover assembly (4 of 4) .....	473
Figure 1-697	Remove the lower stepped cover assembly (1 of 5) .....	474
Figure 1-698	Remove the lower stepped cover assembly (2 of 5) .....	475
Figure 1-699	Remove the lower stepped cover assembly (3 of 5) .....	475
Figure 1-700	Remove the lower stepped cover assembly (4 of 5) .....	476
Figure 1-701	Remove the lower stepped cover assembly (5 of 5) .....	476
Figure 1-702	Reinstall the lower stepped cover (1 of 2) .....	477
Figure 1-703	Reinstall the lower stepped cover (2 of 2) .....	477
Figure 1-704	Remove the top door assembly (1 of 2) .....	478
Figure 1-705	Remove the top door assembly (2 of 2) .....	478
Figure 1-706	Remove the front door (1 of 2) .....	479
Figure 1-707	Remove the front door (2 of 2) .....	479
Figure 1-708	Move the inner upper cover out of the way (1 of 2) .....	480
Figure 1-709	Move the inner upper cover out of the way (2 of 2) .....	480
Figure 1-710	Remove the inner upper cover assembly (1 of 2) .....	481
Figure 1-711	Remove the inner upper cover assembly (2 of 2) .....	481
Figure 1-712	Remove the clutch assembly (front side; 1 of 2) .....	482
Figure 1-713	Remove the clutch assembly (front side; 2 of 2) .....	482
Figure 1-714	Remove the sensor switch assembly (1 of 4) .....	483
Figure 1-715	Remove the sensor switch assembly (2 of 4) .....	484
Figure 1-716	Remove the sensor switch assembly (3 of 4) .....	484
Figure 1-717	Remove the sensor switch assembly (4 of 4) .....	485
Figure 1-718	Move the inner lower cover out of the way (1 of 4) .....	486
Figure 1-719	Move the inner lower cover out of the way (2 of 4) .....	486
Figure 1-720	Move the inner lower cover out of the way (3 of 4) .....	487
Figure 1-721	Move the inner lower cover out of the way (4 of 4) .....	487
Figure 1-722	Remove the inner lower cover assembly (1 of 4) .....	488
Figure 1-723	Remove the inner lower cover assembly (2 of 4) .....	488
Figure 1-724	Remove the inner lower cover assembly (2 of 4) .....	489
Figure 1-725	Remove the inner lower cover assembly (4 of 4) .....	489
Figure 1-726	Remove the front foot cover assembly (1 of 2) .....	490
Figure 1-727	Remove the front foot cover assembly (2 of 2) .....	491
Figure 1-728	Remove the bin cable guide cover (1 of 6) .....	492
Figure 1-729	Remove the bin cable guide cover (2 of 6) .....	492

Figure 1-730	Remove the bin cable guide cover (3 of 6)	493
Figure 1-731	Remove the bin cable guide cover (4 of 6)	493
Figure 1-732	Remove the bin cable guide cover (5 of 6)	494
Figure 1-733	Remove the bin cable guide cover (6 of 6)	494
Figure 1-734	Bin cable guide cover correctly installed	495
Figure 1-735	Bin cable guide cover incorrectly installed	495
Figure 1-736	Remove the rear cover assembly (1 of 4)	496
Figure 1-737	Remove the rear cover assembly (2 of 4)	496
Figure 1-738	Remove the rear cover assembly (3 of 4)	497
Figure 1-739	Remove the rear cover assembly (4 of 4)	497
Figure 1-740	Remove the main controller PCA assembly (1 of 6)	498
Figure 1-741	Remove the main controller PCA assembly (2 of 6)	499
Figure 1-742	Remove the main controller PCA assembly (3 of 6)	499
Figure 1-743	Remove the main controller PCA assembly (4 of 6)	500
Figure 1-744	Remove the main controller PCA assembly (5 of 6)	500
Figure 1-745	Remove the main controller PCA assembly (6 of 6)	501
Figure 1-746	Install a replacement main controller PCA assembly	502
Figure 1-747	Main controller PCA switches	503
Figure 1-748	Booklet maker controller PCA switches	504
Figure 1-749	DIPSW4 alignment settings	504
Figure 1-750	DIPSW4 staple position settings	505
Figure 1-751	DIPSW folding position settings	506
Figure 1-752	Mark the paper	507
Figure 1-753	Folding position adjustment (1 of 3)	507
Figure 1-754	Folding position adjustment (2 of 3)	508
Figure 1-755	Folding position adjustment (3 of 3)	508
Figure 1-756	Positive and negative width adjustment	509
Figure 1-757	Adjust the stitcher (1 of 6)	510
Figure 1-758	Adjust the stitcher (2 of 6)	510
Figure 1-759	Adjust the stitcher (3 of 6)	511
Figure 1-760	Adjust the stitcher (4 of 6)	511
Figure 1-761	Adjust the stitcher (5 of 6)	511
Figure 1-762	Adjust the stitcher (6 of 6)	512
Figure 1-763	Remove the entrance upper guide assembly (1 of 3)	513
Figure 1-764	Remove the entrance upper guide assembly (2 of 3)	514
Figure 1-765	Remove the entrance upper guide assembly (3 of 3)	515
Figure 1-766	Remove the rear foot cover assembly (1 of 2)	516
Figure 1-767	Remove the rear foot cover assembly (2 of 2)	517
Figure 1-768	Remove the stack wall upper assembly and upper wall guide assembly (1 of 5)	518
Figure 1-769	Remove the stack wall upper assembly and upper wall guide assembly (2 of 5)	519
Figure 1-770	Remove the stack wall upper assembly and upper wall guide assembly (3 of 5)	519

Figure 1-771	Remove the stack wall upper assembly and upper wall guide assembly (4 of 5)	520
Figure 1-772	Remove the stack wall upper assembly and upper wall guide assembly (5 of 5)	520
Figure 1-773	Remove the upper cross member assembly (1 of 13)	521
Figure 1-774	Remove the upper cross member assembly (2 of 13)	522
Figure 1-775	Remove the upper cross member assembly (3 of 13)	522
Figure 1-776	Remove the upper cross member assembly (4 of 13)	523
Figure 1-777	Remove the upper cross member assembly (5 of 13)	523
Figure 1-778	Remove the upper cross member assembly (6 of 13)	524
Figure 1-779	Remove the upper cross member assembly (7 of 13)	524
Figure 1-780	Remove the upper cross member assembly (8 of 13)	525
Figure 1-781	Remove the upper cross member assembly (9 of 13)	525
Figure 1-782	Remove the upper cross member assembly (10 of 13)	526
Figure 1-783	Remove the upper cross member assembly (11 of 13)	526
Figure 1-784	Remove the upper cross member assembly (12 of 13)	527
Figure 1-785	Remove the upper cross member assembly (13 of 13)	528
Figure 1-786	Reinstall the upper cross member assembly (1 of 7)	529
Figure 1-787	Reinstall the upper cross member assembly (2 of 7)	529
Figure 1-788	Reinstall the upper cross member assembly (3 of 7)	530
Figure 1-789	Reinstall the upper cross member assembly (4 of 7)	530
Figure 1-790	Reinstall the upper cross member assembly (5 of 7)	531
Figure 1-791	Reinstall the upper cross member assembly (6 of 7)	531
Figure 1-792	Reinstall the upper cross member assembly (7 of 7)	532
Figure 1-793	Remove the paper feed drive assembly (1 of 2)	533
Figure 1-794	Remove the paper feed drive assembly (2 of 2)	534
Figure 1-795	Remove the pressure roller assembly (1 of 8)	536
Figure 1-796	Remove the pressure roller assembly (2 of 8)	536
Figure 1-797	Remove the pressure roller assembly (3 of 8)	537
Figure 1-798	Remove the pressure roller assembly (4 of 8)	537
Figure 1-799	Remove the pressure roller assembly (5 of 8)	538
Figure 1-800	Remove the pressure roller assembly (6 of 8)	538
Figure 1-801	Remove the pressure roller assembly (7 of 8)	539
Figure 1-802	Remove the pressure roller assembly (8 of 8)	539
Figure 1-803	Remove the stack upper bin and lower bin assemblies (1 of 5)	541
Figure 1-804	Remove the stack upper bin and lower bin assemblies (2 of 5)	542
Figure 1-805	Remove the stack upper bin and lower bin assemblies (3 of 5)	542
Figure 1-806	Remove the stack upper bin and lower bin assemblies (4 of 5)	543
Figure 1-807	Remove the stack upper bin and lower bin assemblies (5 of 5)	543
Figure 1-808	Reinstall the stack wall upper assembly and upper wall guide assembly (1 of 2)	544
Figure 1-809	Reinstall the stack wall upper assembly and upper wall guide assembly (2 of 2)	545
Figure 1-810	Remove the height wall assembly (1 of 2)	546
Figure 1-811	Remove the height wall assembly (2 of 2)	547

Figure 1-812	Reinstall the height wall assembly .....	547
Figure 1-813	Remove the paper face sensor and flag assembly (1 of 9) .....	548
Figure 1-814	Remove the paper face sensor and flag assembly (2 of 9) .....	549
Figure 1-815	Remove the paper face sensor and flag assembly (3 of 9) .....	549
Figure 1-816	Remove the paper face sensor and flag assembly (4 of 9) .....	550
Figure 1-817	Remove the paper face sensor and flag assembly (5 of 9) .....	550
Figure 1-818	Remove the paper face sensor and flag assembly (6 of 9) .....	551
Figure 1-819	Remove the paper face sensor and flag assembly (7 of 9) .....	551
Figure 1-820	Remove the paper face sensor and flag assembly (8 of 9) .....	552
Figure 1-821	Remove the paper face sensor and flag assembly (9 of 9) .....	552
Figure 1-822	Remove the staple subassembly (1 of 6) .....	553
Figure 1-823	Remove the staple subassembly (2 of 6) .....	553
Figure 1-824	Remove the staple subassembly (3 of 6) .....	554
Figure 1-825	Remove the staple subassembly (4 of 6) .....	554
Figure 1-826	Remove the staple subassembly (5 of 6) .....	555
Figure 1-827	Remove the staple subassembly (6 of 6) .....	555
Figure 1-828	Remove the staple connecting cable assembly (1 of 2) .....	556
Figure 1-829	Remove the staple connecting cable assembly (2 of 2) .....	557
Figure 1-830	Remove the staple assembly (1 of 7) .....	558
Figure 1-831	Remove the staple assembly (2 of 7) .....	559
Figure 1-832	Remove the staple assembly (3 of 7) .....	559
Figure 1-833	Remove the staple assembly (4 of 7) .....	560
Figure 1-834	Remove the staple assembly (5 of 7) .....	560
Figure 1-835	Remove the staple assembly (6 of 7) .....	561
Figure 1-836	Remove the staple assembly (7 of 7) .....	561
Figure 1-837	Remove the paper detect holder assembly .....	562
Figure 1-838	Reinstall the paper detect holder assembly .....	563
Figure 1-839	Identify the operation tray assembly .....	564
Figure 1-840	Remove the operation tray assembly (1 of 11) .....	565
Figure 1-841	Remove the operation tray assembly (2 of 11) .....	566
Figure 1-842	Remove the operation tray assembly (3 of 11) .....	567
Figure 1-843	Remove the operation tray assembly (4 of 11) .....	567
Figure 1-844	Remove the operation tray assembly (5 of 11) .....	568
Figure 1-845	Remove the operation tray assembly (6 of 11) .....	568
Figure 1-846	Remove the operation tray assembly (7 of 11) .....	569
Figure 1-847	Remove the operation tray assembly (8 of 11) .....	569
Figure 1-848	Remove the operation tray assembly (9 of 11) .....	570
Figure 1-849	Remove the operation tray assembly (10 of 11) .....	570
Figure 1-850	Remove the operation tray assembly (11 of 11) .....	571
Figure 1-851	Reinstall the operation tray assembly (1 of 5) .....	571
Figure 1-852	Reinstall the operation tray assembly (2 of 5) .....	572

Figure 1-853	Reinstall the operation tray assembly (3 of 5)	572
Figure 1-854	Reinstall the operation tray assembly (4 of 5)	573
Figure 1-855	Reinstall the operation tray assembly (5 of 5)	574
Figure 1-856	Identify the operation tray assembly	575
Figure 1-857	Remove the swing guide assembly (1 of 12)	576
Figure 1-858	Remove the swing guide assembly (2 of 12)	576
Figure 1-859	Remove the swing guide assembly (3 of 12)	577
Figure 1-860	Remove the swing guide assembly (4 of 12)	577
Figure 1-861	Remove the swing guide assembly (5 of 12)	578
Figure 1-862	Remove the swing guide assembly (6 of 12)	578
Figure 1-863	Remove the swing guide assembly (7 of 12)	579
Figure 1-864	Remove the swing guide assembly (8 of 12)	579
Figure 1-865	Remove the swing guide assembly (9 of 12)	580
Figure 1-866	Remove the swing guide assembly (10 of 12)	580
Figure 1-867	Remove the swing guide assembly (11 of 12)	581
Figure 1-868	Remove the swing guide assembly (12 of 12)	581
Figure 1-869	Reinstall the swing guide assembly (1 of 7)	582
Figure 1-870	Reinstall the swing guide assembly (2 of 7)	582
Figure 1-871	Reinstall the swing guide assembly (3 of 7)	583
Figure 1-872	Reinstall the swing guide assembly (4 of 7)	583
Figure 1-873	Reinstall the swing guide assembly (5 of 7)	584
Figure 1-874	Reinstall the swing guide assembly (6 of 7)	584
Figure 1-875	Reinstall the swing guide assembly (7 of 7)	585
Figure 1-876	Remove the return roller assembly (1 of 2)	587
Figure 1-877	Remove the return roller assembly (2 of 2)	587
Figure 1-878	Remove the clutch assembly (rear side; 1 of 6)	588
Figure 1-879	Remove the clutch assembly (rear side; 2 of 6)	588
Figure 1-880	Remove the clutch assembly (rear side; 3 of 6)	589
Figure 1-881	Remove the clutch assembly (rear side; 4 of 6)	589
Figure 1-882	Remove the clutch assembly (rear side; 5 of 6)	590
Figure 1-883	Remove the clutch assembly (rear side; 6 of 6)	590
Figure 1-884	Remove the stack ejection motor assembly (1 of 7)	591
Figure 1-885	Remove the stack ejection motor assembly (2 of 7)	591
Figure 1-886	Remove the stack ejection motor assembly (3 of 7)	592
Figure 1-887	Remove the stack ejection motor assembly (4 of 7)	592
Figure 1-888	Remove the stack ejection motor assembly (5 of 7)	593
Figure 1-889	Remove the stack ejection motor assembly (6 of 7)	593
Figure 1-890	Remove the stack ejection motor assembly (7 of 7)	594
Figure 1-891	Remove the press motor assembly (1 of 7)	595
Figure 1-892	Remove the press motor assembly (2 of 7)	595
Figure 1-893	Remove the press motor assembly (3 of 7)	596

Figure 1-894	Remove the press motor assembly (4 of 7)	596
Figure 1-895	Remove the press motor assembly (5 of 7)	597
Figure 1-896	Remove the press motor assembly (6 of 7)	597
Figure 1-897	Remove the press motor assembly (7 of 7)	598
Figure 1-898	Remove the common driver PCA assembly (1 of 2)	599
Figure 1-899	Remove the common driver PCA assembly (2 of 2)	600
Figure 1-900	Remove the interface cable assembly (1 of 3)	601
Figure 1-901	Remove the interface cable assembly (2 of 3)	601
Figure 1-902	Remove the interface cable assembly (3 of 3)	602
Figure 1-903	Remove the paper pass assembly (1 of 6)	603
Figure 1-904	Remove the paper pass assembly (2 of 6)	604
Figure 1-905	Remove the paper pass assembly (3 of 6)	604
Figure 1-906	Remove the paper pass assembly (4 of 6)	605
Figure 1-907	Remove the paper pass assembly (5 of 6)	605
Figure 1-908	Remove the paper pass assembly (6 of 6)	606
Figure 1-909	Remove the knob	608
Figure 1-910	Remove the saddle output bin assembly (1 of 2)	609
Figure 1-911	Remove the saddle output bin assembly (2 of 2)	609
Figure 1-912	Reinstall the saddle output bin assembly	610
Figure 1-913	Remove the right cover assembly (BM PCA; 1 of 7)	611
Figure 1-914	Remove the right cover assembly (BM PCA; 2 of 7)	612
Figure 1-915	Remove the right cover assembly (BM PCA; 3 of 7)	612
Figure 1-916	Remove the right cover assembly (BM PCA; 4 of 7)	613
Figure 1-917	Remove the right cover assembly (BM PCA; 5 of 7)	613
Figure 1-918	Remove the right cover assembly (BM PCA; 6 of 7)	614
Figure 1-919	Remove the right cover assembly (BM PCA; 7 of 7)	614
Figure 1-920	Remove the booklet maker controller PCA	615
Figure 1-921	Remove the inner side plate assembly (1 of 8)	616
Figure 1-922	Remove the inner side plate assembly (2 of 8)	617
Figure 1-923	Remove the inner side plate assembly (3 of 8)	617
Figure 1-924	Remove the inner side plate assembly (4 of 8)	618
Figure 1-925	Remove the inner side plate assembly (5 of 8)	618
Figure 1-926	Remove the inner side plate assembly (6 of 8)	619
Figure 1-927	Remove the inner side plate assembly (7 of 8)	619
Figure 1-928	Remove the inner side plate assembly (8 of 8)	620
Figure 1-929	Inner plate assembly in the up position	620
Figure 1-930	Inner plate assembly in the middle position	621
Figure 1-931	Reinstall the inner side plate assembly (1 of 3)	621
Figure 1-932	Reinstall the inner side plate assembly (2 of 3)	622
Figure 1-933	Reinstall the inner side plate assembly (3 of 3)	622
Figure 1-934	Remove the guide sensor assembly (1 of 4)	623

Figure 1-935	Remove the guide sensor assembly (2 of 4)	623
Figure 1-936	Remove the guide sensor assembly (3 of 4)	624
Figure 1-937	Remove the guide sensor assembly (4 of 4)	624
Figure 1-938	Remove the guide motor assembly (1 of 3)	625
Figure 1-939	Remove the guide motor assembly (2 of 3)	626
Figure 1-940	Remove the guide motor assembly (3 of 3)	626
Figure 1-941	Remove the saddle motor assembly (SS and BM; 1 of 3)	627
Figure 1-942	Remove the saddle motor assembly (SS and BM; 2 of 3)	627
Figure 1-943	Remove the saddle motor assembly (SS and BM; 3 of 3)	628
Figure 1-944	Remove the saddle feed motor assembly (1 of 6)	629
Figure 1-945	Remove the saddle feed motor assembly (2 of 6)	630
Figure 1-946	Remove the saddle feed motor assembly (3 of 6)	630
Figure 1-947	Remove the saddle feed motor assembly (4 of 6)	631
Figure 1-948	Remove the saddle feed motor assembly (5 of 6)	631
Figure 1-949	Remove the saddle feed motor assembly (6 of 6)	632
Figure 1-950	Remove the folding-motor mount assembly (1 of 6)	633
Figure 1-951	Remove the folding-motor mount assembly (2 of 6)	634
Figure 1-952	Remove the folding-motor mount assembly (3 of 6)	634
Figure 1-953	Remove the folding-motor mount assembly (4 of 6)	635
Figure 1-954	Remove the folding-motor mount assembly (5 of 6)	635
Figure 1-955	Remove the folding-motor mount assembly (6 of 6)	636
Figure 1-956	Reinstall the folding-motor mount assembly	637
Figure 1-957	Remove the delivery switch mount assembly (1 of 4)	638
Figure 1-958	Remove the delivery switch mount assembly (2 of 4)	639
Figure 1-959	Remove the delivery switch mount assembly (4 of 4)	639
Figure 1-960	Remove the delivery switch mount assembly (4 of 4)	640
Figure 1-961	Remove the saddle stapler assembly (1 of 3)	641
Figure 1-962	Remove the saddle stapler assembly (2 of 3)	642
Figure 1-963	Remove the saddle stapler assembly (3 of 3)	642
Figure 1-964	Remove the lower left guide assembly (1 of 3)	643
Figure 1-965	Remove the lower left guide assembly (2 of 3)	643
Figure 1-966	Remove the lower left guide assembly (3 of 3)	644
Figure 1-967	Remove the saddle delivery inner cover, front assembly (1 of 3)	645
Figure 1-968	Remove the saddle delivery inner cover, front assembly (2 of 3)	645
Figure 1-969	Remove the saddle delivery inner cover, front assembly (3 of 3)	646
Figure 1-970	Remove the saddle delivery inner cover, rear assembly (1 of 3)	647
Figure 1-971	Remove the saddle delivery inner cover, rear assembly (2 of 3)	647
Figure 1-972	Remove the saddle delivery inner cover, rear assembly (3 of 3)	648
Figure 1-973	Remove the saddle guide assembly (1 of 5)	650
Figure 1-974	Remove the saddle guide assembly (2 of 5)	650
Figure 1-975	Remove the saddle guide assembly (3 of 5)	651

Figure 1-976	Remove the saddle guide assembly (4 of 5)	651
Figure 1-977	Remove the saddle guide assembly (5 of 5)	652
Figure 1-978	Reinstall the saddle guide assembly (1 of 4)	653
Figure 1-979	Reinstall the saddle guide assembly (2 of 4)	653
Figure 1-980	Reinstall the saddle guide assembly (3 of 4)	654
Figure 1-981	Reinstall the saddle guide assembly (4 of 4)	654
Figure 1-982	Remove the saddle feed assembly (1 of 7)	656
Figure 1-983	Remove the saddle feed assembly (2 of 7)	656
Figure 1-984	Remove the saddle feed assembly (3 of 7)	657
Figure 1-985	Remove the saddle feed assembly (4 of 7)	657
Figure 1-986	Remove the saddle feed assembly (5 of 7)	658
Figure 1-987	Remove the saddle feed assembly (6 of 7)	658
Figure 1-988	Remove the saddle feed assembly (7 of 7)	659
Figure 1-989	Reinstall the saddle feed assembly	659
Figure 1-990	Remove the saddle assembly (1 of 13)	661
Figure 1-991	Remove the saddle assembly (2 of 13)	661
Figure 1-992	Remove the saddle assembly (3 of 13)	662
Figure 1-993	Remove the saddle assembly (4 of 13)	662
Figure 1-994	Remove the saddle assembly (5 of 13)	663
Figure 1-995	Remove the saddle assembly (6 of 13)	663
Figure 1-996	Remove the saddle assembly (7 of 13)	664
Figure 1-997	Remove the saddle assembly (8 of 13)	664
Figure 1-998	Remove the saddle assembly (9 of 13)	665
Figure 1-999	Remove the saddle assembly (10 of 13)	665
Figure 1-1000	Remove the saddle assembly (11 of 13)	666
Figure 1-1001	Remove the saddle assembly (12 of 13)	666
Figure 1-1002	Remove the saddle assembly (13 of 13)	667
Figure 1-1003	Reinstall the saddle assembly	668
Figure 1-1004	Remove the upper delivery guide assembly (1 of 3)	669
Figure 1-1005	Remove the upper delivery guide assembly (2 of 3)	670
Figure 1-1006	Remove the upper delivery guide assembly (3 of 3)	670
Figure 1-1007	Remove the saddle paper delivery assembly (1 of 5)	671
Figure 1-1008	Remove the saddle paper delivery assembly (2 of 5)	671
Figure 1-1009	Remove the saddle paper delivery assembly (3 of 5)	672
Figure 1-1010	Remove the saddle paper delivery assembly (4 of 5)	672
Figure 1-1011	Remove the saddle paper delivery assembly (5 of 5)	673
Figure 1-1012	Reinstall the saddle paper delivery assembly	673
Figure 1-1013	Remove the saddle rear end sensor assembly (1 of 10)	675
Figure 1-1014	Remove the saddle rear end sensor assembly (2 of 10)	675
Figure 1-1015	Remove the saddle rear end sensor assembly (3 of 10)	676
Figure 1-1016	Remove the saddle rear end sensor assembly (4 of 10)	677

Figure 1-1017	Remove the saddle rear end sensor assembly (5 of 10)	678
Figure 1-1018	Remove the saddle rear end sensor assembly (6 of 10)	678
Figure 1-1019	Remove the saddle rear end sensor assembly (7 of 10)	679
Figure 1-1020	Remove the saddle rear end sensor assembly (8 of 10)	679
Figure 1-1021	Remove the saddle rear end sensor assembly (9 of 10)	680
Figure 1-1022	Remove the saddle rear end sensor assembly (10 of 10)	680
Figure 1-1023	Reinstall the saddle rear end sensor assembly (1 of 2)	681
Figure 1-1024	Reinstall the saddle rear end sensor assembly (2 of 2)	681
Figure 1-1025	Remove the punch front cover (1 of 2)	682
Figure 1-1026	Remove the punch front cover (2 of 2)	683
Figure 1-1027	Remove the punch lower front cover assembly (1 of 3)	684
Figure 1-1028	Remove the punch lower front cover assembly (2 of 3)	684
Figure 1-1029	Remove the punch lower front cover assembly (3 of 3)	685
Figure 1-1030	Remove the punch rear cover assembly (1 of 2)	686
Figure 1-1031	Remove the punch rear cover assembly (2 of 2)	686
Figure 1-1032	Remove the punch controller PCA assembly	687
Figure 1-1033	Remove the punch waste tray	688
Figure 1-1034	Remove the punch inner cover assembly (1 of 4)	689
Figure 1-1035	Remove the punch inner cover assembly (2 of 4)	689
Figure 1-1036	Remove the punch inner cover assembly (3 of 4)	690
Figure 1-1037	Remove the punch inner cover assembly (4 of 4)	690
Figure 1-1038	Remove the punch top cover (1 of 6)	691
Figure 1-1039	Remove the punch top cover (2 of 6)	691
Figure 1-1040	Remove the punch top cover (3 of 6)	692
Figure 1-1041	Remove the punch top cover (4 of 6)	692
Figure 1-1042	Remove the punch top cover (5 of 6)	693
Figure 1-1043	Remove the punch top cover (6 of 6)	693
Figure 1-1044	Remove the punch hole assembly (1 of 8)	694
Figure 1-1045	Remove the punch hole assembly (2 of 8)	695
Figure 1-1046	Remove the punch hole assembly (3 of 8)	695
Figure 1-1047	Remove the punch hole assembly (4 of 8)	696
Figure 1-1048	Remove the punch hole assembly (5 of 8)	696
Figure 1-1049	Remove the punch hole assembly (6 of 8)	697
Figure 1-1050	Remove the punch hole assembly (7 of 8)	697
Figure 1-1051	Remove the punch hole assembly (8 of 8)	698
Figure 1-1052	Determine the punch hole skew	699
Figure 1-1053	Adjust the punch hole location	700
Figure 1-1054	Correct punch hole alignment	701
Figure 1-1055	Set the punch hole assembly type	702
Figure 1-1056	SW601 punch hole assembly type settings	703
Figure 1-1057	SW601 sensor adjustment settings	703

Figure 1-1058	Set the sensor adjustment values .....	704
Figure 1-1059	SW601 sensor adjustment settings .....	704
Figure 1-1060	SW601 sensor adjustment settings .....	705
Figure 2-1	M855 base product cover locations (1 of 2) .....	715
Figure 2-2	M855 base product assembly locations (2 of 2) .....	716
Figure 2-3	M880 base product assembly locations (1 of 2) .....	718
Figure 2-4	M880 base product assembly locations ( 2 of 2) .....	719
Figure 2-5	Stapler/stacker and booklet maker main assemblies .....	720
Figure 2-6	Stapler/stacker and booklet maker PCA .....	721
Figure 2-7	Stapler/stacker .....	722
Figure 2-8	Stapler/stacker with hole puncher external assembly locator .....	723
Figure 2-9	Staple stacker internal assembly locator .....	724
Figure 2-10	Staple stacker with hole puncher internal assembly locator .....	725
Figure 2-11	Staple stacker external assembly locator (door open) .....	726
Figure 2-12	Staple stacker with hole puncher external assembly locator (door open) .....	727
Figure 2-13	Booklet maker external assembly locator .....	728
Figure 2-14	Booklet maker with hole puncher external assembly locator .....	729
Figure 2-15	Booklet maker internal assembly locator .....	730
Figure 2-16	Booklet maker with hole puncher internal assembly locator .....	731
Figure 2-17	Booklet maker external assembly locator (door open) .....	732
Figure 2-18	Booklet maker with hole puncher external assembly locator (door open) .....	733
Figure 2-19	IPTU external assembly locator (1 of 3) .....	734
Figure 2-20	IPTU external assembly locator (2 of 3) .....	734
Figure 2-21	IPTU external assembly locator (3 of 3) .....	735
Figure 2-22	IPTU internal assembly locator (1 of 2) .....	736
Figure 2-23	IPTU internal assembly locator (2 of 2) .....	736
Figure 2-24	IPTU PCA .....	737
Figure 2-25	1x500-sheet feeder (1 of 2) .....	738
Figure 2-26	1x500-sheet feeder (2 of 2) .....	739
Figure 2-27	3x500-sheet feeder (1 of 2) .....	740
Figure 2-28	3x500-sheet feeder (2 of 2) .....	741
Figure 2-29	HCI feeder (1 of 6) .....	742
Figure 2-30	HCI feeder (2 of 6) .....	743
Figure 2-31	HCI feeder (3 of 6) .....	744
Figure 2-32	HCI feeder (4 of 6) .....	745
Figure 2-33	HCI feeder (5 of 6) .....	746
Figure 2-34	HCI feeder (6 of 6) .....	746
Figure 2-35	Document feeder and scanner assemblies (M880) .....	748
Figure 2-36	Document feeder assemblies (M880, 1 of 2) .....	750
Figure 2-37	Document feeder assemblies (M880, 2 of 2) .....	752
Figure 2-38	Scanner assemblies (M880) .....	754

Figure 2-39	Covers (M855) .....	756
Figure 2-40	Covers (M880) .....	758
Figure 2-41	Right door assembly .....	760
Figure 2-42	Internal components (1 of 6) .....	762
Figure 2-43	Internal components (2 of 6) .....	764
Figure 2-44	Internal components (3 of 6) .....	766
Figure 2-45	Internal components (4 of 6) .....	768
Figure 2-46	Internal components (5 of 6) .....	770
Figure 2-47	Internal components (6 of 6) .....	772
Figure 2-48	Intermediate paper transfer unit (IPTU) assemblies .....	774
Figure 2-49	1x500-sheet feeder with stand (M855 only) covers .....	776
Figure 2-50	1x500-sheet feeder with stand components .....	778
Figure 2-51	3x500-sheet feeder covers .....	780
Figure 2-52	3x500-sheet feeder components .....	782
Figure 2-53	HCI feeder covers .....	784
Figure 2-54	HCI feeder internal components (1 of 2) .....	786
Figure 2-55	HCI feeder internal components (2 of 2) .....	788
Figure 2-56	Stapler/stacker covers .....	790
Figure 2-57	Booklet maker covers .....	792
Figure 2-58	Finisher main body (1 of 3) .....	794
Figure 2-59	Finisher main body (2 of 3) .....	796
Figure 2-60	Finisher main body (3 of 3) .....	798
Figure 2-61	Stapler/stacker main body .....	800
Figure 2-62	Booklet maker main body .....	802
Figure 2-63	Booklet maker saddle assembly (1 of 3) .....	804
Figure 2-64	Booklet maker saddle assembly (2 of 3) .....	805
Figure 2-65	Booklet maker saddle assembly (3 of 3) .....	806

---

# 1 Removal and replacement

- [Removal and replacement strategy](#)
- [Customer-self repair assemblies](#)
- [Pickup, feed, and separation rollers and pads](#)
- [Covers and doors](#)
- [Main assemblies](#)
- [Input accessories](#)
- [Intermediate paper transport unit \(IPTU\)](#)
- [Finishing accessories](#)

# Removal and replacement strategy


## Considerations during removal and replacement


This chapter describes the removal and replacement of field-replaceable units (FRUs) only.

Replacing FRUs is generally the reverse of removal. Notes are included to provide directions for difficult or critical replacement procedures.

HP does not support repairing individual subassemblies or troubleshooting to the PCA component level.

---

 **WARNING!** Never operate or service the product with the protective cover removed from the laser scanner assembly. The reflected beam, although invisible, can damage your eyes.


 **WARNING!** The sheet-metal parts can have sharp edges. Be careful when handling sheet-metal parts.


 **CAUTION:** 

Some parts are sensitive to electrostatic discharge (ESD). Look for the ESD reminder when removing product parts. Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.

Protect the ESD-sensitive parts by placing them in ESD pouches when they are out of the product.

**CAUTION:** Do not bend or fold the flat cables during removal or installation.

 **NOTE:** To install a self-tapping screw, first turn it counterclockwise to align it with the existing thread pattern, and then carefully turn it clockwise to tighten. Do not overtighten. If a self-tapping screw-hole becomes stripped, repair the screw-hole or replace the affected assembly.

 **TIP:** For clarity, some figures in this chapter show assemblies removed that are not required to be removed to service the product (for example, the M880 scanner and document feeder assemblies). The procedures in this manual are correct for your product.

---

## Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152-mm (6-in) shaft length




**NOTE:** For the best fit, use a JIS #2 Phillips screwdriver for the stapler/stacker.

- Small, flat-blade screwdriver
- Needle-nose pliers
- ESD strap (if one is available)
- Penlight



**CAUTION:** Always use a Phillips screwdriver (callout 1). Do not use a Pozidriv screwdriver (callout 2) or any motorized screwdriver. These can damage screws or screw threads.

Figure 1-1 Screwdrivers



## Types of screws



**WARNING!** Make sure that assemblies are replaced with the correct screw type. Using the incorrect screw (for example, substituting a long screw for the correct shorter screw) can cause damage to the product or interfere with product operation. Do not intermix screws that are removed from one assembly with the screws that are removed from another assembly.

For a complete list of screw types and part numbers, see the Parts chapter in the product repair manual.

## Service approach

The products described in this manual use a field repair strategy. Defective parts are diagnosed and replaced at the Field Replaceable Unit (FRU) assembly level. Repair normally begins by using the product internal diagnostics and the following two-step process:

1. Isolate the problem to the major system (for example, the network or server, or the product).
2. Troubleshoot the problem by using the procedures in the troubleshooting manual.


After you locate a faulty part, the product can usually be repaired at the assembly level by replacing FRUs. Some mechanical assemblies might need to be repaired at the subassembly level. Hewlett-Packard Company does not support replacement of components on the printed circuit assemblies.

The user replaces toner cartridges as they are depleted. Additional instructions about other user-replaceable parts are provided in this section.

The product tracks the amount of use on the customer-replaceable supplies by keeping a page count. The product prompts the user to replace certain items when a supply is depleted or a specific number of pages has been printed.

Swapping toner cartridges between products might cause a misrepresentation of supply life values and is not recommended.

## Before performing service

 **WARNING!** Turn the product off, wait 5 seconds, and then remove the power cord before attempting to service the product. *If this warning is not followed, severe injury and damage to the product can result.* The power must be on for certain functional checks during troubleshooting. However, the power supply should be disconnected during parts removal.

1. Remove all paper.
2. Place the product on an ESD mat (if available). If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.
3. Remove the toner cartridges.
4. Remove the imaging drums.
5. Remove the trays.

## After performing service

1. Reinstall the toner cartridges.
2. Reinstall the trays.
3. Reinstall the imaging drums.
4. Return all paper to the trays.
5. Plug in the power cable and turn on the product.
6. Perform print-quality tests by printing from a host computer, the scanner glass, and the document feeder.

## Parts removal order

If multiple components must be removed to gain access to an assembly, the first step of the removal procedure lists all of the components that must be removed to gain access to that assembly. Use these lists to determine which parts must be removed before removing other parts.

## Supported paper sizes and types

If the product is experiencing assembly failure, use the tables in this section to verify that the customer is using media that meets HP specifications.

- [Supported paper sizes for the input trays and duplexer](#)
- [Supported paper types for the input trays and duplexer](#)
- [Supported paper sizes for the finishing accessories](#)
- [Supported paper types for the finishing accessories](#)

## Supported paper sizes for the input trays and duplexer



**NOTE:** To obtain the best results, select the correct paper size and type in the print driver before printing.

**Table 1-1** Supported paper sizes for the input trays and duplexer

Size and dimensions	Tray 1	Tray 2	3x500-sheet trays	3,500-sheet high-capacity trays	Automatic duplex printing
Letter 279 x 216 mm (11 x 8.5 in)	✓	✓	✓	✓	✓
Letter Rotated 216 x 279 mm (8.5 x 11 in)	✓	✓	✓		✓
Legal 216 x 356 mm (8.5 x 14 in)	✓	✓	✓		✓
Executive 267 x 184 mm (10.5 x 7.3 in)	✓	✓	✓		✓
Statement 216 x 140 mm (8.5 x 5.5 in)	✓				✓
Oficio (8.5 x 13) 216 x 330 mm (8.5 x 13 in)	✓	✓	✓		✓
11 x 17 279 x 432 mm (11 x 17 in)	✓	✓			✓
12 x 18 305 x 457 mm (12 x 18 in)	✓		✓		✓
3 x 5 76 x 127 mm (3 x 5 in)	✓				
4 x 6 101 x 152 mm (4 x 6 in)	✓				
5 x 7 127 x 178 mm (5 x 7 in)	✓				
5 x 8 127 x 203 mm (5 x 8 in)	✓				
A3 297 x 420 mm (11.7 x 16.5 in)	✓	✓	✓		✓
A4 297 x 210 mm (11.7 x 8.3 in)	✓	✓	✓	✓	✓

**Table 1-1 Supported paper sizes for the input trays and duplexer (continued)**

Size and dimensions	Tray 1	Tray 2	3x500-sheet trays	3,500-sheet high-capacity trays	Automatic duplex printing
A4 Rotated 210 x 297 mm (8.3 x 11.7)	✓	✓	✓		✓
A5 148 x 210 mm (5.8 x 8.3 in)	✓	✓	✓		✓
A6 105 x 148 mm (4.2 x 5.8 in)	✓				
RA3 305 x 430 mm (12 x 17 in)	✓		✓		✓
RA4 215 x 305 mm (8.5 x 12 in)	✓		✓		✓
SRA3 320 x 450 mm (12.6 x 17.7 in)	✓		✓		✓
SRA4 225 x 320 mm (8.9 x 12.6 in)	✓	✓	✓		✓
B4 (JIS) 257 x 364 mm (10.1 x 14.3 in)	✓	✓	✓		✓
B5 (JIS) 257 x 182 mm (10.1 x 7.2 in)	✓	✓	✓		✓
B6 (JIS) 128 x 182 mm (5.1 x 7.2 in)	✓				
Oficio (216 x 340) 215.9 x 340 mm (8.5 x 13.4 in)	✓	✓	✓		✓
8K 270 x 390 mm 270 x 390 mm (10.6 x 15.4 in)	✓	✓	✓		✓
16K 195 x 270 mm 270 x 195 mm (10.6 x 7.7 in)	✓	✓	✓		✓
8K 260 x 368 mm 260 x 368 mm (10.2 x 14.5 in)	✓	✓	✓		✓
16K 184 x 260 mm 260 x 184 mm (10.2 x 7.2 in)	✓	✓	✓		✓
8K 273 x 394 mm 273 x 394 mm (10.8 x 16 in)	✓	✓	✓		✓

**Table 1-1 Supported paper sizes for the input trays and duplexer (continued)**

Size and dimensions	Tray 1	Tray 2	3x500-sheet trays	3,500-sheet high-capacity trays	Automatic duplex printing
16K 197 x 273 mm 273 x 197 mm (10.8 x 7.8 in)	✓	✓	✓		✓
D Postcard (JIS) 148 x 200 mm (5.8 x 7.9 in)	✓				
Envelope #9 98 x 225 mm (3.9 x 8.9 in)	✓				
Envelope #10 105 x 241 mm (4.1 x 9.5 in)	✓				
Envelope Monarch 98 x 191 mm (3.9 x 7.5 in)	✓				
Envelope B5 176 x 250 mm (6.9 x 9.8 in)	✓				
Envelope C5 162 x 229 mm (6.4 x 9 in)	✓				
Envelope C6 114 x 162 mm (4.5 x 6.4 in)	✓				
Envelope DL 110 x 220 mm (4.3 x 8.7 in)	✓				
Custom 76 x 127 mm to 320 x 457 mm (3.0 x 5.0 in to 12.6 x 18.0 in)	✓				
Custom 148 x 210 mm to 297 x 432 mm (5.9 x 8.3 in to 11.6 x 17 in)		✓			
Custom 148 x 210 mm to 320 x 457 mm (5.9 x 8.3 in to 12.6 x 18.0 in)			✓		
Custom 175 x 210 mm to 320 x 457 mm (6.9 x 8.3 in to 12.6 x 18.0 in)					✓

## Supported paper types for the input trays and duplexer

Tray 1, Tray 2, and the 3x500-sheet trays support several types of paper in the following weight range: 60-220 g/m<sup>2</sup> (16-58 lb).

The 3,500-sheet high-capacity trays support cut-sheet paper in the following weight range: 60-120 g/m<sup>2</sup> (16-32 lb).

The automatic duplex printing unit supports paper in the following weight range: 60-220 g/m<sup>2</sup> (16-58 lb).



**NOTE:** To obtain the best results, select the correct paper size and type in the print driver before printing.

**Table 1-2** Supported paper types

Paper type	Tray 1	Tray 2	3x500-sheet trays	3,500-sheet high-capacity trays	Automatic duplex printing
Cut-sheet paper	✓	✓	✓	✓	✓
Labels	✓	✓	✓		
Transparencies	✓	✓			
Glossy paper	✓	✓			✓
Glossy film	✓	✓			
Photo paper	✓	✓			
Envelopes	✓				

## Supported paper sizes for the finishing accessories

 **NOTE:** For paper dimensions, see [Supported paper sizes for the input trays and duplexer on page 5](#)

**Table 1-3** Supported paper sizes for the finishing accessories

Size	Stacking (Portrait)	Stacking (Landscape)	Staple (Corner)	Staple (Saddle)	Hole punch 2 holes	Hole punch 3–4 holes	Booklet
Letter		✓	✓	✓	✓	✓	
Letter	✓		✓	✓	✓		✓
Short-edge feed							
Legal	✓		✓	✓	✓		✓
Executive		✓					
Executive	✓						
Short-edge feed							
Statement	✓						
Oficio (8.5 x 13)	✓		✓	✓	✓		✓
11 x 17	✓		✓	✓	✓	✓	✓
12 x 18	✓						
3 x 5							
4 x 6	✓						
5 x 7	✓						
5 x 8	✓						
A3	✓		✓	✓	✓	✓	✓
A4		✓	✓	✓	✓	✓	
A4	✓		✓	✓	✓		✓
Short-edge feed							
A5	✓	✓					
A6	✓						
RA3	✓						
RA4	✓	✓					
SRA3	✓						
SRA4	✓	✓					
B4 (JIS)	✓		✓	✓			
B5 (JIS)		✓					

**Table 1-3 Supported paper sizes for the finishing accessories (continued)**

Size	Stacking (Portrait)	Stacking (Landscape)	Staple (Corner)	Staple (Saddle)	Hole punch 2 holes	Hole punch 3–4 holes	Booklet
B5 (JIS)	✓						
Short-edge feed							
B6 (JIS)	✓						
Oficio (216 x 340)	✓		✓	✓	✓		✓
8K 270 x 390 mm	✓		✓	✓			
16K 195 x 270 mm		✓					
16K 195 x 270 mm	✓						
Short-edge feed							
8K 260 x 368 mm	✓						
16K 184 x 260 mm		✓					
16K 184 x 260 mm	✓						
Short-edge feed							
8K 273 x 394 mm	✓		✓				
16K 197 x 273 mm		✓					
16K 197 x 273 mm	✓						
Short-edge feed							
D Postcard (JIS)	✓	✓					
Envelope #9	✓						
Envelope #10	✓						
Envelope Monarch	✓						
Envelope B5	✓						
Envelope C5	✓						
Envelope C6	✓						

**Table 1-3** Supported paper sizes for the finishing accessories (continued)

Size	Stacking (Portrait)	Stacking (Landscape)	Staple (Corner)	Staple (Saddle)	Hole punch 2 holes	Hole punch 3–4 holes	Booklet
Envelope DL	✓						
Custom	✓	✓					
Dimensions vary							

## Supported paper types for the finishing accessories



**NOTE:** The number of sheets that can be stapled or folded into booklets varies with the thickness and size of the paper. The numbers in the following table indicate the number of sheets supported for each feature.

Pages pass through the hole punch unit one sheet at a time.

**Table 1-4** Supported paper types for the finishing accessories

Type	Stacking in bins 1 or 2	Staples, small sheets of paper	Staples, large sheets of paper	Hole punch	Booklets in bin 3 with one cover sheet	Booklets in bin 3 with no cover sheet
Plain	✓	50	30	✓	14	15
HP EcoSMART Lite	✓	50	30	✓	14	15
HP Matte 90g	✓	44	22	✓	9	10
Light 60-74g	✓	50	30	✓	14	15
Bond	✓	50	30	✓	9	10
Recycled	✓	50	30	✓	14	15
Intermediate 85-95g	✓	50	30	✓	5	6
HP Matte 120g	✓	18	11	✓	4	5
HP Soft Gloss 120g	✓	8	8	✓	4	5
HP Glossy 120g	✓	8	8	✓	4	5
Mid-Weight 96-110g	✓	18	11	✓	4	5
Heavy 111-130g	✓	18	9	✓	4	5
Mid-Weight Glossy 96-110g	✓	8	8	✓	4	5
Heavy Glossy 111-130g	✓	8	8	✓	4	5
HP Matte 150g	✓	13	9	✓	2	3
HP Glossy 150g	✓	5	5	✓		
Extra Heavy 131-175g	✓	12	16	✓	2	3
Extra Heavy Glossy 131-175g	✓			✓		
HP Matte 200g	✓			✓		
HP Glossy 200g	✓			✓		
Cardstock 176-220g	✓			✓		
Card Glossy 176-220g	✓			✓		

**Table 1-4** Supported paper types for the finishing accessories (continued)


Type	Stacking in bins 1 or 2	Staples, small sheets of paper	Staples, large sheets of paper	Hole punch	Booklets in bin 3 with one cover sheet	Booklets in bin 3 with no cover sheet
Color Transparency	✓					
Labels	✓					
Letterhead	✓	50	30	✓	14	15
Envelope	✓					
Heavy Envelope	✓					
Preprinted	✓	50	30	✓	14	15
Prepunched	✓	50	30			
Colored	✓	50	30	✓	14	15
Rough	✓	50	30	✓	9	10
Heavy Rough	✓	18	11	✓	5	6

# Customer-self repair assemblies

## Toner cartridge

1. Open the front door.
2. Grasp the handle of the toner cartridge, and then pull out to remove it.

**Figure 1-2** Remove the toner cartridge




## Imaging drum

1. Open the front door.
2. Grasp the handle at the front of the imaging drum, and then slide it out until the blue handle on the top is visible. Grasp the blue handle on the top, and then slide the imaging drum all the way out to remove it.

**⚠ CAUTION:** Do not touch or scratch the green cylinder on the bottom of the drum. While the imaging drum is out of the product, cover the green cylinder with paper to protect it from light exposure.


**Figure 1-3** Remove the image drum



## Secondary transfer roller


1. Open the right door.
2. Lift the green handle on the transfer assembly, and then open the panel.

**Figure 1-4** Remove the secondary transfer roller (1 of 2)



3. Remove the secondary transfer roller.


**Figure 1-5** Remove the secondary transfer roller (2 of 2)



## Reinstall the secondary transfer roller


Align the secondary transfer roller with the slots in the product, and then push until it clicks into place.

**Figure 1-6** Reinstall the secondary transfer roller




## Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5

Slide the tray open until it stops, and then lift up on the front of the tray to release it. Remove the tray.

 **NOTE:** Tray 2 is shown below. The procedure is the same for the 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5.


**Figure 1-7** Remove Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5



## Intermediate transfer belt (ITB)


1. Open the right door.

**Figure 1-8** Remove the ITB (1 of 4)




2. Lift the green handle on the transfer assembly, and then open the panel.

**Figure 1-9** Remove the ITB (2 of 4)




3. Raise the ITB levers.

**Figure 1-10** Remove the ITB (3 of 4)



4. Remove the ITB.

**Figure 1-11** Remove the ITB (4 of 4)




## Fuser

**⚠ WARNING!** The fuser might be hot.


1. Open the right door.

**Figure 1-12** Remove the fuser (1 of 3)




2. Rotate the two blue fuser handles toward the center of the fuser as shown below.

**Figure 1-13** Remove the fuser (2 of 3)



3. Grasp the handles and slide the fuser toward the right door to remove it.

**Figure 1-14** Remove the fuser (3 of 3)




## Switch back tray

Press and hold one button (callout 1) while pulling the switch back tray away from the product (callout 2) to remove it.



**NOTE:** The M855 is shown below. The procedure is the same for the M880.

**Figure 1-15** Remove the switch back tray



## Formatter


1. Loosen two screws.

**Figure 1-16** Remove the formatter (1 of 2)




2. Grasp the screws, and then slide the formatter out of the product.

**Figure 1-17** Remove the formatter (2 of 2)




## Reinstall the formatter or install a replacement formatter

1. Remove the following components from the existing formatter, and then reinstall them on the replacement formatter.

 **NOTE:** Not all of these components will be installed on the formatter---which components are installed depends on the product configuration. Identify the installed components, remove those components, and then install them on the replacement formatter.

- Hard-disk drive. See [Remove the HDD on page 26](#).
  - Solid-state memory. See [Remove the SSM on page 28](#).
  - Memory DIMM. See [Memory DIMM on page 32](#).
  - Fax PCA. See [Fax PCA \(M880\) on page 35](#).
2. Make sure that the formatter is seated completely when reinstalling it. To verify that the formatter is correctly installed, use the power switch to turn on the product power, and then observe the following functions of the LEDs on the formatter.
    - The heartbeat LED (callout 1) illuminates if the formatter is completely seated.
    - The connectivity LED (callout 2) indicates that the formatter is functioning correctly.
      - While the product is initializing, the connectivity LED rapidly blinks, and then turns off.
      - After the initialization sequence is complete, the connectivity LED slowly blinks continuously.

If the LEDs do not function correctly, see the LED diagnostics section in the product troubleshooting manual.




## Hard-disk drive (HDD) or solid-state memory (SSM)

Before proceeding, remove the following assemblies:


- Formatter. See [Formatter on page 23](#).

### Identify the storage device

- Hard-disk drive (HDD). See [Remove the HDD on page 26](#).




- Solid-state memory (SSM). See [Remove the SSM on page 28](#).




## Remove the HDD

 **CAUTION:**  ESD sensitive assembly.

1. Disconnect two connectors (callout 1).


 **CAUTION:** To disconnect the black connector (callout 2), grasp the connector and pull upward. Do not pull on the cable to disconnect the connector.

**Figure 1-18** Remove the HDD (1 of 2)



2. Release two tabs (callout 1), and then slide the HDD out and away from the plastic mounting bracket (callout 2) to remove it.

**Figure 1-19** Remove the HDD (2 of 2)



## Reinstall the HDD




**NOTE:** If you are installing a replacement drive, you must reinstall the product firmware. See [Reinstall the product firmware on page 30](#).

---


## Remove the SSM

 **CAUTION:**  ESD sensitive assembly.

1. Disconnect two connectors (callout 1).


 **CAUTION:** To disconnect the black connector (callout 2), grasp the connector and pull upward. Do not pull on the cable to disconnect the connector.

**Figure 1-20** Remove the SSM (1 of 2)



2. Release two tabs (callout 1), and then slide the solid state memory out and away from the plastic mounting bracket (callout 2) to remove it.

**Figure 1-21** Remove the SSM (2 of 2)



## Reinstall the SSM



**NOTE:** If you are installing a replacement SSM, you must reinstall the product firmware. See [Reinstall the product firmware on page 30](#).

---

## Reinstall the product firmware



**NOTE:** If you are installing a replacement HDD or SSM, use the procedure below to reinstall the product firmware on the replacement drive.

If you are removing the HDD or SSM so that it can be installed on a replacement formatter, you can skip this procedure.

1. Locate the product support Web site.
  - **In the US:**
    - Go to [www.hp.com/support/colorljM855](http://www.hp.com/support/colorljM855) or [www.hp.com/support/colorljflowMFPM880](http://www.hp.com/support/colorljflowMFPM880) .
  - **Outside the US:**
    - Go to <http://www.hp.com/support>
    - Select your country/region.
    - Select **Product Support & Troubleshooting**
    - Enter the product name, and then select **Search**.
2. Select **Drivers, Software, and Firmware**, and then select **Cross operating system (BIOS, Firmware, Diagnostics, etc.)**.
3. Locate the firmware download, and then select **Download**.
4. Copy the firmware upgrade file to the root directory of a USB flash drive. The firmware upgrade file has a `.bd1` extension.
5. Insert the USB flash drive into the USB port on the product control panel.
6. The following message displays on the control panel: **Error: 99.09.63 Incorrect Disk**. Touch the **OK** button to continue.
7. Wait for the **Pre-Boot** menu to appear on the control panel display, and then touch the down arrow ▼ button to scroll to **3 Administrator**. Touch the **OK** button to select it.
8. Touch the down arrow ▼ button to scroll to **6 Manage Disk**. Touch the **OK** button to select it.
9. Touch the down arrow ▼ button to scroll to **4 Clear Disk PWD**. Touch the **OK** button to select it.
10. The message **Proceed with Requested Action** displays. Touch the **OK** button to select it.
11. Touch the back ↶ button to return to the **Pre-Boot** menu home screen.
12. Touch the down arrow ▼ button to scroll to **3 Administrator**. Touch the **OK** button to select it.
13. Touch the down arrow ▼ button to scroll to **1 Download**. Touch the **OK** button to select it.
14. Touch the down arrow ▼ button to scroll to **3 USB Thumbdrive**. Touch the **OK** button to select it.
15. Touch the down arrow ▼ button to scroll to the firmware upgrade file that you downloaded in step 4. Touch the **OK** button to select it.



**NOTE:** If no `.bd1` files are listed, try saving the file to a different USB flash drive.

16. Wait while the file transfers. When the transfer is complete, the message **Complete** displays on the screen.
17. Turn the product off, remove the USB flash drive, and then turn the product on. Wait for several minutes while the product initializes.

## Memory DIMM

Before proceeding, remove the following assemblies:


- Formatter. See [Formatter on page 23](#).

### Remove the memory DIMM

**CAUTION:**  ESD sensitive assembly.


1. Release two clips.

**Figure 1-22** Remove the memory DIMM (1 of 2)



2. Rotate the DIMM upward (callout 1), and then remove it (callout 2).


**Figure 1-23** Remove the memory DIMM (2 of 2)



## Reinstall the memory DIMM


1. Align the notch (callout 1) on the DIMM with the tab (callout 2) on the connector.

**Figure 1-24** Reinstall the memory DIMM




2. Slide the DIMM into the connector (callout 1), and then rotate the DIMM down, toward the formatter. (callout 2).

**Figure 1-25** Reinstall the memory DIMM



3. Make sure that the memory DIMM snaps into the holder.

**Figure 1-26** Reinstall the memory DIMM



## Fax PCA (M880)

Before proceeding, remove the following assemblies:


- Formatter. See [Formatter on page 23](#).

### Remove the fax PCA (M880)

 **CAUTION:**  ESD sensitive assembly.


1. Rotate the connector end of the fax PCA up and away from the formatter to release it.

**Figure 1-27** Remove the fax PCA (M880; 1 of 2)



2. Carefully remove the fax PCA from the formatter bracket.

**Figure 1-28** Remove the fax PCA (M880; 2 of 2)



## Document feeder mylar strip (M880)


1. Open the document feeder cover.

**Figure 1-29** Remove the document feeder mylar strip (M880; 1 of 4)




2. Locate the mylar strip.

**Figure 1-30** Remove the document feeder mylar strip (M880; 2 of 4)




3. Carefully remove the mylar strip.

**Figure 1-31** Remove the document feeder mylar strip (M880; 3 of 4)



4. Use your finger to remove any adhesive that remains after removing the mylar strip.

**Figure 1-32** Remove the document feeder mylar strip (M880; 4 of 4)



### Install a replacement document feeder mylar strip (M880)

Use the following guidelines when you install the replacement mylar strip:


1. Skin oils on the mylar strip can cause paper pickup problems. Wash your hands before handling the replacement mylar strip.
2. When handling the replacement mylar strip, do not touch the adhesive portion of the strip.

3. Position the replacement mylar strip as shown, with the rounded corners on the strip facing the document tray.




**NOTE:** Make sure that the adhesive side of the guide is face down.

**Figure 1-33** Install a replacement document feeder mylar strip (M880; 1 of 2)



4. Press down firmly on the strip to adhere it to the product.

**Figure 1-34** Install a replacement document feeder mylar strip (M880; 2 of 2)



## Document feeder white backing (M880)


1. Open the document feeder.

**Figure 1-35** Remove the document feeder white backing (M880; 1 of 3)




2. Carefully remove the white backing.

**Figure 1-36** Remove the document feeder white backing (M880; 2 of 3)



3. Remove any rubber stoppers that might still be attached to the document feeder.

**Figure 1-37** Remove the document feeder white backing (M880; 3 of 3)




### Install a replacement document feeder white backing (M880)

1. Position the replacement white backing on the scanner glass. Carefully remove the protective backing from the rubber stoppers.


**CAUTION:** Do not touch the exposed adhesive.

**Figure 1-38** Install a replacement document feeder white backing (M880; 1 of 6)




2. Make sure that the arrow on the replacement white backing is positioned in the upper-left corner of the scanner glass.

**Figure 1-39** Install a replacement document feeder white backing (M880; 2 of 6)



3. Completely close the document feeder.

**Figure 1-40** Install a replacement document feeder white backing (M880; 3 of 6)



4. Firmly push down on the four corners of the document feeder to adhere the white backing to the document feeder.

**Figure 1-41** Install a replacement document feeder white backing (M880; 4 of 6)




5. Carefully open the document feeder.

**Figure 1-42** Install a replacement document feeder white backing (M880; 5 of 6)



6. Firmly press on the white backing over the areas shown below to make sure that the rubber stoppers are completely adhered to the document feeder.

**Figure 1-43** Install a replacement document feeder white backing (M880; 6 of 6)



## Background selector (M880)


1. Open the document-feeder door.

**Figure 1-44** Remove the background selector (M880; 1 of 4)




2. Rotate the input tray up.

**Figure 1-45** Remove the background selector (M880; 2 of 4)




3. Release two tabs.

**Figure 1-46** Remove the background selector (M880; 3 of 4)



4. Slide the background selector away from the product to remove it.

**Figure 1-47** Remove the background selector (M880; 4 of 4)




## Reinstall the background selector (M880)

Push in on the background selector until the tabs snap into place.

 **NOTE:** If jams occur after the assembly is installed, make sure that the assembly is fully seated.

**Figure 1-48** Reinstall the background selector (M880)



## Control panel assembly (M855)

1. Tilt the control panel up.

**Figure 1-49** Remove the control panel assembly (M855; 1 of 10)



2. Release one tab.

**Figure 1-50** Remove the control panel assembly (M855; 2 of 10)



3. Remove the cover.

**Figure 1-51** Remove the control panel assembly (M855; 3 of 10)



4. Release one blue locking latch.

**Figure 1-52** Remove the control panel assembly (M855; 4 of 10)



5. Rotate the back of the control panel up and away from the product.


**Figure 1-53** Remove the control panel assembly (M855; 5 of 10)



6. Lift the control panel assembly up and off of the product.


**CAUTION:** The control panel is still attached to the product by the control-panel cables. Do not attempt to completely remove the assembly.

**Figure 1-54** Remove the control panel assembly (M855; 6 of 10)




7. Tilt the control panel forward to access the control-panel connectors.

**Figure 1-55** Remove the control panel assembly (M855; 7 of 10)




8. Remove one screw (callout 1), and then release one ground wire (callout 2).

**Figure 1-56** Remove the control panel assembly (M855; 8 of 10)




9. Disconnect two USB cables (callout 1), and then disconnect one connector (callout 2).

**Figure 1-57** Remove the control panel assembly (M855; 9 of 10)



10. Remove the control panel assembly.

**Figure 1-58** Remove the control panel assembly (M855; 10 of 10)




## Reinstall the control panel assembly (M855)

Make sure that the USB cables (callout 1) are connected to the correct connectors. See the label (callout 2) next to the connectors.



**NOTE:** One connector on the control panel is not used and remains empty.

**Figure 1-59** Reinstall the control panel (M855)



## Control panel assembly (M880)


1. Tilt the control panel up.

**Figure 1-60** Remove the control panel assembly (M880; 1 of 8)



2. Release one tab (callout 1), and then rotate the cover up (callout 2) to remove it.

**Figure 1-61** Remove the control panel assembly (M880; 2 of 8)



3. Slide the keyboard about halfway out of the product.

**Figure 1-62** Remove the control panel assembly (M880; 3 of 8)




4. Disconnect two connectors.


**Figure 1-63** Remove the control panel assembly (M880; 4 of 8)



5. Remove one screw.


 **TIP:** Use the edge of a coin to loosen the screw.

**Figure 1-64** Remove the control panel assembly (M880; 5 of 8)




6. Slide the keyboard tray all the way into the product.

**Figure 1-65** Remove the control panel assembly (M880; 6 of 8)



7. Slide the control panel toward the right door.

**Figure 1-66** Remove the control panel assembly (M880; 7 of 8)



8. Slide the control panel toward the front of the product to remove it.




**Reinstallation tip** If you are installing a replacement control panel assembly, remove the keyboard assembly so that it can be installed on the replacement control panel assembly. See [Keyboard assembly \(M880\) on page 59](#).



**IMPORTANT:** If a device is installed in the hardware integration pocket (HIP), remove the HIP cover. See [Hardware integration pocket \(HIP\) cover \(M880\) on page 98](#). Remove the device and transfer it to the replacement control panel.


**Figure 1-67** Remove the control panel assembly (M880; 8 of 8)



## Reinstall the control panel assembly (M880)


1. Insert the cable and wire harness (callout 1) into the opening at the back of the control panel (callout 2).

**Figure 1-68** Reinstall the control panel assembly (M880; 1 of 3)




2. Insert the tabs on the control panel into the slots on the product.

**Figure 1-69** Reinstall the control panel assembly (M880; 2 of 3)



3. Slide the control panel toward the left door to secure it to the product.

**Figure 1-70** Reinstall the control panel assembly (M880; 3 of 3)



## Keyboard assembly (M880)

Before proceeding, remove the following assemblies:

- Control panel (M880). See [Control panel assembly \(M880\) on page 53](#).

### Remove the keyboard assembly (M880)

1. Place the control panel on a flat surface.

**Figure 1-71** Remove the keyboard assembly (M880; 1 of 7)




2. Open the hinged latch to release the flat cable.

**CAUTION:** This connector is a Zero Insertion Force (ZIF) connector that uses a hinged retainer to secure a flat cable. The hinged retainer must be opened to release the flat cable.

**CAUTION:** Be careful. Do not dislodge the latch from the connector when opening it.

**Figure 1-72** Remove the keyboard assembly (M880; 2 of 7)



3. Disconnect the flat cable.

**Figure 1-73** Remove the keyboard assembly (M880; 3 of 7)



4. Tilt the screen down until it lies flat.

**Figure 1-74** Remove the keyboard assembly (M880; 4 of 7)



5. Slide the keyboard tray all of the way out of the control panel until it stops.

**Figure 1-75** Remove the keyboard assembly (M880; 5 of 7)




6. Turn the control panel face-down on the work surface.

**Figure 1-76** Remove the keyboard assembly (M880; 6 of 7)



7. Release and hold two tabs (callout 1) while sliding the keyboard tray away from the control panel (callout 2) to remove it.


**Figure 1-77** Remove the keyboard assembly (M880; 7 of 7)



## Reinstall the keyboard assembly (M880)

1. Turn the keyboard tray upside down, and then position the flat cable (callout 1) inside the tray cavity. Align the edges of the tray (callout 2) with the slots in the control panel (callout 3).

**Figure 1-78** Reinstall the keyboard assembly (M880; 1 of 7)




2. Slide the keyboard tray all the way into the control panel. The tabs on the tray snap into place as it is installed.

**Figure 1-79** Reinstall the keyboard assembly (M880; 2 of 7)



3. Turn the control panel face-up.

**Figure 1-80** Reinstall the keyboard assembly (M880; 3 of 7)



4. Tilt the screen up.


**Figure 1-81** Reinstall the keyboard assembly (M880; 4 of 7)



5. Open the hinged latch, and then position the flat cable in the connector.

**CAUTION:** Be careful. Do not dislodge the latch from the connector when opening it.

**Figure 1-82** Reinstall the keyboard assembly (M880; 5 of 7)




6. Carefully close the latch to lock the flat cable into position.

**CAUTION:** This connector is a Zero Insertion Force (ZIF) connector that uses a hinged retainer to secure a flat cable. When the flat cable is reinstalled, fully insert the flat cable in the connector, and then close the hinged retainer to lock the flat cable into the connector and provide proper electrical contact. If the flat cable is not locked into the connector, no electrical contact will occur.

**CAUTION:** Be careful. Do not dislodge the latch from the connector when closing it.


**Figure 1-83** Reinstall the keyboard assembly (M880; 6 of 7)



7. Lightly pull on the flat cable to verify that it is securely fastened in the connector.

**⚠ CAUTION:** Be careful. Do not use your full force to pull on the flat cable. A light pull on the cable is sufficient to verify that it is securely fastened.

**Figure 1-84** Reinstall the keyboard assembly (M880; 7 of 7)



## Pickup, feed, and separation rollers and pads

- [Document-feeder roller \(M880 only\)](#)
- [Document-feeder separation pad \(M880 only\)](#)
- [Tray 1 rollers](#)
- [Tray 2, 1x500-sheet feeder, and 3x500-sheet feeder rollers](#)
- [High-capacity input \(HCI\) rollers](#)

## Document-feeder roller (M880 only)

**CAUTION:** If you are replacing the roller, do not touch the surface of the replacement roller. Skin oils deposited on the roller might cause paper pickup problems.


1. Open the document-feeder door.

**Figure 1-85** Remove the document-feeder roller (M880; 1 of 3)




2. Release one tab, and then open the access door.

**Figure 1-86** Remove the document-feeder roller (M880; 2 of 3)



3. Slide the roller left, and then lift it up and out of the product.


**Figure 1-87** Remove the document-feeder roller (M880; 3 of 3)



### Reinstall the document-feeder roller (M880 only)

The roller assembly is keyed. When reinstalling the roller assembly, position the hex-shaped fitting on the shaft toward the rear of the product.

**Figure 1-88** Reinstall the document-feeder roller (M880)



**IMPORTANT:** When the roller is reinstalled, the access door must be fully closed. When you close the door, you should hear two audible clicks. If, after replacing the roller document feeder, a document feeder jam message appears on the control panel display, make sure that the access door is fully closed.

## Document-feeder separation pad (M880 only)

**CAUTION:** If you are replacing the pad, do not touch the surface of the replacement pad. Skin oils deposited on the pad might cause paper pickup problems.

1. Open the document-feeder door.

**Figure 1-89** Remove the document-feeder separation pad (M880; 1 of 4)




2. Release one tab to open the access door.

**Figure 1-90** Remove the document-feeder separation pad (M880; 2 of 4)



3. The separation pad is spring-loaded and partially releases when the access door is opened.


**Figure 1-91** Remove the document-feeder separation pad (M880; 3 of 4)



4. Lift the separation pad up and away from the product.

**CAUTION:** If the spring becomes dislodged, securely reinstall it as shown below.

**Figure 1-92** Remove the document-feeder separation pad (M880; 4 of 4)



## Reinstall the document-feeder separation pad (M880 only)


1. Release and hold the separation pad access door open.

**Figure 1-93** Reinstall the document-feeder separation pad (M880; 1 of 5)



2. Align the pins on the separation pad with the mounting slots.

**Figure 1-94** Reinstall the document-feeder separation pad (M880; 2 of 5)



3. Carefully press down on the separation pad to compress the spring.

**Figure 1-95** Reinstall the document-feeder separation pad (M880; 3 of 5)




4. Continue to press down on the separation pad, and then release the access door.

**Figure 1-96** Reinstall the document-feeder separation pad (M880; 4 of 5)



5. Verify that the separation pad is correctly installed and that the access door is fully closed as shown below.

**Figure 1-97** Reinstall the document-feeder separation pad (M880; 5 of 5)




## Tray 1 rollers

**CAUTION:** Do not touch the surface of the rollers. Skin oils deposited on the rollers might cause paper pickup problems.


1. Open the right door.
2. Release two hinge pins and then remove the paper-feed cover.

**Figure 1-98** Remove the Tray 1 rollers (1 of 5)




3. Release one tab (callout 1), slide the multipurpose upper feed guide to the right to release it (callout 2), and then lift it away from the door to remove it (callout 3).

**Figure 1-99** Remove the Tray 1 rollers (2 of 5)




4. Remove one plastic clip.

**Figure 1-100** Remove the Tray 1 rollers (3 of 5)




5. Remove the upper roller by sliding it to the right.

**Figure 1-101** Remove the Tray 1 rollers (4 of 5)



6. Pinch and hold the tab at the end of the lower roller to release it, and then slide the roller to the right to release it from the metal shaft. Slide the roller down to remove it.


**Figure 1-102** Remove the Tray 1 rollers (5 of 5)



## Reinstall the Tray 1 rollers

Position the tabs on the multipurpose upper feed guide in the slots in the right door, and then slide it to the left to secure it to the door. One tab will click into place when the guide is seated properly.

**Figure 1-103** Reinstall the Tray 1 rollers



## Tray 2, 1x500-sheet feeder, and 3x500-sheet feeder rollers

Before proceeding, remove one or more of the following trays, depending upon which rollers you are replacing:

- Tray 2. See [Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 on page 18](#).
- 1x500 Tray 3 (1x500 only). See [Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 on page 18](#).
- 3x500 Tray 3 (3x500 only). See [Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 on page 18](#).
- 3x500 Tray 4 (3x500 only). See [Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 on page 18](#).
- 3x500 Tray 5 (3x500 only). See [Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 on page 18](#).


**CAUTION:** Do not touch the surface of the rollers. Skin oils deposited on the rollers might cause paper pickup problems.

**NOTE:** Tray 2 is shown in the figures below. The procedure is the same for all of the referenced trays.

### Remove the Tray 2, 1x500-sheet feeder, and 3x500-sheet feeder rollers


1. Remove the appropriate tray. See [Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 on page 18](#).
2. Locate the rollers on the right-hand side of the tray cavity.

**Figure 1-104** Remove the Tray 2, 1x500, and 3x500 rollers (1 of 2)



3. Grasp the plastic tab on the roller and then pull the roller off of the rod. Repeat the process for the other rollers.


**Figure 1-105** Remove the Tray 2, 1x500, and 3x500 rollers (2 of 2)



### Reinstall the Tray 2, 1x500-sheet feeder, and 3x500-sheet feeder rollers

Reinstall the rollers in the order shown below. Make sure that the rollers snap into place.

**Figure 1-106** Reinstall the Tray 2, 1x500, and 3x500 rollers



## High-capacity input (HCI) rollers

Before proceeding, remove the following assemblies:


- HCI right tray. See [HCI right tray on page 360](#).
- HCI left tray. See [HCI left tray on page 361](#).

**CAUTION:** If you are replacing the rollers, do not touch the surface of the replacement rollers. Skin oils deposited on the rollers might cause paper pickup problems.


### Remove the HCI rollers

1. Locate the rollers inside the tray cavity.


**Figure 1-107** Remove the HCI rollers (1 of 2)



2. Pinch the tabs at the end of the rollers to release them, and then remove two rollers in the order shown below.

 **NOTE:** One roller is not replaced.


**Figure 1-108** Remove the HCI rollers (2 of 2)




## Reinstall the HCI rollers

Reinstall the rollers in the order shown below. Make sure that the rollers snap into place.

**Figure 1-109** Reinstall the HCI rollers



# Covers and doors

 **TIP:** For clarity, some figures in this chapter show assemblies removed that are not required to be removed to service the product (for example, the scanner and document feeder assemblies). The procedures in this manual are correct for your product.

---

- [Location of major components](#)
- [Scanner back cover \(M880\)](#)
- [Scanner left cover \(M880\)](#)
- [Scanner right cover \(M880\)](#)
- [Scanner front cover \(M880\)](#)
- [Right upper rear cover \(M855\)](#)
- [Hardware integration pocket \(HIP\) cover \(M855\)](#)
- [Hardware integration pocket \(HIP\) cover \(M880\)](#)
- [Face-down bin](#)
- [Left rear cover](#)
- [Switch back cover](#)
- [Lower right cover](#)
- [Rear upper rear cover \(M880\)](#)
- [Right upper rear cover \(M880\)](#)
- [Rear upper MFP cover \(M880\)](#)
- [Left upper rear cover and rear upper B cover \(M880\)](#)
- [Rear upper front cover \(M880\)](#)
- [Front top cover](#)
- [Rear top cover \(M855\)](#)
- [Left cover](#)
- [Right upper front cover \(M855\)](#)
- [Right upper front cover \(M880\)](#)
- [Right upper cover \(M855\)](#)
- [Right door assembly](#)
- [Left front cover](#)
- [Front door](#)
- [Rear cover](#)
- [Right rear cover](#)

- [Front inner cover](#)

# Location of major components

Figure 1-110 M855 base product covers and doors (1 of 2)




Table 1-5 M855 base product covers and doors (1 of 2)

Item	Description	Item	Description
1	Tray 1	7	Tray 2
2	Right door	8	Power switch
3	Switch back tray	9	Front door
4	Face-down bin	10	HIP cover
5	Power receptacle	11	USB insertion slot
6	Engine test button		

Figure 1-111 M855 base product covers and doors (2 of 2)




Table 1-6 M855 base product covers and doors (2 of 2)

Item	Description	Item	Description
1	Right upper cover	9	Rear cover
2	Switch back cover	10	Rear top cover
3	Right door assembly	11	Right upper rear cover
4	Lower right cover	12	Front door assembly
5	Face-down bin	13	Left front cover
6	Left cover	14	Right upper front cover
7	Left rear cover	15	Front top cover
8	Right rear cover		

Figure 1-112 M880 base product covers and doors (1 of 2)





Table 1-7 M880 base product covers and doors (1 of 2)

Item1	Description	Item	Description
1	Tray 1	6	Engine test button
2	Right door	7	Tray 2
3	Switch back tray	8	Power switch
4	Face-down bin	9	Front door
5	Power receptacle	10	Rear upper MFP cover

**Figure 1-113** M880 base product covers and doors (2 of 2)




**Table 1-8** M880 base product covers and doors (2 of 2)

Item	Description	Item	Description
1	Switch back cover	9	Left upper rear cover
2	Right door assembly	10	Rear upper rear cover
3	Lower right cover	11	Right upper rear cover
4	Face-down bin	12	Front door assembly
5	Left cover	13	Left front cover
6	Left rear cover	14	Right upper front cover
7	Right rear cover	15	Front top cover
8	Rear cover	16	Rear upper front cover

## Scanner back cover (M880)

1. Remove two screws.

**Figure 1-114** Remove the scanner back cover (M880; 1 of 2)



2. Remove the cover.

**Figure 1-115** Remove the scanner back cover (M880; 2 of 2)



## Scanner left cover (M880)

Before proceeding, remove the following assemblies:

- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).

### Remove the scanner left cover (M880)

1. Remove two screws.

**Figure 1-116** Remove the scanner left cover (M880; 1 of 2)



2. Slide the cover towards the rear of the product to release it, and then remove the cover.

**Figure 1-117** Remove the scanner left cover (M880; 2 of 2)



## Scanner right cover (M880)

Before proceeding, remove the following assemblies:

- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).

### Remove the scanner right cover (M880)


1. Remove two screws.

**Figure 1-118** Remove the scanner right cover (M880; 1 of 2)



2. Slide the cover towards the rear of the product to remove it.

**Figure 1-119** Remove the scanner right cover (M880; 2 of 2)



## Scanner front cover (M880)

Before proceeding, remove the following assemblies:

- Hardware integration pocket (HIP) cover (M880). See [Hardware integration pocket \(HIP\) cover \(M880\) on page 98](#).
- Control panel assembly (M880). See [Control panel assembly \(M880\) on page 53](#).
- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).
- Scanner left cover (M880). See [Scanner left cover \(M880\) on page 89](#).
- Scanner right cover (M880). See [Scanner right cover \(M880\) on page 90](#).

### Remove the scanner front cover (M880)


1. Raise the document feeder to the open position.

**Figure 1-120** Remove the scanner front cover (M880; 1 of 8)



2. Release one tab (callout 1), and then remove the wire guide (callout 2).

**Figure 1-121** Remove the scanner front cover (M880; 2 of 8)



3. Remove two screws.

**Figure 1-122** Remove the scanner front cover (M880; 3 of 8)



4. Remove one screw.

**Figure 1-123** Remove the scanner front cover (M880; 4 of 8)



5. Remove two screws.

**Figure 1-124** Remove the scanner front cover (M880; 5 of 8)



6. Carefully flex the corner of the cover away from the scanner (callout 1), and then slightly rotate the bottom of the cover up and off of the scanner (callout 2).

**Figure 1-125** Remove the scanner front cover (M880; 6 of 8)



7. Carefully flex the corner of the cover away from the scanner (callout 1), and then rotate the bottom of the cover up (callout 2).

**Figure 1-126** Remove the scanner front cover (M880; 7 of 8)



8. Continue to rotate the cover up and away from the product to remove it.


**Figure 1-127** Remove the scanner front cover (M880; 8 of 8)



## Right upper rear cover (M855)

Remove two screws (callout 1), and then remove the cover (callout 2).

**Figure 1-128** Remove the right upper rear cover (M855)



## Hardware integration pocket (HIP) cover (M855)

Use a small flat blade screwdriver to carefully release the cover, and then remove it.

**Figure 1-129** Remove the hardware integration pocket (HIP) cover (M855)



## Hardware integration pocket (HIP) cover (M880)

1. Note the location of four tabs under the HIP cover.

**Figure 1-130** Remove the HIP cover (M880; 1 of 3)



2. Release two tabs on the side of the HIP cover toward the control panel screen.

**Figure 1-131** Remove the HIP cover (M880; 2 of 3)



3. Remove the HIP cover.


**Figure 1-132** Remove the HIP cover (M880; 3 of 3)



## Reinstall the HIP cover (M880)

1. Align the tabs (callout 1) on the cover with the slots in the product (callout 2).

**Figure 1-133** Reinstall the HIP cover (M880; 1 of 2)




2. Lower the HIP cover until it snaps into place.

**Figure 1-134** Reinstall the HIP cover (M880; 2 of 2)




## Face-down bin

 **NOTE:** The M855 is pictured in the figures below. The same face-down bin part is used on the M855 and the M880. On the M880, the face-down bin is located in the cavity under the scanner assembly.

1. Remove two screws.

**Figure 1-135** Remove the face-down bin (1 of 2)



2. Lift up, and then remove the face-down bin.


**Figure 1-136** Remove the face-down bin (2 of 2)



## Reinstall the face-down bin


1. Make sure that the tabs (callout 1) on the bin are aligned with the slots (callout 2) in the product.

**Figure 1-137** Reinstall the face-down bin (1 of 2)




2. Press downward and toward the right door (callout 1) to fully seat the tabs, and then lower the bin into position (callout 2).

**Figure 1-138** Remove the face-down bin (2 of 2)




3. Check to make sure that the cover is installed correctly and that no tabs are visible.


 **IMPORTANT:** Incorrect installation might cause paper jams.

 **NOTE:** The scanner assembly on the M880 obscures the view of this portion of the face-down bin. Slide your fingers across the edge between the face-down bin and the product to make sure that all the tabs are seated properly.

**Figure 1-139** Correct installation of face-down bin.



**Figure 1-140** Incorrect installation of face-down bin.



## Left rear cover


Before proceeding, remove the following assemblies:

- Intermediate paper transport unit (IPTU), if it is installed. See [IPTU assembly on page 437](#).

### Remove the left rear cover


1. Remove one screw (callout 1).

**Figure 1-141** Remove the left rear cover (1 of 2)



2. Release one tab (callout 1), and then remove the cover (callout 2).


**Figure 1-142** Remove the left rear cover (2 of 2)



## Switch back cover


1. Open the right door, and then remove two screws.

**Figure 1-143** Remove the switch back cover (1 of 2)




2. Remove the cover (callout 1).

**Figure 1-144** Remove the switch back cover (2 of 2)



## Lower right cover

 **NOTE:** If the Tray 2 is not already removed for servicing, remove it now.


1. Remove one screw.

**Figure 1-145** Remove the lower right cover (1 of 2)



2. Remove the cover (callout 1).


**Figure 1-146** Remove the lower right cover (2 of 2)



## Rear upper rear cover (M880)

1. Remove seven screws.

**Figure 1-147** Remove the rear upper rear cover (M880; 1 of 2)



2. Remove the cover (callout 1).


**Figure 1-148** Remove the rear upper rear cover (M880; 2 of 2)



## Right upper rear cover (M880)


1. Remove two screws.

**Figure 1-149** Remove the right upper rear cover (M880; 1 of 2)



2. Remove the cover (callout 1).


**Figure 1-150** Remove the right upper rear cover (M880; 2 of 2)



## Rear upper MFP cover (M880)


1. Remove one screw (callout 1).

**Figure 1-151** Remove the rear upper MFP cover (M880; 1 of 2)



2. Remove the cover.


**Figure 1-152** Remove the rear upper MFP cover (M880; 2 of 2)



## Reinstall the rear upper MFP cover (M880)

Install the tab (callout 1) on the cover into the slot (callout 2) on the product, and then lower the cover into place.


**Figure 1-153** Reinstall the rear upper MFP cover (M880)



## Left upper rear cover and rear upper B cover (M880)

Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Rear upper MFP cover (M880). See [Rear upper MFP cover \(M880\) on page 109](#).

 **NOTE:** The figures below show the document feeder and scanner removed for clarity. It is not necessary to remove these parts before removing the left upper rear cover and rear upper B cover.

### Remove the left upper rear cover and rear upper B cover (M880)

1. Remove one screw.

**Figure 1-154** Remove the left upper rear cover and rear upper B cover (M880; 1 of 3)




2. Remove the cover (callout 1).

**Figure 1-155** Remove the left upper rear cover and rear upper B cover (M880; 2 of 3)



3. Remove one screw, and then separate the rear upper B cover from the left upper rear cover.

**Figure 1-156** Remove the left upper rear cover and rear upper B cover (M880; 3 of 3)



## Rear upper front cover (M880)

Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Rear upper MFP cover (M880). See [Rear upper MFP cover \(M880\) on page 109](#).
- Left upper rear cover (M880). See [Left upper rear cover and rear upper B cover \(M880\) on page 111](#).
- Document feeder (M880). See [Document feeder assembly \(M880\) on page 154](#).
- Scanner assembly (M880). See [Scanner assembly \(M880\) on page 162](#).

### Remove the rear upper front cover (M880)


1. Release one tab.

**Figure 1-157** Remove the rear upper front cover (M880; 1 of 2)



2. Slide the cover away from the product to remove it.

**Figure 1-158** Remove the rear upper front cover (M880; 2 of 2)



## Front top cover

Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).

### Remove the front top cover

1. Remove one screw (callout 1).

**Figure 1-159** Remove the front top cover (1 of 2)



2. Release one tab (callout 1), and then remove the cover.

**Figure 1-160** Remove the front top cover (2 of 2)



## Rear top cover (M855)


Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).

### Remove the rear top cover (M855)

1. Remove one screw.

**Figure 1-161** Remove the rear top cover (M855; 1 of 3)



2. Slide the cover away from the product to remove it.

**Figure 1-162** Remove the rear top cover (M855; 2 of 3)



3. **Optional step:** If necessary, remove one screw, and then separate the cover assembly.

**Figure 1-163** Remove the rear top cover (M855; 3 of 3)



## Left cover


Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).

### Remove the left cover


1. Remove two screws (callout 1).

**Figure 1-164** Remove the left cover (1 of 2)



2. Slide the cover away from the product to remove it.

**Figure 1-165** Remove the left cover (2 of 2)



## Right upper front cover (M855)

Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Hardware integration pocket (HIP) cover (M855). See [Hardware integration pocket \(HIP\) cover \(M855\) on page 97](#).
- Control panel (M855). See [Control panel assembly \(M855\) on page 47](#)
- Front top cover. See [Front top cover on page 115](#).


### Remove the right upper front cover (M855)


1. Remove one screw.

**Figure 1-166** Remove the right upper front cover (M855; 1 of 2)




2. Release two tabs, and then rotate the cover away from the product to remove it.

 **NOTE:** Do not remove the USB cable from the cover. Release the cable from the product, and then remove it with the cover.

 **TIP:** Use the arrows embossed on the product to locate the tabs.

**Figure 1-167** Remove the right upper front cover (M855; 2 of 2)




## Right upper front cover (M880)

Before proceeding, remove the following assemblies:


- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Document feeder (M880). See [Document feeder assembly \(M880\) on page 154](#).
- Scanner assembly (M880). See [Scanner assembly \(M880\) on page 162](#).
- Front top cover. See [Front top cover on page 115](#).

### Remove the right upper front cover (M880)

1. Release two tabs, and then rotate the cover away from the product.


 **TIP:** Use the arrows embossed on the product to locate the tabs.

**Figure 1-168** Remove the right upper front cover (M880; 1 of 2)



2. Remove the cover.

**Figure 1-169** Remove the right upper front cover (M880; 2 of 2)



## Right upper cover (M855)

Before proceeding, remove the following assemblies:

- Optional: Switch back tray. See [Switch back tray on page 22](#).
- Control panel (M855). See [Control panel assembly \(M855\) on page 47](#)
- Right upper rear cover (M855). See [Right upper rear cover \(M855\) on page 96](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Switch back cover. See [Switch back cover on page 105](#).
- Front top cover. See [Front top cover on page 115](#).
- Rear top cover. See [Rear top cover \(M855\) on page 116](#).
- Right upper front cover (M855). See [Right upper front cover \(M855\) on page 120](#).


## Remove the right upper cover (M855)

1. Release the wire harnesses from the guide (callout 1), and then remove one screw (callout 2).




**NOTE:** Release the control panel cables from the guides as needed.

**Figure 1-170** Remove the right upper cover (M855; 1 of 9)




2. Open the front door, remove one screw (callout 1), release one tab (callout 2), and then remove the delivery fan cover (callout 3).

**Figure 1-171** Remove the right upper cover (M855; 2 of 9)



3. Remove one screw (callout 1), and then push up on the assembly to release two sheet-metal tabs (callout 2).

**Figure 1-172** Remove the right upper cover (M855; 3 of 9)




4. From the rear side of the product, remove two screws.

**Figure 1-173** Remove the right upper cover (M855; 4 of 9)



5. From the right-rear side of the product, release one tab.

**Figure 1-174** Remove the right upper cover (M855; 5 of 9)




6. Carefully remove the cover assembly.

**CAUTION:** Release the control panel cables from the guides as needed to remove the assembly. Make sure that the control-panel cables are correctly routed and are not pinched when the assembly is reinstalled.


**NOTE:** The cover is still attached to a sheet-metal bracket.

**Figure 1-175** Remove the right upper cover (M855; 6 of 9)




7. **Optional step:** To remove the cover from the sheet-metal bracket, remove two screws.

**Figure 1-176** Remove the right upper cover (M855; 7 of 9)




8. **Optional step:** To remove the cover from the sheet-metal bracket, before proceeding, note the location of the six tabs that secure the right upper cover to the assembly.

**Figure 1-177** Remove the right upper cover (M855; 8 of 9)



9. **Optional step:** To remove the cover from the sheet-metal bracket, release three tabs (callout 1), release three additional tabs (callout 2), and then separate the cover from the assembly.

**Figure 1-178** Remove the right upper cover (M855; 9 of 9)



## Right door assembly


Before proceeding, remove the following assemblies:

- Switch back cover. See [Switch back cover on page 105](#).

### Remove the right door assembly


1. Open the right door, and then remove one screw (callout 1).

**Figure 1-179** Remove the right door assembly (1 of 7)




2. Slide the retainer arm and guide (callout 1) to the left to disengage it from the product.

**Figure 1-180** Remove the right door assembly (2 of 7)




3. On the door assembly, remove two self-tapping screws (callout 1), release two tabs (callout 2), and then remove the motor cover (callout 3).


**Figure 1-181** Remove the right door assembly (3 of 7)




4. Release the wire harness from the retainer (callout 1), disconnect three connectors (callout 2), and then release one wire tie (callout 3).

 **TIP:** To release the wire tie (callout 3), push in on the tab, and then remove the wire tie from the door.


**Figure 1-182** Remove the right door assembly (4 of 7)



5. Disconnect one connector (callout 1), and then release one wire tie (callout 2).


 **TIP:** To release the wire tie (callout 2), push in on the tab, and then remove the wire tie from the door.

**Figure 1-183** Remove the right door assembly (5 of 7)




6. Remove one screw (callout 1), and then release the wire harness from the retainer (callout 2).

**Figure 1-184** Remove the right door assembly (6 of 7)



7. Carefully lift up the door assembly to remove it.


**Figure 1-185** Remove the right door assembly (7 of 7)



### Reinstall the right door assembly

When reinstalling the retainer arm, make sure that the tabs on the arm (callout 1) are installed in the slots in the product (callout 2).

**Figure 1-186** Reinstall the right door assembly



## Left front cover

Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Front top cover. See [Front top cover on page 115](#).
- Left cover. See [Left cover on page 118](#).

### Remove the left front cover


1. Open the front door
2. At the left side of the door, rotate the end of the retaining strap until it aligns with the hole in the bracket, and then push the strap through the hole to release it.

**Figure 1-187** Remove the left front cover (1 of 5)



3. Remove two screws.

**Figure 1-188** Remove the left front cover (2 of 5)



4. At the front of the product near the power switch, remove one screw.

**Figure 1-189** Remove the left front cover (3 of 5)




5. At the top of the product, remove one screw (callout 1), and then release one tab (callout 2).


**Figure 1-190** Remove the left front cover (4 of 5)



6. Rotate the edge of the cover near the front door away from the product to release three tabs, and then remove the cover.

 **NOTE:** The front door must be open to remove the cover.


**Figure 1-191** Remove the left front cover (5 of 5)



## Install a replacement left front cover

If a replacement cover is installed, release two tabs on each side of the clip (callout 1), and then remove the retaining strap (callout 2) from the discarded cover and install it on the replacement cover.

**Figure 1-192** Install a replacement left front cover



## Front door


1. Open the front door
2. At the left side of the door, rotate the end of the retaining strap until it aligns with the hole in the bracket, and then push the strap through the hole to release it.

**Figure 1-193** Remove the front door (1 of 9)




3. Remove two screws that fasten the two plastic rails to the door.


**Figure 1-194** Remove the front door (2 of 9)



4. Use a small flat blade screwdriver to release a tab (callout 1), slightly raise the plastic rail (callout 2), and then slide the rail to the right (callout 3) to release and remove it.


 **NOTE:** Repeat this step for the remaining rail.

**Figure 1-195** Remove the front door (3 of 9)




5. At the right side of the door, remove two screws.

**Figure 1-196** Remove the front door (4 of 9)



6. Support the interlock-switch arm (callout 1), and then remove the switch lever (callout 2).


**Figure 1-197** Remove the front door (5 of 9)



7. Slide the interlock-switch arm to the right to release it.

**⚠ CAUTION:** The interlock-switch arm is spring loaded. Firmly grasp the arm when it is removed to prevent it from retracting.


**Figure 1-198** Remove the front door (6 of 9)



8. At the right side of the door, remove two screws.

 **NOTE:** Support the door.


**Figure 1-199** Remove the front door (7 of 9)



9. At the left side of the door, remove two screws.


 **NOTE:** Support the door.

**Figure 1-200** Remove the front door (8 of 9)



10. Raise the door until it is about one-half of the way open (callout 1), push down on the door (callout 2) to release it, and then remove the door.


**Figure 1-201** Remove the front door (9 of 9)



### Reinstall the front door


1. When reinstalling the door, make sure that the pins (callout 1) on the door are positioned in the slots (callout 2) on the product.

**Figure 1-202** Reinstall the front door (1 of 2)



2. When reinstalling the rails, make sure that the pin (callout 1) on the inner door is positioned inside the slot (callout 2) on the rail before reinstalling the screws.

**Figure 1-203** Reinstall the front door (2 of 2)



## Rear cover


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).

### Remove the rear cover


1. Remove two screws.

**Figure 1-204** Remove the rear cover (1 of 3)




2. **M880 only:** Remove three screws.

**Figure 1-205** Remove the rear cover (2 of 3)



3. Remove twelve screws, and then remove the cover.


**Figure 1-206** Remove the rear cover (3 of 3)



### Install a replacement rear cover

If a replacement cover is installed, remove the fuser fan cover and the right rear cover, and then install them on the replacement cover.

1. Release three tabs, and then remove the fuser fan cover.


 **TIP:** Look for the arrows embossed on the cover to locate the tabs.

**Figure 1-207** Install a replacement rear cover (1 of 2)



2. Remove two screws, and then separate the right rear cover from the rear cover.

**Figure 1-208** Install a replacement rear cover (2 of 2)



## Right rear cover


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the right rear cover

1. Remove two screws, and then separate the right rear cover from the rear cover.

**Figure 1-209** Remove the right rear cover (1 of 2)



2. **Optional step:** If necessary, remove one screw, and then separate the small upper cover from the right rear cover.

**Figure 1-210** Remove the right rear cover (2 of 2)



## Front inner cover


Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Front top cover. See [Front top cover on page 115](#).
- Left cover. See [Left cover on page 118](#).
- Left front cover. See [Left front cover on page 133](#).
- Front door assembly. See [Front door on page 137](#).

### Remove the front inner cover


1. Remove eight screws.

**Figure 1-211** Remove the front inner cover (1 of 2)



2. Release two tabs, and then remove the front inner cover.


**Figure 1-212** Remove the front inner cover (2 of 2)



### Reinstall the front inner cover

Make sure that the tabs (callout 1) on the cover are inserted in the slots (callout 2) in the product.

**Figure 1-213** Reinstall the front inner cover



# Main assemblies



**TIP:** For clarity, some figures in this chapter show assemblies removed that are not required to be removed to service the product (for example, the scanner and document feeder assemblies). The procedures in this manual are correct for your product.

---

- [Location of major components](#)
- [Document feeder assembly \(M880\)](#)
- [Scanner control board \(SCB\) \(M880\)](#)
- [Scanner assembly \(M880\)](#)
- [Interlock switch assembly](#)
- [Front-door open detection switch](#)
- [Main switch assembly](#)
- [Secondary transfer assembly](#)
- [Multipurpose tray \(Tray 1\) drive assembly](#)
- [Multipurpose tray \(Tray 1\) guide assembly](#)
- [Tray 2 pickup unit](#)
- [Fuser home position sensor](#)
- [Shutter gear holder assembly](#)
- [Fuser-edge area cooling fan FM10 \(front\)](#)
- [Fuser-edge area cooling fan FM9 \(rear\)](#)
- [Fuser fan FM2](#)
- [Fuser fan duct](#)
- [Cartridge fan FM3 \(yellow and magenta\)](#)
- [Cartridge fan FM4 \(cyan and black\)](#)
- [Laser/scanner fan FM1](#)
- [Delivery fan FM8](#)
- [Cartridge front area cooling fan FM7](#)
- [Memory tag PCA](#)
- [Image-drum motor](#)
- [Fuser power supply](#)
- [Primary transfer-roller disengagement motor](#)
- [Intermediate transfer belt \(ITB\) alienation-drive assembly](#)
- [Fuser motor](#)

- [Intermediate transfer belt \(ITB\) motor](#)
- [Toner-cartridge feed motor \(black\)](#)
- [Toner-cartridge feed motor \(yellow, magenta, and cyan\)](#)
- [Environmental sensor](#)
- [Interconnect PCA \(M855\)](#)
- [Interconnect PCA \(M880\)](#)
- [Formatter case](#)
- [Formatter, formatter case, and interconnect board \(ICB\)](#)
- [High-voltage power supply \(HVPS\) B](#)
- [DC controller PCA](#)
- [Color-plane registration \(CPR\) sensor assembly](#)
- [Low-voltage power supply \(LVPS\)](#)
- [High-voltage power supply \(HVPS\) A \(first transfer\)](#)
- [Lifter-drive assembly](#)
- [Toner-cartridge drive assembly \(yellow and magenta\)](#)
- [Toner-cartridge drive assembly \(cyan and black\)](#)
- [Cartridge interface PCA \(cyan and black\)](#)
- [Cartridge interface PCA \(yellow and magenta\)](#)
- [Main drive assembly](#)
- [Replace or reinstall the toner-cartridge drive assemblies or the main drive assembly](#)
- [Fuser drive assembly](#)
- [Scanner cover](#)
- [Laser/scanner assembly \(yellow and magenta\)](#)
- [Laser/scanner assembly \(cyan and black\)](#)
- [Duplex reverse assembly \(M855\)](#)
- [Duplex reverse assembly \(M880\)](#)
- [VOC fan \(M855\)](#)
- [VOC fan \(M880\)](#)
- [Face-down delivery assembly\(M855\)](#)
- [Face-down delivery assembly \(M880\)](#)
- [Face-down cover](#)

- [Duplexing feed assembly](#)
- [Multipurpose tray \(Tray 1\) pickup assembly](#)

# Location of major components

Figure 1-214 Base product main assemblies (1 of 2)




Table 1-9 Base product main assemblies (1 of 2)

Item	Description	Item	Description
1	Face-down delivery assembly	7	Fuser drive assembly
2	Low-voltage power supply (LVPS)	8	ITB alienation drive assembly
3	Secondary transfer (T2) assembly	9	Fuser PCA
4	Multipurpose tray (Tray 1) drive assembly	10	Main drive assembly
5	Toner cartridge drive assembly (C/K)	11	Shutter gear holder assembly
6	Toner cartridge drive assembly (Y/M)		

Figure 1-215 Base product main assemblies (2 of 2)




Table 1-10 Base product main assemblies (2 of 2)

Item	Description	Item	Description
1	Duplex reverse assembly	4	Fuser home position sensor assembly
2	Duplexing feed assembly (assembly is attached to the right door)	5	Color-plane registration (CPR) sensor assembly
3	Multipurpose tray (Tray 1) pickup assembly (assembly is attached to the right door)		

## Document feeder assembly (M880)

Before proceeding, remove the following assemblies:

- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).


### Remove the document feeder assembly (M880)




**IMPORTANT:** If you are installing a replacement ADF assembly, you must use the [Service](#) menu to set the [Document feeder Kit Interval](#) and [ADF Count](#) values to zero. See [Reinstall the document feeder assembly \(M880\) on page 159](#).

1. Disconnect two connectors (callout 1), and one flat cable (callout 2).


**Figure 1-216** Remove the document feeder assembly (M880; 1 of 9)



2. Remove one screw (callout 1) and the retainer.


 **NOTE:** The screw (callout 1) that secures the wire retainer is longer than other screws used in the product. Make sure that you use this screw when the retainer is reinstalled.

**Figure 1-217** Remove the document feeder assembly (M880; 2 of 9)




3. Remove one screw (callout 1) to release one ground wire.


**Figure 1-218** Remove the document feeder assembly (M880; 3 of 9)




4. Remove two screws (callout 1) to release the document feeder hinges.

 **NOTE:** These screws (callout 1) are longer than other screws used in the product. Make sure that you use these screws when the document feeder assembly is reinstalled.


**Figure 1-219** Remove the document feeder assembly (M880; 4 of 9)



5. Carefully push the document feeder wire harness and flat cable up through the opening in the scanner bezel.


 **Reinstallation tip** When the document feeder is reinstalled, make sure that the wire harness and flat cable are behind the scanner bezel, or the scanner back cover will not fit properly.

**Figure 1-220** Remove the document feeder assembly (M880; 5 of 9)



6. Raise the document feeder to the open position.

**Figure 1-221** Remove the document feeder assembly (M880; 6 of 9)




7. Lift the document feeder up until it stops.

**Figure 1-222** Remove the document feeder assembly (M880; 7 of 9)




8. Tilt the assembly towards the rear of the product to release the hinges.

**Figure 1-223** Remove the document feeder assembly (M880; 8 of 9)





9. Lift the assembly up and off of the product.

**Figure 1-224** Remove the document feeder assembly (M880; 9 of 9)



## Reinstall the document feeder assembly (M880)

 **IMPORTANT:** If a replacement document feeder is installed, you must follow the instructions below to reset the counter. Failure to follow these instructions might result in more frequent paper jams.

 **NOTE:** If a replacement document feeder or scanner assembly is installed, you must install a replacement white backing on the document feeder. See [Document feeder white backing \(M880\) on page 39](#).

### Installing a replacement document feeder assembly

If a replacement document feeder is installed, do the following:

1. From the Home screen on the control panel, scroll to and touch the [Device Maintenance](#) button.
2. Open the [Service](#) menu.
3. On the sign-in screen, select the [Service Access Code](#) option from the drop-down list.
4. Enter the following service access code for this product: 11088013.
5. Reset the following values:
  - [Document Feeder Kit Interval](#); set to zero
  - [ADF Count](#); set to zero

## Scanner control board (SCB) (M880)

Before proceeding, remove the following assemblies:


- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).

### Remove the SCB (M880)

1. Disconnect four wire harness connectors (callout 1), one inline connector (callout 2), two flat cables (callout 3), and one USB connector (callout 4).


 **NOTE:** The scanner control board (SCB) fan connector does not need to be disconnected.

**Figure 1-225** Remove the SCB (M880; 1 of 4)




2. Release the wire harnesses from the retainer (callout 1).

**Figure 1-226** Remove the SCB (M880; 2 of 4)




3. Remove two screws (callout 1).


**Figure 1-227** Remove the SCB (M880; 3 of 4)



4. Carefully remove the SCB.

 **Reinstallation tip** If you are installing a replacement SCB, make sure to remove the protective cover from the USB connector (callout 1) on the replacement SCB before installing it in the product.

**Figure 1-228** Remove the SCB (M880; 4 of 4)



## Scanner assembly (M880)

**⚠ WARNING!** The scanner assembly weighs approximately 26.3 kg (58.0 lbs). HP recommends that two people lift the assembly off of the product.

Before proceeding, remove the following assemblies:


- Control panel assembly (M880). See [Control panel assembly \(M880\) on page 53](#).
- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).
- Document feeder assembly (M880). See [Document feeder assembly \(M880\) on page 154](#).
- Scanner control board (M880). See [Scanner control board \(SCB\) \(M880\) on page 160](#).
- Rear upper MFP cover (M880). See [Rear upper MFP cover \(M880\) on page 109](#).
- Rear upper rear cover (M880). See [Rear upper rear cover \(M880\) on page 107](#).
- Right upper rear cover (M880). See [Right upper rear cover \(M880\) on page 108](#).

## Remove the scanner assembly (M880)

**🔧 IMPORTANT:** If you are installing a replacement scanner assembly, you must use the [Service](#) menu to set the [Flatbed Count](#) value to zero. See [Reinstall the scanner assembly \(M880\) on page 166](#).


1. At the rear of the product, release the wire harness (callout 1) from the retainer (callout 2).

**Figure 1-229** Remove the scanner assembly (M880; 1 of 7)




2. Remove four screws (callout 1).

**Figure 1-230** Remove the scanner assembly (M880; 2 of 7)




3. At the front of the product (where the control panel was removed), release one tab (callout 1), and then separate the wire guide from the product (callout 2).

**Figure 1-231** Remove the scanner assembly (M880; 3 of 7)




4. Release the USB cable and wire harness (callout 1) from the guide (callout 2), and then remove the guide.

**Figure 1-232** Remove the scanner assembly (M880; 4 of 7)



5. Remove three screws (callout 1).

**Figure 1-233** Remove the scanner assembly (M880; 5 of 7)



6. Carefully place the USB cable and wire harness in the cavity below the control panel mounting bracket to keep them out of the way when the scanner is removed.


**Figure 1-234** Remove the scanner assembly (M880; 6 of 7)



7. Carefully lift the scanner assembly up and off of the product.

**⚠ WARNING!** The scanner assembly weighs approximately 26.3 kg (58.0 lbs). HP recommends that two people lift the assembly off of the product.

**Figure 1-235** Remove the scanner assembly (M880; 7 of 7)



## Reinstall the scanner assembly (M880)



**IMPORTANT:** If a replacement scanner assembly is installed, you must follow the instructions below to reset the counter. Failure to follow these instructions might result in more frequent paper jams.



**NOTE:** If a replacement document feeder or scanner assembly is installed, you must install a replacement white backing on the document feeder. See [Document feeder white backing \(M880\) on page 39](#).

### Installing a replacement scanner assembly

If a replacement scanner assembly is installed, do the following:

1. From the Home screen on the control panel, scroll to and touch the [Device Maintenance](#) button.
2. Open the [Service](#) menu.
3. On the sign-in screen, select the [Service Access Code](#) option from the drop-down list.
4. Enter the following service access code for this product: 11088013.
5. Reset the following value:
  - [Flatbed Count](#); set to zero

## Interlock switch assembly

Before proceeding, remove the following assemblies:


- Front door. See [Front door on page 137](#).
- Front inner cover. See [Front inner cover on page 147](#).

### Remove the interlock switch assembly

If the toner cartridges have not already been removed for servicing the product, remove them now.


1. Disconnect two connectors (callout 1), remove one screw (callout 2), and then remove the interlock switch assembly (callout 3).

**Figure 1-236** Remove the interlock switch assembly (1 of 2)



2. Release the wire harness from the retainer (callout 1), release two tabs (callout 2), and then remove the right-door open detection switch (callout 3) from the assembly.

**Figure 1-237** Remove the interlock switch assembly (2 of 2)




## Front-door open detection switch

Before proceeding, remove the following assemblies:


- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Front top cover. See [Front top cover on page 115](#).
- Left cover. See [Left cover on page 118](#).
- Left front cover. See [Left front cover on page 133](#).

### Remove the front-door open detection switch

1. Carefully release the flag from the holders to remove it.


 **Reinstallation tip** Note how the spring at the right end of the flag shaft is installed. If the spring becomes dislodged while removing the flag, you must correctly reinstall it so that the flag will properly function. See [Reinstall the front-door-open detection switch on page 171](#).

**Figure 1-238** Remove the front-door open detection switch (1 of 4)




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

**Figure 1-239** Remove the front-door open detection switch (2 of 4)




3. Release one tab (callout 1), and then remove the switch holder (callout 2).

**Figure 1-240** Remove the front-door open detection switch (3 of 4)



4. Release two tabs (callout 1), and then remove the front-door open detection switch (callout 2) from the assembly.


**Figure 1-241** Remove the front-door open detection switch (4 of 4)



### Reinstall the front-door-open detection switch


1. When the flag is reinstalled, make sure that the lower end of the spring is behind the holder.

**Figure 1-242** Reinstall the front-door-open detection switch (1 of 3)




2. When the flag is reinstalled, make sure that the top end of the spring is correctly seated on the flag.

**Figure 1-243** Reinstall the front-door-open detection switch (2 of 3)



3. Verify that the switch (callout 1) moves to the up position when the flag is toggled to the door closed position (callout 2).

**Figure 1-244** Reinstall the front-door-open detection switch (3 of 3)



## Main switch assembly

Before proceeding, remove the following assemblies:


- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Front top cover. See [Front top cover on page 115](#).
- Left cover. See [Left cover on page 118](#).
- Left front cover. See [Left front cover on page 133](#).
- Front door assembly. See [Front door on page 137](#).
- Front inner cover. See [Front inner cover on page 147](#).

### Remove the main switch assembly


If the toner cartridges have not already been removed for servicing the product, remove them now.

1. Release the wire harness from one retainer (callout 1), and then from the guide (callout 2).


**Figure 1-245** Remove the main switch assembly (1 of 3)



2. Release the wire harness from one guide (callout 1), and then disconnect one connector (callout 2).


 **TIP:** It is easier to disconnect the connector if the harness is first released from the guide.

**Figure 1-246** Remove the main switch assembly (2 of 3)



3. Remove one screw (callout 1), release one tab (callout 2), and then slide the switch assembly upward (callout 3) to remove it.

**Figure 1-247** Remove the main switch assembly (3 of 3)



## Secondary transfer assembly


Before proceeding, remove the following assemblies:

- Secondary transfer roller. See [Secondary transfer roller on page 16](#)
- Intermediate transfer belt. See [Intermediate transfer belt \(ITB\) on page 19](#).

### Remove the secondary transfer assembly


1. Open the right door to access the assemblies in the following steps.
2. Release two tabs (callout 1), and then lift up (callout 2) to remove the right ITB guide (callout 3).

**Figure 1-248** Remove the secondary transfer assembly (1 of 10)




3. Remove one screw (callout 1), release one tab (callout 2), and then remove the left ITB guide (callout 3).


**Figure 1-249** Remove the secondary transfer assembly (2 of 10)



4. Grasp the connector cover (callout 1), and then remove the cover by lifting up while releasing the tab (callout 2).


 **TIP:** Use the arrow embossed on the cover to locate the tab.

**Figure 1-250** Remove the secondary transfer assembly (3 of 10)




5. Push in on the red mark on the connector (callout 1), and then disconnect the connector.

**Figure 1-251** Remove the secondary transfer assembly (4 of 10)




6. Release the wire harness from two cable retainers (callout 1).

**Figure 1-252** Remove the secondary transfer assembly (5 of 10)




7. Disconnect one connector (callout 1).

**Figure 1-253** Remove the secondary transfer assembly (6 of 10)





8. Remove one white plastic retainer (callout 1).

**Figure 1-254** Remove the secondary transfer assembly (7 of 10)




9. Use a small flat-blade screwdriver to slide one black-plastic bushing away from the chassis (callout 1).


 **TIP:** After the assembly is removed later in this procedure, use the clip removed in the step above to secure the bushing to the shaft so it will not be lost.




**Figure 1-255** Remove the secondary transfer assembly (8 of 10)




10. Press down on the black handle (callout 1), and then Insert a screwdriver into the hole (callout 2) on the Multipurpose tray (Tray 1) drive assembly to hold the black handle in place.

 **TIP:** Using this method to hold the black handle in place will allow you to use both hands to remove the assembly, and will also make reinstalling the assembly easier.


**Figure 1-256** Remove the secondary transfer assembly (9 of 10)



11. Carefully press the feed guide (callout 1) toward the back of the product. Grasp the secondary transfer assembly and slide it toward the left (callout 2) to release the shaft (callout 3), and then remove the assembly.


 **NOTE:** Handle the assembly carefully. The registration assembly tension springs and spring mounting blocks at each end of the secondary transfer assembly can be easily dislodged. See [Figure 1-258 Reinstall the secondary transfer assembly \(1 of 3\) on page 181](#).

**Figure 1-257** Remove the secondary transfer assembly (10 of 10)




## Reinstall the secondary transfer assembly


1. Before reinstalling the secondary transfer assembly, make sure that the registration assembly tension springs (callout 1) and spring mounting blocks (callout 2) at each end of the secondary transfer assembly are correctly positioned.

 **NOTE:** The springs should be straight (as shown below), and not bent or curved.


**Figure 1-258** Reinstall the secondary transfer assembly (1 of 3)




2. Carefully turn the assembly over, and then make sure that the tabs on the spring mounting blocks are fully seated in the assembly sheet metal.

 **NOTE:** If the secondary transfer assembly is removed or replaced while servicing the product and a **13.B2.DD** error message appears on the control-panel display, remove the assembly and make sure that the registration tension springs and spring mounting blocks are correctly installed.



**Figure 1-259** Reinstall the secondary transfer assembly (2 of 3)



3. When the secondary transfer assembly is reinstalled, make sure that the gear assembly (callout 1) is placed under the ITB rail (callout 2).

 **NOTE:** To make reinstalling the assembly easier, insert a screwdriver into the hole on the Multipurpose tray (Tray 1) drive assembly to hold the black handle in place. See [Figure 1-256 Remove the secondary transfer assembly \(9 of 10\) on page 180](#).

**Figure 1-260** Reinstall the secondary transfer assembly (3 of 3)



## Multipurpose tray (Tray 1) drive assembly

Before proceeding, remove the following assemblies:

- Intermediate transfer belt (ITB). See [Intermediate transfer belt \(ITB\) on page 19](#).
- Fuser. See [Fuser on page 21](#).
- Secondary transfer assembly. See [Secondary transfer assembly on page 175](#).

### Remove the multipurpose tray (Tray 1) drive assembly

1. At the right side of the product, near the lower right corner of the right door, remove one small cover (callout 1).

**Figure 1-261** Remove the multipurpose tray (Tray 1) drive assembly (1 of 13)




2. Remove one screw (callout 1).

**Figure 1-262** Remove the multipurpose tray (Tray 1) drive assembly (2 of 13)



3. Open the right door, remove one screw (callout 1), and then remove the handle (callout 2).


**Figure 1-263** Remove the multipurpose tray (Tray 1) drive assembly (3 of 13)



4. Press down on the black handle (callout 1) to release it, and then pull it forward to remove it.


 **NOTE:** The handle is spring loaded. Firmly grasp the handle when it is removed.

**Figure 1-264** Remove the multipurpose tray (Tray 1) drive assembly (4 of 13)




5. Open the right door, and then remove one screw (callout 1).

**Figure 1-265** Remove the multipurpose tray (Tray 1) drive assembly (5 of 13)




6. Slide the retainer arm and guide (callout 1) to the left to disengage it from the chassis.

**Figure 1-266** Remove the multipurpose tray (Tray 1) drive assembly (6 of 13)




7. Remove two screws (callout 1), and then remove the right-inner cover (callout 2).

**Figure 1-267** Remove the multipurpose tray (Tray 1) drive assembly (7 of 13)




8. On the door assembly, remove two self-tapping screws (callout 1), release two tabs (callout 2), and then remove the motor cover (callout 3).


**Figure 1-268** Remove the multipurpose tray (Tray 1) drive assembly (8 of 13)



9. Disconnect one connector (callout 1), and then release one wire tie (callout 2).


 **TIP:** To release the wire tie (callout 2), push in on the tab, and then remove the wire tie from the door.

**Figure 1-269** Remove the multipurpose tray (Tray 1) drive assembly (9 of 13)




10. Remove one screw (callout 1), and then disconnect one connector (callout 2).


**Figure 1-270** Remove the multipurpose tray (Tray 1) drive assembly (10 of 13)



11. Release one wire tie (callout 1).


 **TIP:** To release the wire tie, push in on the tab, and then remove the wire tie from the chassis.

**Figure 1-271** Remove the multipurpose tray (Tray 1) drive assembly (11 of 13)




12. Remove two screws (callout 1).

**Figure 1-272** Remove the multipurpose tray (Tray 1) drive assembly (12 of 13)



13. Use a small flat-blade screwdriver (callout 1) to carefully release the assembly and two sheet-metal tabs (callout 2), and then remove the assembly (callout 3).

**Figure 1-273** Remove the multipurpose tray (Tray 1) drive assembly (13 of 13)



## Multipurpose tray (Tray 1) guide assembly

Before proceeding, remove the following assemblies:

- Secondary transfer roller. See [Secondary transfer roller on page 16](#)
- Intermediate transfer belt. See [Intermediate transfer belt \(ITB\) on page 19](#).
- Fuser. See [Fuser on page 21](#).
- Secondary transfer assembly. See [Secondary transfer assembly on page 175](#).
- Multipurpose tray (Tray 1) drive assembly. See [Multipurpose tray \(Tray 1\) drive assembly on page 183](#).


### Remove the multipurpose tray guide assembly

Disconnect one connector (callout 1), release one wire retainer (callout 2), remove two screws (callout 3), and then remove the multipurpose-tray guide (Tray 1) assembly.



**Reinstallation tip** Make sure that the connector (callout 1) is securely in place when the assembly is reinstalled.

**Figure 1-274** Remove the multipurpose tray guide assembly



## Tray 2 pickup unit


Before proceeding, remove the following assemblies:

- Secondary transfer roller. See [Secondary transfer roller on page 16](#)
- Tray 2. See [Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 on page 18](#).
- Intermediate transfer belt. See [Intermediate transfer belt \(ITB\) on page 19](#).
- Fuser. See [Fuser on page 21](#).
- Secondary transfer assembly. See [Secondary transfer assembly on page 175](#).
- Multipurpose tray (Tray 1) drive assembly. See [Multipurpose tray \(Tray 1\) drive assembly on page 183](#).
- Multipurpose tray (Tray 1) guide assembly. See [Multipurpose tray \(Tray 1\) guide assembly on page 190](#).

### Remove the Tray 2 pickup assembly

Disconnect one connector (callout 1), remove four screws (callout 2), and then remove the Tray 2 pickup assembly (callout 3).

**Figure 1-275** Remove the Tray 2 pickup assembly



## Fuser home position sensor


Before proceeding, remove the following assemblies:

- Fuser. See [Fuser on page 21](#).

### Remove the fuser home position sensor


1. Open the front door, remove one screw (callout 1), release one tab (callout 2), and then remove the delivery fan cover (callout 3).

**Figure 1-276** Remove the fuser home position sensor (1 of 3)



2. Disconnect one connector (callout 1).


**Figure 1-277** Remove the fuser home position sensor (2 of 3)



3. Open the right door, remove one screw (callout 1), release one tab (callout 2), and then remove the sensor assembly (callout 3).

**CAUTION:** As the assembly is removed, guide the wire harness through the opening in the chassis from the front of the product.


**Figure 1-278** Remove the fuser home position sensor (3 of 3)



### Reinstall the fuser home position sensor

As the assembly is reinstalled, guide the wire harness through the opening in the chassis to the front of the product, and then make sure that the tab on the sensor (callout 1) is installed in the opening (callout 2) in the chassis.

**Figure 1-279** Reinstall the fuser home position sensor



## Shutter gear holder assembly


Before proceeding, remove the following assemblies:

- Fuser. See [Fuser on page 21](#).

### Remove the shutter gear holder assembly


1. Open the right door, remove one screw (callout 1), and then remove one gear (callout 2).

**Figure 1-280** Remove the shutter gear holder assembly (1 of 5)




2. Slide the left shutter toward the back of the product to remove it.

**Figure 1-281** Remove the shutter gear holder assembly (2 of 5)



3. Slide the right shutter toward the front of the product to remove it.


**Figure 1-282** Remove the shutter gear holder assembly (3 of 5)



4. Remove one gear (callout 1), remove two screws (callout 2), and then separate the gear assembly (callout 3) from the chassis.


**CAUTION:** The assembly is still connected to the product by a wire harness. Do not attempt to completely remove the assembly.

**Figure 1-283** Remove the shutter gear holder assembly (4 of 5)



5. Disconnect two connectors.


**Figure 1-284** Remove the shutter gear holder assembly (5 of 5)



### Reinstall the shutter gear holder assembly


1. Align the round tabs (callout 1) on the back of the shutter gear holder assembly with the slots (callout 2) in the chassis.

**Figure 1-285** Reinstall the shutter gear holder assembly (1 of 6)



2. Note the location of the guides on the back of the shutters.

**Figure 1-286** Reinstall the shutter gear holder assembly (2 of 6)




3. Make sure that the guides (callout 1) on the shutters align with the rails (callout 2) so that they slide freely.




**NOTE:** The left shutter is shown below. The procedure is the same for the right shutter.

**Figure 1-287** Reinstall the shutter gear holder assembly (3 of 6)




4. When the white gear (callout 1) is reinstalled, position the gear back in the assembly so that the teeth on the white gear align with the teeth on the smaller gear (callout 2).

**Figure 1-288** Reinstall the shutter gear holder assembly (4 of 6)




5. When replacing the black gear, make sure that the teeth on the black gear align with the teeth on the white gear (callout 1). Also make sure that the teeth on the shutters (callout 2) align with the teeth on the black gear.

**Figure 1-289** Reinstall the shutter gear holder assembly (5 of 6)



6. Make sure that the arrows on the shutters align with the notches in the gear.

**Figure 1-290** Reinstall the shutter gear holder assembly (6 of 6)



## Fuser-edge area cooling fan FM10 (front)


Before proceeding, remove the following assemblies:

- Fuser. See [Fuser on page 21](#).
- Shutter gear holder assembly. See [Shutter gear holder assembly on page 194](#).

### Remove the fuser-edge area cooling fan FM10 (front)


1. Release the wire harness from one retainer (callout 1), disconnect one connector (callout 2), and then remove two screws (callout 3).

**Figure 1-291** Remove the fuser-edge area cooling fan FM10 (front; 1 of 3)




2. Rotate the top of the fan away from the chassis (callout 1), and then lift it up and away from the product (callout 2) to remove it.

**Figure 1-292** Remove the fuser-edge area cooling fan FM10 (front; 2 of 3)




3. To remove the fan from the holder, release one tab (callout 1) and then rotate the top of the fan (callout 2) out of the holder to remove it.

**Figure 1-293** Remove the fuser-edge area cooling fan FM10 (front; 3 of 3)




## Reinstall the fuser-edge area cooling fan FM10 (front)

1. Make sure that the fan is oriented as shown below when reinstalling it in the holder.


 **NOTE:** The label in the center of the fan should be facing inward, toward the holder.

**Figure 1-294** Reinstall the fuser-edge area cooling fan FM10 (front; 1 of 3)




2. The embossed arrows on the fan must point into the chassis and to the left (toward the wire harness) when the fan and holder are installed in the product.

**Figure 1-295** Reinstall the fuser-edge area cooling fan FM10 (front; 2 of 3)



3. When reinstalling the fan, make sure that the tab is installed first and that it fits behind the sheet metal (callout 1).

**Figure 1-296** Reinstall the fuser-edge area cooling fan FM10 (front; 3 of 3)



## Fuser-edge area cooling fan FM9 (rear)


Before proceeding, remove the following assemblies:

- Fuser. See [Fuser on page 21](#).
- Shutter gear holder assembly. See [Shutter gear holder assembly on page 194](#).

### Remove the fuser-edge area cooling fan FM9 (rear)


1. Release the wire harness from one retainer (callout 1), disconnect one connector (callout 2), and then remove two screws (callout 3).

**Figure 1-297** Remove the fuser-edge area cooling fan FM9 (rear; 1 of 3)




2. Rotate the top of the fan away from the chassis (callout 1), and then lift it up and away from the product (callout 2) to remove it.

**Figure 1-298** Remove the Remove the fuser-edge area cooling fan FM9 (rear; 2 of 3)



3. To remove the fan from the holder, release one tab (callout 1) and then rotate the top of the fan out of the holder (callout 2) to remove it.

**Figure 1-299** Remove the fuser-edge area cooling fan FM9 (rear; 3 of 3)




### Reinstall the fuser-edge area cooling fan FM9 (rear)

1. Make sure that the fan is oriented as shown below when reinstalling it in the holder.




**NOTE:** The label in the center of the fan should be facing inward, toward the holder.

**Figure 1-300** Reinstall the fuser-edge area cooling fan FM9 (rear; 1 of 3)




2. The embossed arrows on the fan must point into the chassis and to the left (away from the wire harness) when the fan and holder are installed in the product.

**Figure 1-301** Reinstall the fuser-edge area cooling fan FM9 (rear; 2 of 3)



3. When reinstalling the left fuser cooling fan, make sure that the tab is installed first and that it fits behind the sheet metal (callout 1).

**Figure 1-302** Reinstall the fuser-edge area cooling fan FM9 (rear; 3 of 3)



## Fuser fan FM2


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the fuser fan FM2


1. Locate the fuser fan (callout 1).

**Figure 1-303** Remove the fuser fan FM2 (1 of 5)




2. Release the wire harness (callout 1) from the guides (callout 2).

**Figure 1-304** Remove the fuser fan FM2 (2 of 5)




3. Disconnect one connector (callout 1), and then rotate the fan assembly out and down (callout 2) to remove it.

**Figure 1-305** Remove the fuser fan FM2 (3 of 5)




4. Disconnect one connector (callout 1) on the fan holder, and then release the wire harness (callout 2) from the guides.

**Figure 1-306** Remove the fuser fan FM2 (4 of 5)



5. Release three tabs (callout 1), and then rotate the fuser fan (callout 2) out of the fan holder.

**Figure 1-307** Remove the fuser fan FM2 (5 of 5)




## Reinstall the fuser fan FM2

1. Make sure that the fan is oriented as shown below when reinstalling it in the holder.




**NOTE:** The label in the center of the fan should be facing inward, toward the holder.

**Figure 1-308** Reinstall the fuser fan FM2 (1 of 3)




2. The embossed arrows on the fan must point into the chassis and to the left (toward the wire harness) when the fan and holder are installed in the product.

**Figure 1-309** Reinstall the fuser fan FM2 (2 of 3)



3. When reinstalling the fuser fan assembly, make sure that the tabs (callout 1) on the holder are installed in the slots (callout 2) on the chassis.

**Figure 1-310** Reinstall the fuser fan FM2 (3 of 3)



## Fuser fan duct


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Fuser fan FM2. See [Fuser fan FM2 on page 207](#).
- Fuser motor. See [Fuser motor on page 242](#).

### Remove the fuser fan duct


1. Remove one screw (callout 1).

**Figure 1-311** Remove the fuser fan duct (1 of 3)




2. Release one tab (callout 1).

**Figure 1-312** Remove the fuser fan duct (2 of 3)



3. Rotate the top of the fuser fan duct away from the product to remove it.


**Figure 1-313** Remove the fuser fan duct (3 of 3)



## Reinstall the fuser fan duct

Insert the tab (callout 1) on the duct into the slot (callout 2) on the chassis before rotating the duct into position.

**Figure 1-314** Reinstall the fuser fan duct



## Cartridge fan FM3 (yellow and magenta)


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the cartridge fan FM3 (yellow and magenta)


1. Locate the cartridge fan (yellow and magenta; callout 1).

**Figure 1-315** Remove the cartridge fan FM3 (yellow and magenta; 1 of 5)




2. Disconnect one connector (callout 1), and then release the wire harnesses (callout 2) from the guides (callout 3).

**Figure 1-316** Remove the cartridge fan FM3 (yellow and magenta; 2 of 5)




3. Rotate the fan assembly to the right (callout 1), while pulling the assembly away from the product (callout 2) to remove it.

**Figure 1-317** Remove the cartridge fan FM3 (yellow and magenta; 3 of 5)




4. Disconnect one connector (callout 1) on the fan holder, and then release the wire harness (callout 2) from the guides.

**Figure 1-318** Remove the cartridge fan FM3 (yellow and magenta; 4 of 5)




5. Release three tabs (callout 1), and then rotate the fan (callout 2) out of the fan holder.

**Figure 1-319** Remove the cartridge fan FM3 (yellow and magenta; 5 of 5)




### Reinstall the cartridge fan FM3 (yellow and magenta)

1. Make sure that the fan is oriented as shown below when reinstalling it in the holder.


 **NOTE:** The label in the center of the fan should be facing outward, away from the holder.

**Figure 1-320** Reinstall the cartridge fan FM3 (yellow and magenta; 1 of 3)




2. The embossed arrows on the fan must point away from the chassis and to the left (toward the wire harness) when the fan and holder are installed in the product.

**Figure 1-321** Reinstall the cartridge fan FM3 (yellow and magenta; 2 of 3)



3. When reinstalling the cartridge fan (yellow and magenta) assembly, make sure that the tabs (callout 1) on the holder are installed in the slots (callout 2) on the product.

**Figure 1-322** Reinstall the cartridge fan FM3 (yellow and magenta; 3 of 3)



## Cartridge fan FM4 (cyan and black)


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the cartridge fan FM4 (cyan and black)


1. Locate the cartridge fan (cyan and black; callout 1).

**Figure 1-323** Remove the cartridge fan FM4 (cyan and black; 1 of 5)




2. Disconnect one connector (callout 1), and then release the wire harnesses (callout 2) from the guides (callout 3).

**Figure 1-324** Remove the cartridge fan FM4 (cyan and black; 2 of 5)




3. Rotate the fan assembly to the right (callout 1), while pulling the assembly away from the product (callout 2) to remove it.

**Figure 1-325** Remove the cartridge fan FM4 (cyan and black; 3 of 5)




4. Disconnect one connector (callout 1) on the fan holder, and then release the wire harness (callout 2) from the guides.

**Figure 1-326** Remove the cartridge fan FM4 (cyan and black; 4 of 5)




5. Release three tabs (callout 1), and then rotate the fan (callout 2) out of the fan holder.

**Figure 1-327** Remove the cartridge fan FM4 (cyan and black; 5 of 5)




### Reinstall the cartridge fan FM4 (cyan and black)

1. Make sure that the fan is oriented as shown below when reinstalling it in the holder.


 **NOTE:** The label in the center of the fan should be facing outward, away from the holder.

**Figure 1-328** Reinstall the cartridge fan FM4 (cyan and black; 1 of 2)




2. The embossed arrows on the fan must point away from the chassis and to the left (toward the wire harness) when the fan and holder are installed in the product.

**Figure 1-329** Reinstall the cartridge fan FM4 (cyan and black; 2 of 3)



3. When reinstalling the cartridge fan (cyan and black) assembly, make sure that the tabs (callout 1) on the holder are installed in the slots (callout 2) on the chassis.

**Figure 1-330** Reinstall the cartridge fan FM4 (cyan and black; 3 of 3)



## Laser/scanner fan FM1


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the laser/scanner fan FM1


1. Locate the laser/scanner fan (callout 1).

**Figure 1-331** Remove the laser/scanner fan FM1 (1 of 4)




2. Release two locking tabs, and then disconnect one connector (callout 1). Release one tab (callout 2), and then rotate the fan assembly to the right (callout 3) to remove it.

**Figure 1-332** Remove the laser/scanner fan FM1 (2 of 4)




3. Disconnect one connector (callout 1) on the fan holder, and then release the wire harness (callout 2) from the guides.

**Figure 1-333** Remove the laser/scanner fan FM1 (3 of 4)




4. Release three tabs (callout 1), and then rotate the laser/scanner fan (callout 2) out of the fan holder.

**Figure 1-334** Remove the laser/scanner fan FM1 (4 of 4)




## Reinstall the laser/scanner fan FM1

1. Make sure that the fan is oriented as shown below when reinstalling it in the holder.


 **NOTE:** The label in the center of the fan should be facing inward, toward the holder.

**Figure 1-335** Reinstall the laser/scanner fan FM1 (1 of 3)




2. The embossed arrows on the fan must point into the chassis and to the left (toward the wire harness) when the fan and holder are installed in the product.

**Figure 1-336** Reinstall the laser/scanner fan FM1 (2 of 3)



3. When reinstalling the laser/scanner fan assembly, make sure that the tabs (callout 1) on the holder are installed in the slots (callout 2) on the chassis.


**Figure 1-337** Reinstall the laser/scanner fan FM1 (3 of 3)



## Delivery fan FM8


1. Open the front door.
2. Remove one screw (callout 1), release one tab (callout 2), and then remove the delivery fan cover (callout 3).

**Figure 1-338** Remove the delivery fan FM8 (1 of 3)




3. Disconnect one connector (callout 1), release the wire harness from the retainer (callout 2), remove three screws (callout 3), release one tab (callout 4), and then remove the delivery fan holder (callout 5).

**Figure 1-339** Remove the delivery fan FM8 (2 of 3)



4. Release the wire harness from the guide (callout 1), release one tab (callout 2), and then remove the fan (callout 3).

**Figure 1-340** Remove the delivery fan FM8 (3 of 3)



## Cartridge front area cooling fan FM7


Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Front top cover. See [Front top cover on page 115](#).
- Left front cover. See [Left front cover on page 133](#).

### Remove the cartridge front area cooling fan FM7


1. Disconnect one connector (callout 1), and then release the wire harness from the retainer (callout 2).

**Figure 1-341** Remove the cartridge front area cooling fan FM7 (1 of 2)



2. Remove three screws (callout 1), and then remove the fan (callout 2).


**Figure 1-342** Remove the cartridge front area cooling fan FM7 (2 of 2)



### Reinstall the cartridge front area cooling fan FM7

When the fan is reinstalled, make sure that the label (callout 1) on the fan is facing out and away from the chassis.

**Figure 1-343** Reinstall the cartridge front area cooling fan FM7



## Memory tag PCA

 **CAUTION:**  ESD sensitive assembly.


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the memory tag PCA


1. Disconnect two connectors (callout 1) on the motors above the memory tag PCA, and then disconnect 11 connectors (callout 2) on the memory tag PCA.

**Figure 1-344** Remove the memory tag PCA (1 of 3)




2. If you are removing the memory tag PCA to gain access to parts behind it, remove four screws (callout 1), and then remove the memory tag PCA and sheet-metal bracket.

**Figure 1-345** Remove the memory tag PCA (2 of 3)



3. If you are replacing the memory tag PCA, remove four screws (callout 1), and then remove the memory tag PCA.


**Figure 1-346** Remove the memory tag PCA (3 of 3)



## Reinstall the memory tag PCA and sheet-metal bracket

Make sure that the tab (callout 1) on the sheet-metal bracket is installed in the slot (callout 2) on the chassis.

**Figure 1-347** Reinstall the memory tag PCA




## Image-drum motor

Before proceeding, remove the following assemblies:


- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

## Remove the image-drum motor


 **NOTE:** All four motors are the same part number.

1. Locate the image-drum motors: yellow (callout 1), magenta (callout 2), cyan (callout 3), and black (callout 4).


**Figure 1-348** Remove the image-drum motor (1 of 2)



2. Disconnect one connector (callout 1), remove four screws (callout 2), and then remove the image-drum motor

 **NOTE:** The following figure shows the magenta image-drum motor. The removal procedure is the same for all four motors.

**Figure 1-349** Remove the image-drum motor (2 of 2)



## Fuser power supply

 **CAUTION:**  ESD sensitive assembly.


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the fuser power supply


1. Disconnect four connectors (callout 1), release the wire harnesses from one retainer (callout 2), and then remove two screws (callout 3).

**Figure 1-350** Remove the fuser power supply (1 of 2)



2. Rotate the top of the fuser power supply away from the chassis (callout 1), and then lift it up (callout 2) to remove it.


**Figure 1-351** Remove the fuser power supply (2 of 2)



### Reinstall the fuser power supply


1. Make sure that the tab (callout 1) on the fuser power supply is installed in the slot (callout 2) on the chassis.

**Figure 1-352** Reinstall the fuser power supply (1 of 2)



2. Make sure that the sheet-metal tab below the power connector is positioned as shown below. The tab should be outside of the sheet-metal frame.

**Figure 1-353** Reinstall the fuser power supply (2 of 2)



## Primary transfer-roller disengagement motor


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Fuser power supply. See [Fuser power supply on page 235](#).

### Remove the primary transfer-roller disengagement motor


1. Remove one screw (callout 1), and then remove the motor cover (callout 2).

**Figure 1-354** Remove the primary transfer-roller disengagement motor (1 of 2)



2. Disconnect one connector (callout 1), remove two screws (callout 2), and then remove the primary-transfer roller disengagement motor (callout 3).

**Figure 1-355** Remove the primary transfer-roller disengagement motor (2 of 2)



## Intermediate transfer belt (ITB) alienation-drive assembly


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Fuser power supply. See [Fuser power supply on page 235](#).

### Remove the ITB alienation-drive assembly


1. Remove one screw (callout 1), and then remove the motor cover (callout 2).

**Figure 1-356** Remove the ITB alienation drive assembly (1 of 2)



2. Release one retainer (callout 1), disconnect one connector (callout 2). Remove three screws (callout 3), and then remove the ITB alienation drive assembly (callout 4).

**Figure 1-357** Remove the ITB alienation drive assembly (2 of 2)



## Fuser motor


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the fuser motor


1. Locate the fuser motor (callout 1).

**Figure 1-358** Remove the fuser motor (1 of 2)



2. Disconnect one connector (callout 1), remove three screws (callout 2), and then remove the fuser motor.

**Figure 1-359** Remove the fuser motor (2 of 2)



## Intermediate transfer belt (ITB) motor


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the ITB motor


1. Locate the ITB motor (callout 1).

**Figure 1-360** Remove the ITB motor (1 of 2)



2. Disconnect one connector (callout 1), remove three screws (callout 2), and then remove the ITB motor.

**Figure 1-361** Remove the ITB motor (2 of 2)



## Toner-cartridge feed motor (black)


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the toner-cartridge feed motor (black)


1. Locate the toner-cartridge feed motor (black; callout 1).

**Figure 1-362** Remove the toner-cartridge feed motor (black; 1 of 2)



2. Disconnect one connector (callout 1), remove two screws (callout 2), and then remove the toner-cartridge feed motor (black).

**Figure 1-363** Remove the toner-cartridge feed motor (black; 2 of 2)



## Toner-cartridge feed motor (yellow, magenta, and cyan)


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the toner-cartridge feed motor (yellow, magenta, and cyan)

1. Locate the toner-cartridge feed motor (yellow, magenta, and cyan; callout 1).

**Figure 1-364** Remove the toner-cartridge feed motor (yellow, magenta, and cyan; 1 of 2)




2. Disconnect one connector (callout 1), remove two screws (callout 2), and then remove the toner-cartridge feed motor (yellow, magenta, and cyan).



**Reinstallation tip** Connect the connector (callout 1) before reinstalling the screws (callout 2).

**Figure 1-365** Remove the toner-cartridge feed motor (yellow, magenta, and cyan; 2 of 2)



## Environmental sensor


Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Left cover. See [Left cover on page 118](#).

### Remove the environmental sensor

Disconnect one connector (callout 1). Release three tabs (callout 2), and then remove the environmental sensor (callout 3).

**Figure 1-366** Remove the environmental sensor



## Interconnect PCA (M855)

 **CAUTION:**  ESD sensitive assembly.


Before proceeding, remove the following assemblies:

- Formatter. See [Formatter on page 23](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Left cover. See [Left cover on page 118](#).

### Remove the interconnect PCA (M855)


1. Disconnect four connectors.

**Figure 1-367** Remove the interconnect PCA (M855; 1 of 4)




2. Remove two screws (callout 1).

**Figure 1-368** Remove the interconnect PCA (M855; 2 of 4)




3. Locate one retainer.

**Figure 1-369** Remove the interconnect PCA (M855; 3 of 4)




4. Squeeze the ends of the retainer together (callout 1) to release it, and then remove the retainer (callout 2).

**Figure 1-370** Remove the interconnect PCA (M855; 4 of 4)




## Reinstall the interconnect PCA (M855)

Make sure that the slot (callout 1) on the interconnect PCA is installed over the tab (callout 2) on the chassis.

 **NOTE:** If the formatter was not removed prior to removing the interconnect PCA, remove it before attempting to reinstall the PCA.

**Figure 1-371** Reinstall the interconnect PCA (M855)



## Interconnect PCA (M880)


 **CAUTION:**  ESD sensitive assembly.

Before proceeding, remove the following assemblies:


- Formatter. See [Formatter on page 23](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Left cover. See [Left cover on page 118](#).

### Remove the interconnect PCA (M880)

1. Disconnect two connectors (callout 1) on top of the interconnect PCA and three connectors (callout 2) on the side.


 **NOTE:** Use a small flat-blade screwdriver to press the tab and release one of the top connectors as shown below.

**Figure 1-372** Remove the interconnect PCA (M880; 1 of 4)




2. Remove two screws.

**Figure 1-373** Remove the interconnect PCA (M880; 2 of 4)




3. Locate one retainer.

**Figure 1-374** Remove the interconnect PCA (M880; 3 of 4)



4. Squeeze the ends of the retainer together (callout 1) to release it, and then remove the retainer (callout 2).

**Figure 1-375** Remove the interconnect PCA (M880; 4 of 4)




### Reinstall the interconnect PCA (M880)

Make sure that the slot (callout 1) on the interconnect PCA is installed over the tab (callout 2) on the chassis.



**NOTE:** If the formatter was not removed prior to removing the interconnect PCA, remove it before attempting to reinstall the PCA.

**Figure 1-376** Reinstall the interconnect PCA (M880)



## Formatter case


Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Left cover. See [Left cover on page 118](#).
- Interconnect PCA (M855). See [Interconnect PCA \(M855\) on page 248](#).
- Interconnect PCA (M880). See [Interconnect PCA \(M880\) on page 252](#).

### Remove the formatter case


1. **M880 only:** Remove the cable from two retainers.

**Figure 1-377** Remove the formatter case (1 of 2)



2. Remove seven screws (callout 1), and then remove the formatter case.


**Figure 1-378** Remove the formatter case (2 of 2)



### Reinstall the formatter case

Make sure that the tab (callout 1) on the formatter case is installed in the slot (callout 2) on the chassis.

**Figure 1-379** Reinstall the formatter case



## Formatter, formatter case, and interconnect board (ICB)



**NOTE:** This procedure can be used to gain access to the DC controller when removing the main drive assembly.


### Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Left cover. See [Left cover on page 118](#).


### Remove the formatter, formatter case, and ICB

1. Remove the wire harness from one retainer (callout 1). **M880 only:** Remove the cable from two retainers (callout 2).


**Figure 1-380** Remove the formatter, formatter case, and ICB (1 of 4)



2. Disconnect four connectors (callout 1). **M880 only:** Disconnect one additional connector (callout 2) by pressing one tab while pulling up gently on the cable.


 **NOTE:** Use a small flat-blade screwdriver to press the tab and release the connector (callout 2).

**Figure 1-381** Remove the formatter, formatter case, and ICB (2 of 4)




3. Remove seven screws (callout 1).

**Figure 1-382** Remove the formatter, formatter case, and ICB (3 of 4)



4. Lift up (callout 1) to release one hook (callout 2), and then remove the formatter, formatter case, and ICB.


**Figure 1-383** Remove the formatter, formatter case, and ICB (4 of 4)



### Reinstall the formatter, formatter case, and ICB

Make sure that the hook on the formatter case is installed in the slot on the chassis.

**Figure 1-384** Reinstall the formatter, formatter case, and ICB



## High-voltage power supply (HVPS) B


 **CAUTION:**  ESD sensitive assembly.

Before proceeding, remove the following assemblies:


- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Left cover. See [Left cover on page 118](#).

### Remove the HVPS B

1. Disconnect two connectors (callout 1), and then remove one screw (callout 2).


 **CAUTION:** Use care when disconnecting the white plastic connector at the top of the PCA. It can be easily damaged.

**Figure 1-385** Remove the HVPS B (1 of 2)



2. Release six tabs (callout 1) and then remove the HVPS B.


**Figure 1-386** Remove the HVPS B (2 of 2)




## Reinstall the HVPS B

1. After the HVPS B is installed and all tabs are in place, locate the circular locator windows (callout 1) along the side of the HVPS B.


**Figure 1-387** Reinstall the HVPS B (1 of 2)



2. Make sure that the contact spring (callout 1) can be seen through the eight locator windows. If the spring cannot be seen, remove and reinstall the HVPS B.

 **NOTE:** No error message is displayed on the control panel if these springs are positioned incorrectly. Poor print quality will be the only indicator.

**Figure 1-388** Reinstall the HVPS B (2 of 2)



## DC controller PCA

 **CAUTION:**  ESD sensitive assembly.


Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Left cover. See [Left cover on page 118](#).
- Formatter case. See [Formatter case on page 255](#).

### Remove the DC controller PCA

Disconnect all of the connectors on the DC controller PCA. Remove six screws (callout 1), and then remove the DC controller PCA.

**Figure 1-389** Remove the DC controller PCA



## Color-plane registration (CPR) sensor assembly


Before proceeding, remove the following assemblies:

- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left cover. See [Left cover on page 118](#).
- Front top cover. See [Front top cover on page 115](#).
- Front door assembly. See [Front door on page 137](#).
- Left front cover. See [Left front cover on page 133](#).
- Front inner cover. See [Front inner cover on page 147](#).

### Remove the CPR sensor assembly


1. Remove one screw (callout 1), and then remove the bracket (callout 2).

**Figure 1-390** Remove the CPR sensor assembly (1 of 5)




2. Remove three screws (callout 1).

**Figure 1-391** Remove the CPR sensor assembly (2 of 5)




3. Slide the sheet-metal cover out of the product.

**Figure 1-392** Remove the CPR sensor assembly (3 of 5)





4. Disconnect two connectors inside the cartridge cavity.

**Figure 1-393** Remove the CPR sensor assembly (4 of 5)




5. Lift the CPR sensor assembly up to release two hooks on the assembly from the metal rod.

 **NOTE:** One clip is located toward the front of the product, and the other clip is located toward the back of the product.

 **Reinstallation tip** Make sure that the clips are snapped into place when reinstalling the CPR sensor assembly.


**Figure 1-394** Remove the CPR sensor assembly (5 of 5)




## Reinstall the CPR sensor assembly

1. Note the location of two springs (callout 1) on the CPR sensor assembly. When reinstalling the CPR sensor assembly, make sure that these springs are positioned between the CPR sensor assembly and the product chassis.


**Figure 1-395** Reinstall the CPR sensor assembly (1 of 4)



2. After the CPR sensor assembly is reinstalled, look into the cavity where the ITB would be installed. Locate the spring pedestal (callout 1), and make sure that the CPR spring at the back right-hand corner is correctly positioned (callout 2).


 **TIP:** This spring can also be viewed by looking into the cavity where the black toner cartridge would be installed.

**Figure 1-396** Reinstall the CPR sensor assembly (2 of 4)




3. Make sure that the tabs (callout 1) on the sheet-metal cover are inserted into the slots (callout 2) inside the product.

**Figure 1-397** Reinstall the CPR sensor assembly (3 of 4)



4. Make sure that the tab on the bracket (callout 1) is positioned in the slot in the chassis (callout 2).

**Figure 1-398** Reinstall the CPR sensor assembly (4 of 4)



## Low-voltage power supply (LVPS)


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).

### Remove the LVPS


1. **M880 only:** Disconnect one connector (callout 1).

**Figure 1-399** Remove the LVPS (1 of 5)




2. Disconnect four connectors (callout 1), and then release the wire harnesses from three retainers (callout 2).

**Figure 1-400** Remove the LVPS (2 of 5)




3. Remove three screws (callout 1).

**Figure 1-401** Remove the LVPS (3 of 5)




4. Lift the LVPS up (callout 1), push in on the lower right side (callout 2), and then rotate the top of the LVPS away from the product (callout 3).

**Figure 1-402** Remove the LVPS (4 of 5)



5. Lift the LVPS up and out of the product

**Figure 1-403** Remove the LVPS (5 of 5)



## High-voltage power supply (HVPS) A (first transfer)

 **CAUTION:**  ESD sensitive assembly.


Before proceeding, remove the following assemblies:

- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Low-voltage power supply (LVPS). See [Low-voltage power supply \(LVPS\) on page 269](#).


### Remove the HVPS A (first transfer)

1. Disconnect one connector (callout 1), and then remove one screw (callout 2).


**Figure 1-404** Remove the HVPS A (first transfer) (1 of 3)



2. Release seven tabs.


 **TIP:** Release the corner tabs first.

**Figure 1-405** Remove the HVPS A (first transfer) (2 of 3)



3. Lift the HVPS A up and off of one retainer, and then remove it from the product.


**Figure 1-406** Remove the HVPS A (first transfer) (3 of 3)



## Reinstall the HVPS A (first transfer)


1. Position the slot bordered in white on the HVPS A into the retainer on the chassis before engaging the clips.

**Figure 1-407** Reinstall the HVPS A (first transfer) (1 of 3)




2. After the HVPS A is installed and all tabs are in place, locate the circular locator windows across the top of the HVPS A.


**Figure 1-408** Reinstall the HVPS A (first transfer) (2 of 3)



3. Make sure that the contact spring (callout 1) can be seen through the 32 locator windows. If the spring cannot be seen, remove and reinstall the HVPS A (first transfer).

 **NOTE:** No error message is displayed on the control panel if these springs are positioned incorrectly. Poor print quality will be the only indicator.

**Figure 1-409** Reinstall the HVPS A (first transfer) (3 of 3)



## Lifter-drive assembly


Before proceeding, remove the following assemblies:

- Tray 2. See [Tray 2, 1x500 Tray 3, 3x500 Tray 3, 3x500 Tray 4, and 3x500 Tray 5 on page 18](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Low-voltage power supply (LVPS). See [Low-voltage power supply \(LVPS\) on page 269](#).
- High-voltage power supply (HVPS) A (first transfer). See [High-voltage power supply \(HVPS\) A \(first transfer\) on page 272](#).

### Remove the lifter-drive assembly


1. Disconnect three connectors (callout 1).

**Figure 1-410** Remove the lifter-drive assembly (1 of 3)



2. Remove three screws (callout 1), and then release two tabs (callout 2).

**Figure 1-411** Remove the lifter-drive assembly (2 of 3)



3. Remove the lifter-drive assembly through the Tray 2 cavity.


**Figure 1-412** Remove the lifter-drive assembly (3 of 3)




## Reinstall the lifter-drive assembly

1. When reinstalling the lifter-drive assembly, make sure that the assembly is unlocked (callout 1). If the lifter is locked (callout 2), the lifter will not function properly.

**Figure 1-413** Unlocked position of the lifter-driver assembly (correct)




**Figure 1-414** Locked position of the lifter-driver assembly (incorrect)



2. If the assembly is in the locked position (callout 2 above), use a small, flat-blade screwdriver to press on the spring-loaded metal plate and move it to the unlocked position.

**Figure 1-415** Unlocking the lifter-drive assembly



## Toner-cartridge drive assembly (yellow and magenta)

Before proceeding, remove the following assemblies:

- All four toner cartridges. See [Toner cartridge on page 14](#).
- All four imaging drums. See [Imaging drum on page 15](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Memory tag PCA. See [Memory tag PCA on page 230](#).
- Fuser fan FM2. See [Fuser fan FM2 on page 207](#).
- Cartridge fan FM3 (yellow and magenta). See [Cartridge fan FM3 \(yellow and magenta\) on page 214](#).
- Laser/scanner fan FM1. See [Laser/scanner fan FM1 on page 222](#).
- All four image drum motors. See [Image-drum motor on page 233](#).
- Fuser motor. See [Fuser motor on page 242](#).
- Fuser fan duct. See [Fuser fan duct on page 211](#).
- Toner-cartridge feed motor (yellow, magenta, and cyan). See [Toner-cartridge feed motor \(yellow, magenta, and cyan\) on page 245](#).


## Remove the toner-cartridge drive assembly (yellow and magenta)

Disconnect one connector (callout 1), remove four screws (callout 2), and then remove the toner-cartridge drive assembly (yellow and magenta; callout 3).




**NOTE:** Two of the screws are longer than the other two. See the reinstallation instructions below.

**Figure 1-416** Remove the toner-cartridge drive assembly (yellow and magenta)




## Reinstall the toner-cartridge drive assembly (yellow and magenta)

1. Follow the gear-alignment procedure when replacing or reinstalling the toner-cartridge drive assembly (yellow and magenta). See [Replace or reinstall the toner-cartridge drive assemblies or the main drive assembly on page 291](#).
2. After the gear-alignment procedure is complete, install the two longer screws in the top positions (callout 1), and then install the two shorter screws in the lower positions (callout 2).

 **NOTE:** Move the black locks on the main drive assembly to the right (unlocked position) in order to install the lower screws in the toner-cartridge drive assembly.

**Figure 1-417** Reinstall the toner-cartridge drive assembly (yellow and magenta)



## Toner-cartridge drive assembly (cyan and black)

Before proceeding, remove the following assemblies:

- All four toner cartridges. See [Toner cartridge on page 14](#).
- All four imaging drums. See [Imaging drum on page 15](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Fuser fan FM2. See [Fuser fan FM2 on page 207](#).
- Fuser fan duct. See [Fuser fan duct on page 211](#).
- Cartridge fan FM3 (yellow and magenta). See [Cartridge fan FM3 \(yellow and magenta\) on page 214](#).
- Cartridge fan FM4 (cyan and black). See [Cartridge fan FM4 \(cyan and black\) on page 218](#).
- Laser/scanner fan FM1. See [Laser/scanner fan FM1 on page 222](#).
- Memory tag PCA. See [Memory tag PCA on page 230](#).
- All four image drum motors. See [Image-drum motor on page 233](#).
- Fuser motor. See [Fuser motor on page 242](#).
- Toner-cartridge feed motor (black). See [Toner-cartridge feed motor \(black\) on page 244](#).
- Toner-cartridge feed motor (yellow, magenta, and cyan). See [Toner-cartridge feed motor \(yellow, magenta, and cyan\) on page 245](#).
- Toner-cartridge drive assembly (yellow and magenta). See [Toner-cartridge drive assembly \(yellow and magenta\) on page 280](#).


## Remove the toner-cartridge drive assembly (cyan and black)

Disconnect one connector (callout 1), remove three screws (callout 2), and then remove the toner-cartridge drive assembly (cyan and black; callout 3).




**NOTE:** One of the screws is longer than the other two. See the reinstallation instructions below.

**Figure 1-418** Remove the toner-cartridge drive assembly (cyan and black)




### Reinstall the toner-cartridge drive assembly (cyan and black)

1. Follow the gear-alignment procedure when replacing or reinstalling the toner-cartridge drive assembly (cyan and black). See [Replace or reinstall the toner-cartridge drive assemblies or the main drive assembly on page 291](#).
2. After the gear-alignment procedure is complete, install the longer screw in the top position (callout 1), and then install the two shorter screws in the lower positions (callout 2).


 **NOTE:** Move the black locks on the main drive assembly to the right (unlocked position) in order to install the lower screws in the toner-cartridge drive assembly.

**Figure 1-419** Reinstall the toner-cartridge drive assembly (cyan and black)



## Cartridge interface PCA (cyan and black)

 **CAUTION:**  ESD sensitive assembly.

 **NOTE:** This part is the same part number as the cartridge interface PCA (yellow and magenta).

Before proceeding, remove the following assemblies:


- All four toner cartridges. See [Toner cartridge on page 14](#).
- All four imaging drums. See [Imaging drum on page 15](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Fuser fan FM2. See [Fuser fan FM2 on page 207](#).
- Fuser fan duct. See [Fuser fan duct on page 211](#).
- Cartridge fan FM3 (yellow and magenta). See [Cartridge fan FM3 \(yellow and magenta\) on page 214](#).
- Cartridge fan FM4 (cyan and black). See [Cartridge fan FM4 \(cyan and black\) on page 218](#).
- Laser/scanner fan FM1. See [Laser/scanner fan FM1 on page 222](#).
- Memory tag PCA. See [Memory tag PCA on page 230](#).
- All four image drum motors. See [Image-drum motor on page 233](#).
- Fuser motor. See [Fuser motor on page 242](#).
- Toner-cartridge feed motor (black). See [Toner-cartridge feed motor \(black\) on page 244](#).
- Toner-cartridge feed motor (yellow, magenta, and cyan). See [Toner-cartridge feed motor \(yellow, magenta, and cyan\) on page 245](#).
- Toner-cartridge drive assembly (yellow and magenta). See [Toner-cartridge drive assembly \(yellow and magenta\) on page 280](#).
- Toner-cartridge drive assembly (cyan and black). See [Toner-cartridge drive assembly \(cyan and black\) on page 282](#).

## Remove the cartridge interface PCA (cyan and black)

Remove three screws (callout 1), release one tab (callout 2), and then remove the cartridge interface PCA (cyan and black; callout 3).


 **NOTE:** These screws have washers attached.

**Figure 1-420** Remove the cartridge interface PCA (cyan and black)



## Cartridge interface PCA (yellow and magenta)

 **CAUTION:**  ESD sensitive assembly.

 **NOTE:** This part is the same part number as the cartridge interface PCA (cyan and black).

Before proceeding, remove the following assemblies:


- All four toner cartridges. See [Toner cartridge on page 14](#).
- All four imaging drums. See [Imaging drum on page 15](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Fuser fan FM2. See [Fuser fan FM2 on page 207](#).
- Fuser fan duct. See [Fuser fan duct on page 211](#).
- Cartridge fan FM4 (cyan and black). See [Cartridge fan FM4 \(cyan and black\) on page 218](#).
- Cartridge fan FM3 (yellow and magenta). See [Cartridge fan FM3 \(yellow and magenta\) on page 214](#).
- Laser/scanner fan FM1. See [Laser/scanner fan FM1 on page 222](#).
- Memory tag PCA. See [Memory tag PCA on page 230](#).
- All four image drum motors. See [Image-drum motor on page 233](#).
- Fuser motor. See [Fuser motor on page 242](#).
- Toner-cartridge feed motor (yellow, magenta, and cyan). See [Toner-cartridge feed motor \(yellow, magenta, and cyan\) on page 245](#).
- Toner-cartridge drive assembly (yellow and magenta). See [Toner-cartridge drive assembly \(yellow and magenta\) on page 280](#).

## Remove the cartridge interface PCA (yellow and magenta)

Remove three screws (callout 1), release one tab (callout 2), and then remove the cartridge interface PCA (yellow and magenta; callout 3).

 **NOTE:** These screws have washers attached.

**Figure 1-421** Remove the cartridge interface PCA (yellow and magenta)



## Main drive assembly

Before proceeding, remove the following assemblies:


- All four toner cartridges. See [Toner cartridge on page 14](#).
- Intermediate transfer belt (ITB). See [Intermediate transfer belt \(ITB\) on page 19](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Left cover. See [Left cover on page 118](#).
- Rear cover. See [Rear cover on page 143](#).
- Fuser fan FM2. See [Fuser fan FM2 on page 207](#).
- Fuser fan duct. See [Fuser fan duct on page 211](#).
- Cartridge fan FM3 (yellow and magenta). See [Cartridge fan FM3 \(yellow and magenta\) on page 214](#).
- Cartridge fan FM4 (cyan and black). See [Cartridge fan FM4 \(cyan and black\) on page 218](#).
- Laser/scanner fan FM1. See [Laser/scanner fan FM1 on page 222](#).
- Memory tag PCA. See [Memory tag PCA on page 230](#).
- All four image drum motors. See [Image-drum motor on page 233](#).
- Fuser power supply. See [Fuser power supply on page 235](#).
- Intermediate transfer belt (ITB) alienation-drive assembly. See [Intermediate transfer belt \(ITB\) alienation-drive assembly on page 240](#).
- Fuser motor. See [Fuser motor on page 242](#).
- Toner-cartridge feed motor (black). See [Toner-cartridge feed motor \(black\) on page 244](#).
- Toner-cartridge feed motor (yellow, magenta, and cyan). See [Toner-cartridge feed motor \(yellow, magenta, and cyan\) on page 245](#).
- Formatter, formatter case, and interconnect board (ICB). See [Formatter, formatter case, and interconnect board \(ICB\) on page 257](#).
- Low-voltage power supply (LVPS). See [Low-voltage power supply \(LVPS\) on page 269](#).
- High-voltage power supply (HVPS) A (first transfer). See [High-voltage power supply \(HVPS\) A \(first transfer\) on page 272](#).
- Toner-cartridge drive assembly (yellow and magenta). See [Toner-cartridge drive assembly \(yellow and magenta\) on page 280](#).
- Toner-cartridge drive assembly (cyan and black). See [Toner-cartridge drive assembly \(cyan and black\) on page 282](#).

- Cartridge interface PCA (cyan and black). See [Cartridge interface PCA \(cyan and black\) on page 284](#).
- Cartridge interface PCA (yellow and magenta). See [Cartridge interface PCA \(yellow and magenta\) on page 286](#).

## Remove the main drive assembly

1. Disconnect four connectors (J113, J138, J141, and J142; callout 1) on the DC Controller, and then release the wire harnesses from the guide (callout 2).


**Figure 1-422** Remove the main drive assembly (1 of 2)



2. Remove 12 screws, and then remove the main drive assembly.

**CAUTION:** Do not remove the six red screws around the main drive assembly. Removal of these screws will cause damage to the assembly.


**Figure 1-423** Remove the main drive assembly (2 of 2)



## Reinstall the main drive assembly

1. Do not touch the LEDs (callout 1) or the bias connections (callout 2) on the back of the main drive assembly. Contamination of these parts by grease or oil might result in print quality problems.

**Figure 1-424** Reinstall the main drive assembly



2. Follow the gear-alignment procedure when replacing or reinstalling the main drive assembly. See [Replace or reinstall the toner-cartridge drive assemblies or the main drive assembly on page 291](#).

## Replace or reinstall the toner-cartridge drive assemblies or the main drive assembly

When the toner-cartridge drive units or the main drive assembly are installed on the product, the gears inside these assemblies must be realigned to ensure correct operation of the product. The following procedures explain how to align the gears when replacing the part or reinstalling the part after service.


- If you are replacing the toner-cartridge drive assembly or the main drive assembly, see [Replace the toner-cartridge drive assembly or the main drive assembly on page 291](#)
- If you are reinstalling the current toner-cartridge drive assembly or the main drive assembly, see [Reinstall the toner-cartridge drive assembly or the main drive assembly on page 296](#)

### Replace the toner-cartridge drive assembly or the main drive assembly

This procedure correctly aligns the gears of the main drive assembly (callout 1) and the toner-cartridge drive assembly(ies) (callout 2). Use the four pins (callout 3) supplied with the replacement units to align the gears.


 **NOTE:** The toner-cartridge drive assembly (black) is shown in the figure below.

**Figure 1-425** Replace the toner-cartridge drive assembly or the main drive assembly (1 of 8)




1. Reinstall the main drive assembly. Push the black locks (callout 1) to the left while rotating the top gears (callout 2) on the main drive assembly until they lock into position. The large holes (callout 3) should point to the right (3 o'clock position).

**Figure 1-426** Replace the toner-cartridge drive assembly or the main drive assembly (2 of 8)




2. Insert the long alignment pins (callout 1) through the gears (callout 2) in the main drive assembly.

**Figure 1-427** Replace the toner-cartridge drive assembly or the main drive assembly (3 of 8)




3. On the toner-cartridge drive assembly, rotate the top gear (callout 1) clockwise until the arrows align (callout 2). Insert the two short pins (callout 3).


**Figure 1-428** Replace the toner-cartridge drive assembly or the main drive assembly (4 of 8)



4. Install the toner-cartridge drive assembly (callout 1) over the long pins in the main drive assembly (callout 2).

 **NOTE:** The toner-cartridge drive assembly (black) is shown in the figure below.


**Figure 1-429** Replace the toner-cartridge drive assembly or the main drive assembly (5 of 8)




5. Check the installation of the toner-cartridge drive assembly.

**CAUTION:** Make sure that the toner-cartridge drive assembly is installed correctly. The assembly should be flush against the chassis (callout 1). Incorrect installation (callout 2) will cause the product to function incorrectly.

**Figure 1-430** Correct position of toner-cartridge drive assembly (6 of 8)



**Figure 1-431** Incorrect position of toner-cartridge drive assembly (7 of 8)




6. Remove the alignment pins (callout 1).



**NOTE:** The toner-cartridge drive assembly (black) is shown in the figure below.


**Figure 1-432** Replace the toner-cartridge drive assembly or the main drive assembly (8 of 8)




## Reinstall the toner-cartridge drive assembly or the main drive assembly

This procedure correctly aligns the gears of the main drive assembly and the toner-cartridge drive assembly(ies) without the use of alignment pins.

1. Reinstall the main drive assembly. Push the black locks (callout 1) to the left while rotating the top gears (callout 2) on the main drive assembly until they lock into position. The large holes (callout 3) should point to the right (3 o'clock position).


 **IMPORTANT:** When reinstalling without the alignment pins, it is important to verify that the locks (callout 1) are engaged.

**Figure 1-433** Reinstall the toner-cartridge drive assembly or the main drive assembly (1 of 4)



2. On the toner-cartridge drive assembly, rotate the top gear (callout 1) clockwise until the arrows align (callout 2).

**Figure 1-434** Reinstall the toner-cartridge drive assembly or the main drive assembly (2 of 4)



3. Carefully install the toner-cartridge drive assembly.




**NOTE:** Be careful not to rotate the gears on the toner-cartridge drive assembly while installing it.

4. Check the installation of the toner-cartridge drive assembly.




**CAUTION:** Make sure that the toner-cartridge drive assembly is installed correctly. The assembly should be flush against the chassis (callout 1). Incorrect installation (callout 2) will cause the product to function incorrectly.

**Figure 1-435** Correct position of toner-cartridge drive assembly (3 of 4)



**Figure 1-436** Incorrect position of toner-cartridge drive assembly (4 of 4)



## Fuser drive assembly


Before proceeding, remove the following assemblies:

- Fuser. See [Fuser on page 21](#).
- Left rear cover. See [Left rear cover on page 104](#).
- Rear cover. See [Rear cover on page 143](#).
- Fuser motor. See [Fuser motor on page 242](#).

### Remove the fuser drive assembly


1. Disconnect two connectors (callout 1), release one wire harness from the retainer (callout 2), and then release the wire harnesses from the guide (callout 3).

**Figure 1-437** Remove the fuser drive assembly (1 of 10)




2. At the right-rear side of the product, remove one screw (callout 1).

**Figure 1-438** Remove the fuser drive assembly (2 of 10)




3. Open the right door, and then remove one screw.

**Figure 1-439** Remove the fuser drive assembly (3 of 10)




4. Slide the retainer arm and guide to the left to disengage it from the chassis.

**Figure 1-440** Remove the fuser drive assembly (4 of 10)




5. Remove one screw (callout 1), and then remove the handle (callout 2).

**Figure 1-441** Remove the fuser drive assembly (5 of 10)




6. Remove two screws (callout 1), and then remove the right inner cover (callout 2).

**Figure 1-442** Remove the fuser drive assembly (6 of 10)




7. Use a small flat-blade screwdriver to release one plastic pin (callout 1), and then slide the duct to the right (callout 2) to remove it.

 **TIP:** Use the arrow embossed on the duct to locate the pin (callout 1).

**Reinstallation tip** Lift up on the pin when the duct is reinstalled.


**Figure 1-443** Remove the fuser drive assembly (7 of 10)



8. Remove one screw (callout 1), and then separate the fuser cover open detection sensor holder (callout 2) from the chassis.


**CAUTION:** The holder is still attached to the product. Do not attempt to completely remove the holder. Separate it from the product, and move it out of the way.

**Figure 1-444** Remove the fuser drive assembly (8 of 10)




9. Remove four screws.

**Figure 1-445** Remove the fuser drive assembly (9 of 10)



10. Remove the fuser drive assembly.


**Figure 1-446** Remove the fuser drive assembly (10 of 10)



### Reinstall the fuser drive assembly


1. Make sure that the wire harness is routed through the correct opening in the chassis when reinstalling the assembly.

**Figure 1-447** Reinstall the fuser drive assembly (1 of 4)




2. When reinstalling the fuser cover open detection sensor holder, make sure that the tab on the holder (callout 1) is installed in the opening in the chassis (callout 2).

**Figure 1-448** Reinstall the fuser drive assembly (2 of 4)




3. When reinstalling the duct, make sure that the tabs on the duct (callout 1) are installed in the slots in the chassis (callout 2).

**Figure 1-449** Reinstall the fuser drive assembly (3 of 4)



4. When reinstalling the retainer arm, make sure that the tabs on the arm (callout 1) are installed in the slots in the chassis (callout 2).

**Figure 1-450** Reinstall the fuser drive assembly (4 of 4)



## Scanner cover

Before proceeding, remove the following assemblies:


- Control panel assembly (M880). See [Control panel assembly \(M880\) on page 53](#).
- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Switch back cover. See [Switch back cover on page 105](#).
- Right upper rear cover (M855). See [Right upper rear cover \(M855\) on page 96](#).
- Right upper rear cover (M880). See [Right upper rear cover \(M880\) on page 108](#).
- Front top cover. See [Front top cover on page 115](#).
- Rear top cover. See [Rear top cover \(M855\) on page 116](#).
- Document feeder assembly (M880). See [Document feeder assembly \(M880\) on page 154](#).
- Scanner assembly (M880). See [Scanner assembly \(M880\) on page 162](#).

### Remove the scanner cover

Remove eight screws (callout 1) and then remove the scanner cover (callout 2).

**CAUTION:** Be careful. Do not drop any of the screws into the product.

**Figure 1-451** Remove the scanner cover



## Laser/scanner assembly (yellow and magenta)


Before proceeding, remove the following assemblies:

- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Switch back cover. See [Switch back cover on page 105](#).
- Right upper rear cover (M855). See [Right upper rear cover \(M855\) on page 96](#).
- Right upper rear cover (M880). See [Right upper rear cover \(M880\) on page 108](#).
- Front top cover. See [Front top cover on page 115](#).
- Rear top cover. See [Rear top cover \(M855\) on page 116](#).
- Document feeder assembly (M880). See [Document feeder assembly \(M880\) on page 154](#).
- Scanner assembly (M880). See [Scanner assembly \(M880\) on page 162](#).
- Scanner cover. See [Scanner cover on page 306](#).

## Remove the laser/scanner assembly (yellow and magenta)


1. Disconnect one connector (callout 1), release one tab (callout 2), and then slide the corner cover to the right (callout 3) to remove it.

**Figure 1-452** Remove the laser/scanner assembly (yellow and magenta; 1 of 6)




2. Disconnect two connectors.

**Figure 1-453** Remove the laser/scanner assembly (yellow and magenta; 2 of 6)



3. Remove three springs.

**Figure 1-454** Remove the laser/scanner assembly (yellow and magenta; 3 of 6)




**TIP:** Hold the spring in place with one hand while releasing it with needle-nose pliers in the other hand.

**Figure 1-455** Remove the laser/scanner assembly (yellow and magenta; 4 of 6)




4. Lift up on the edge of the assembly closest to the left door, and then slide the assembly toward the front of the product.

**Figure 1-456** Remove the laser/scanner assembly (yellow and magenta; 5 of 6)



5. Rotate the left side of the assembly toward the left door (callout 1), and then slide the assembly toward the back of the product (callout 2) to remove it.


**Figure 1-457** Remove the laser/scanner assembly (yellow and magenta; 6 of 6)



## Reinstall the laser/scanner assembly (yellow and magenta)


1. **CAUTION:** Use care when reinstalling the cables for the laser/scanner assemblies. The traces on the cable ends can be damaged when reinserted.

**Figure 1-458** Reinstall the laser/scanner assembly (yellow and magenta; 1 of 2)



2. **CAUTION:** Make sure that the tabs on each side of the laser/scanner are fully seated.

**Figure 1-459** Reinstall the laser/scanner assembly (yellow and magenta; 2 of 2)



## Laser/scanner assembly (cyan and black)


Before proceeding, remove the following assemblies:

- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Right upper rear cover (M855). See [Right upper rear cover \(M855\) on page 96](#).
- Right upper rear cover (M880). See [Right upper rear cover \(M880\) on page 108](#).
- Front top cover. See [Front top cover on page 115](#).
- Rear top cover. See [Rear top cover \(M855\) on page 116](#).
- Document feeder assembly (M880). See [Document feeder assembly \(M880\) on page 154](#).
- Scanner assembly (M880). See [Scanner assembly \(M880\) on page 162](#).
- Scanner cover. See [Scanner cover on page 306](#).

### Remove the laser/scanner assembly (cyan and black)


1. Disconnect one connector (callout 1), release one tab (callout 2), and then slide the corner cover to the right (callout 3) to remove it.

**Figure 1-460** Remove the laser/scanner assembly (cyan and black; 1 of 8)




2. Disconnect two connectors (callout 1), and then remove one spring (callout 2).

**Figure 1-461** Remove the laser/scanner assembly (cyan and black; 2 of 8)




3. Press and hold one spring-loaded tab (callout 1), and then slide the sheet-metal bar toward the front door (callout 2) to release it.

**Figure 1-462** Remove the laser/scanner assembly (cyan and black; 3 of 8)




4. Lift up the edge of the laser/scanner assembly (yellow and magenta; callout 1), and then remove the bar (callout 2).


**Figure 1-463** Remove the laser/scanner assembly (cyan and black; 4 of 8)



5. Remove three springs.

**Figure 1-464** Remove the laser/scanner assembly (cyan and black; 5 of 8)




 **TIP:** Hold the spring in place with one hand while releasing it with needle-nose pliers in the other hand.

**Figure 1-465** Remove the laser/scanner assembly (cyan and black; 6 of 8)




6. Lift up the edge of the laser/scanner assembly (yellow and magenta) (callout 1), and then slide the laser/scanner (cyan and black) to the right (callout 2).

**Figure 1-466** Remove the laser/scanner assembly (cyan and black; 7 of 8)



7. Lift up the edge of the laser/scanner assembly (yellow and magenta), rotate the left side of the assembly towards the left door (callout 1), and then slide the assembly toward the back of the product (callout 2) to remove it.


**Figure 1-467** Remove the laser/scanner assembly (cyan and black; 8 of 8)



## Reinstall the laser/scanner assembly (cyan and black)

1. **CAUTION:** Use care when reinstalling the cables for the laser/scanner assemblies. The traces on the cable ends can be damaged when reinserted.

**Figure 1-468** Reinstall the laser/scanner assembly (cyan and black; 1 of 3)




2. When reinstalling the bar, install the hook on the bar in the slot in the chassis as shown below.

**Figure 1-469** Reinstall the laser/scanner assembly (cyan and black; 2 of 3)



3. Make sure that the spring on the laser/scanner assembly (yellow and magenta) is in place.

**Figure 1-470** Reinstall the laser/scanner assembly (cyan and black; 3 of 3)



## Duplex reverse assembly (M855)


Before proceeding, remove the following assemblies:

- Switch back cover. See [Switch back cover on page 105](#).

### Remove the duplex reverse assembly (M855)

Disconnect four connectors (callout 1), remove two screws (callout 2), and then remove the duplex reverse assembly (callout 3).

**Figure 1-471** Remove the duplex reverse assembly (M855)



## Duplex reverse assembly (M880)


Before proceeding, remove the following assemblies:

- Switch back cover. See [Switch back cover on page 105](#).

### Remove the duplex reverse assembly (M880)

Disconnect three connectors (callout 1), remove two screws (callout 2), and then remove the duplex reverse assembly (callout 3).

**Figure 1-472** Remove the duplex reverse assembly (M880)



## VOC fan (M855)


Before proceeding, remove the following assemblies:

- Switch back tray. See [Switch back tray on page 22](#).
- Control panel (M855). See [Control panel assembly \(M855\) on page 47](#).
- Right upper rear cover (M855). See [Right upper rear cover \(M855\) on page 96](#).
- Hardware integration pocket (HIP) cover (M855). See [Hardware integration pocket \(HIP\) cover \(M855\) on page 97](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Switch back cover. See [Switch back cover on page 105](#).
- Right upper front cover (M855). See [Right upper front cover \(M855\) on page 120](#).
- Front top cover. See [Front top cover on page 115](#).
- Rear top cover. See [Rear top cover \(M855\) on page 116](#).
- Right upper cover (M855). See [Right upper cover \(M855\) on page 124](#).

### Remove the VOC fan (M855)

1. At the top of the product, release the wire harness from the retainer (callout 1), and then disconnect one connector (callout 2).

**Figure 1-473** Remove the VOC fan (M855; 1 of 2)




2. Remove one screw (callout 1), and then remove the VOC fan (callout 2).



**Reinstallation tip** When the fan is reinstalled, make sure that the tab on the bottom fits into the slot provided on the chassis.

**Figure 1-474** Remove the VOC fan (M855; 2 of 2)



## VOC fan (M880)

Before proceeding, remove the following assemblies:

- Switch back tray. See [Switch back tray on page 22](#).
- Scanner back cover (M880). See [Scanner back cover \(M880\) on page 88](#).
- Remove one of the following, depending upon product configuration:
  - Face-down bin. See [Face-down bin on page 101](#).
  - Intermediate paper transport unit (IPTU). See [IPTU assembly on page 437](#).
- Switch back cover. See [Switch back cover on page 105](#).
- Rear upper rear cover (M880). See [Rear upper rear cover \(M880\) on page 107](#).
- Right upper rear cover (M880). See [Right upper rear cover \(M880\) on page 108](#).
- Rear upper MFP cover (M880). See [Rear upper MFP cover \(M880\) on page 109](#).
- Left upper rear cover (M880). See [Left upper rear cover and rear upper B cover \(M880\) on page 111](#).
- Rear upper front cover. See [Rear upper front cover \(M880\) on page 113](#).
- Front top cover. See [Front top cover on page 115](#).
- Right upper front cover (M880). See [Right upper front cover \(M880\) on page 122](#).
- Document feeder assembly (M880). See [Document feeder assembly \(M880\) on page 154](#).
- Scanner assembly (M880). See [Scanner assembly \(M880\) on page 162](#).
- Duplex reverse assembly (M880). See [Duplex reverse assembly \(M880\) on page 320](#).

## Remove the VOC fan (M880)


1. Remove one screw.

**Figure 1-475** Remove the VOC fan (M880; 1 of 6)




2. Remove one screw (callout 1), and then release one tab (callout 2).

**Figure 1-476** Remove the VOC fan (M880; 2 of 6)




3. Release one tab.

**Figure 1-477** Remove the VOC fan (M880; 3 of 6)



4. Release four tabs (callout 1), and then remove the switch back inner cover (callout 2).


**Figure 1-478** Remove the VOC fan (M880; 4 of 6)



5. Remove one screw (callout 1), and then lift the VOC fan (callout 2) away from the product.

**CAUTION:** The VOC fan is still attached to the product by a wire harness. Do not attempt to completely remove the VOC fan.

**Figure 1-479** Remove the VOC fan (M880; 5 of 6)



6. Release the wire harness from the retainer (callout 1), and then disconnect one connector (callout 2) to remove the VOC fan.

**Reinstallation tip** When the fan is reinstalled, make sure that the tab on the bottom fits into the slot provided on the chassis.

**Figure 1-480** Remove the VOC fan (M880; 6 of 6)

